

SOFTWARE LICENSE KEY GENERATOR AND SERIAL NUMBER REPOSITORY

SLK User Guide v5.0 Document Title: SLK User Guide v5.0

DigitalCM Number: 365-095-31649 x.1

Publication Date: 5/2017

ARRIS Trademarks, Copyright, and Other Proprietary Information

©ARRIS Enterprises, LLC, 2017. All rights reserved. No part of this publication may be reproduced in any form or by any means or used to make any derivative work (such as translation, transformation, or adaptation) without written permission from ARRIS Enterprises, LLC. ("ARRIS"). ARRIS reserves the right to revise this publication and to make changes in content from time to time without obligation on the part of ARRIS to provide notification of such revision or change.

ARRIS and the ARRIS logo are all trademarks of ARRIS Enterprises, LLC. Other trademarks and trade names may be used in this document to refer to either the entities claiming the marks and the names of their products. ARRIS disclaims proprietary interest in the marks and names of others.

ARRIS provides this guide without warranty of any kind, implied or expressed, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. ARRIS may make improvements or changes in the product(s) described in this manual at any time.

The capabilities, system requirements and/or compatibility with third-party products described herein are subject to change without notice.

Software License, Safety, and Regulatory Information

IMPORTANT: PLEASE READ THIS SOFTWARE LICENSE ("LICENSE") CAREFULLY BEFORE YOU USE ANY SOFTWARE, FIRMWARE AND RELATED DOCUMENTATION ("SOFTWARE"). BY USING ANY OF THE SOFTWARE, YOU INDICATE YOUR ACCEPTANCE OF EACH OF THE TERMS OF THIS LICENSE. UPON ACCEPTANCE, THIS LICENSE WILL BE A LEGALLY BINDING AGREEMENT BETWEEN YOU AND ARRIS. THE TERMS OF THIS LICENSE APPLY TO YOU AND TO ANY SUBSEQUENT USER OF THIS SOFTWARE.

IF YOU DO NOT AGREE TO ALL OF THE TERMS OF THIS LICENSE (I) DO NOT USE THE SOFTWARE AND (II) RETURN THE SOFTWARE (COLLECTIVELY, "PRODUCT"), INCLUDING ALL COMPONENTS, DOCUMENTATION AND ANY OTHER MATERIALS PROVIDED WITH THE PRODUCT, TO YOUR POINT OF PURCHASE OR SERVICE PROVIDER, AS THE CASE MAY BE, FOR A FULL REFUND.

The Software includes associated media, any printed materials, and any "on line" or electronic documentation. Software provided by third parties may be subject to separate end user license agreements from the manufacturers of such Software. The Software is never sold. ARRIS licenses the Software to the original customer and to any subsequent licensee for personal use only on the terms of this License. ARRIS and its third-party licensors retain the ownership of the Software.

You may:

USE the Software only in connection with the operation of the Product.

TERMINATE this License by destroying the original and all copies of the Software (if applicable) in whatever form.

You may not:

(1) Loan, distribute, rent, lease, give, sublicense or otherwise transfer the Software, in whole or in part. (2) Copy or translate the User Guide included with the Software, other than for personal use. (3) Copy, alter, translate, decompile, disassemble or reverse engineer the Software, including but not limited to,

modifying the Software to make it operate on non-compatible hardware. (4) Remove, alter or cause not to be displayed, any copyright notices or startup message contained in the Software programs or documentation. (5) Export the Software or the Product components in violation of any United States export laws.

The Product is not designed or intended for use in on line control of aircraft, air traffic, aircraft navigation or aircraft communications; or in design, construction, operation or maintenance of any nuclear facility. ARRIS AND ITS THIRD-PARTY LICENSORS DISCLAIM ANY EXPRESS OR IMPLIED WARRANTY OF FITNESS FOR SUCH USES. YOU REPRESENT AND WARRANT THAT YOU SHALL NOT USE THE PRODUCT FOR SUCH PURPOSES.

Title to this Software, including the ownership of all copyrights, mask work rights, patents, trademarks and all other intellectual property rights subsisting in the foregoing, and all adaptations to and modifications of the foregoing shall at all times remain with ARRIS and its third party licensors. ARRIS retains all rights not expressly licensed under this License. The Software, including any images, graphics, photographs, animation, video, audio, music and text incorporated therein is owned by ARRIS or its third party licensors and is protected by United States copyright laws and international treaty provisions. Except as otherwise expressly provided in this License, the copying, reproduction, distribution or preparation of derivative works of the Software, any portion of the Product or the documentation is strictly prohibited by such laws and treaty provisions. Nothing in this License constitutes a waiver of ARRIS' rights under United States copyright law.

This License and your rights regarding any matter it addresses are governed by the laws of the Commonwealth of Pennsylvania, without reference to conflict of laws principles. THIS LICENSE SHALL TERMINATE AUTOMATICALLY if you fail to comply with the terms of this License.

ARRIS is not responsible for any third party software that is provided as a bundled application, or otherwise, with the Software or that is downloaded to, or otherwise installed on, the Product.

U.S. GOVERNMENT RESTRICTED RIGHTS

The Product and documentation is provided with RESTRICTED RIGHTS. The use, duplication or disclosure by the Government is subject to restrictions as set forth in subdivision (c)(1)(ii) of The Rights in Technical Data and Computer Software clause at 52.227 7013. The contractor/manufacturer is ARRIS Enterprises, Inc. 101 Tournament Drive, Horsham, PA 19044.

Open Source Software Information

For instructions on how to obtain a copy of any source code being made publicly available by ARRIS

related to software used in this set-top box you may send your request in writing to:

ARRIS Enterprises, LLC OSS Management 2450 Walsh Avenue Santa Clara, CA 95051 USA

ARRIS has created the opensource.ARRIS.com to serve as a portal for interaction with the software community-at-large. The location opensource.arrisi.com contains information regarding ARRIS's use of open source on the SLK project. To view additional information regarding licenses, acknowledgements and required copyright notices for open source packages used in this ARRIS software application, please navigate to the Open Source Notices section in the user interface.

Contents

About This GuideinPurposeiAudienceiSupported DevicesiRelated DocumentsiGetting Helpi	ix ix ix
Chapter 1 Overview	1 1 2
Chapter 2 Getting StartedIn This ChapterOverview.Registering for a New SLK User AccountActivating an Existing ARRIS User Account.Requesting Access to SLKLogging in to Your SLK User AccountResetting a Forgotten Password1Retrieving a Forgotten User Name1Accessing SLK Help2Accessing the SLK User Guide2Logging Off SLK.	3348145912
Chapter 3 Managing Site Access2In This Chapter2Overview.2Requesting Site Access2Removing Site Access2	5 5 5
Chapter 4 Managing Inventory3In This Chapter3Overview.3Requesting Email Notification of Inventory Changes3Searching SLK3	1 1 1

Viewing Related Hardware Serial Numbers	
Viewing Sales and Purchase Orders	
Viewing License Pools	
Comparing Software Inventory	
Viewing Licensed Hardware	
Viewing License Mobility Product Pools	
Generating Reports	
	47
Chapter 5 Generating Permanent Licenses	
In This Chapter	
Overview.	
Accessing the License Key Generation Wizard	
Using the Generate Keys Option	
Using the License Key Sets Option	
Generating Permanent Licenses for DM 6400 Devices	
Generating Permanent Licenses for Software Version less than 5.6	
Generating Permanent Licenses for Software Version 5.6 or Greater	
Generating Permanent Licenses for CAP-1000 Devices	63
Generating Permanent Licenses for Software Version Less Than 4.0	
Generating Permanent Licenses for Software Version 4.0 or Greater	
Generating Permanent Licenses for SE-6000 Series and ST-6000 Series Devices	73
Generating Permanent Licenses for NE2500 Devices	
Regenerating Permanent Licenses	83
Regenerating Permanent Licenses for DM 6400 Devices	
Regenerating Permanent Licenses for CAP-1000 Devices	
	86
Chapter 6 Using License Mobility with One-time Move Licenses	89
Chapter 6 Using License Mobility with One-time Move Licenses In This Chapter	
Chapter 6 Using License Mobility with One-time Move Licenses In This Chapter	
Chapter 6 Using License Mobility with One-time Move Licenses In This Chapter	
Chapter 6 Using License Mobility with One-time Move Licenses In This Chapter	
Chapter 6 Using License Mobility with One-time Move Licenses In This Chapter	
Chapter 6 Using License Mobility with One-time Move Licenses In This Chapter	
Chapter 6 Using License Mobility with One-time Move Licenses In This Chapter . Overview. Requirements . Constraints Using License Mobility on DM 6400 Devices. Verifying License Availability Revoking All Licenses .	
Chapter 6 Using License Mobility with One-time Move Licenses In This Chapter . Overview. Requirements Constraints Using License Mobility on DM 6400 Devices Verifying License Availability Revoking All Licenses Managing Acknowledgement Codes	
Chapter 6 Using License Mobility with One-time Move Licenses In This Chapter	
Chapter 6 Using License Mobility with One-time Move Licenses In This Chapter	
Chapter 6 Using License Mobility with One-time Move Licenses In This Chapter	
Chapter 6 Using License Mobility with One-time Move Licenses In This Chapter	
Chapter 6 Using License Mobility with One-time Move Licenses In This Chapter Overview. Requirements Constraints Using License Mobility on DM 6400 Devices Verifying License Availability Revoking All Licenses Managing Acknowledgement Codes Using License Mobility on CAP-1000 Devices Verifying License Availability Revoking All Licenses Managing Acknowledgement Codes	
Chapter 6 Using License Mobility with One-time Move Licenses In This Chapter Overview. Requirements Constraints Using License Mobility on DM 6400 Devices. Verifying License Availability Revoking All Licenses Managing Acknowledgement Codes Using License Mobility on CAP-1000 Devices Verifying License Availability Revoking All Licenses Managing Acknowledgement Codes Chapter 7 Using License Mobility with an SLA	
Chapter 6 Using License Mobility with One-time Move Licenses In This Chapter Overview. Requirements Constraints Using License Mobility on DM 6400 Devices Verifying License Availability Revoking All Licenses Managing Acknowledgement Codes Using License Mobility on CAP-1000 Devices Verifying License Availability Revoking All Licenses Managing Acknowledgement Codes	
Chapter 6 Using License Mobility with One-time Move Licenses In This Chapter Overview. Requirements Constraints Using License Mobility on DM 6400 Devices. Verifying License Availability Revoking All Licenses Managing Acknowledgement Codes Using License Mobility on CAP-1000 Devices Verifying License Availability Revoking All Licenses Managing Acknowledgement Codes Chapter 7 Using License Mobility with an SLA . In This Chapter Overview. Requirements	
Chapter 6 Using License Mobility with One-time Move Licenses In This Chapter Overview. Requirements Constraints Using License Mobility on DM 6400 Devices. Verifying License Availability Revoking All Licenses Managing Acknowledgement Codes Using License Mobility on CAP-1000 Devices Verifying License Availability Revoking All Licenses Managing Acknowledgement Codes Verifying License Availability Revoking All Licenses Managing Acknowledgement Codes Managing Acknowledgement Codes Managing Acknowledgement Codes Managing Acknowledgement Codes Managing Acknowledgement Codes	
Chapter 6 Using License Mobility with One-time Move Licenses In This Chapter . Overview. Requirements . Constraints . Using License Mobility on DM 6400 Devices . Verifying License Availability . Revoking All Licenses . Managing Acknowledgement Codes . Using License Mobility on CAP-1000 Devices . Verifying License Availability . Revoking All Licenses . Managing Acknowledgement Codes . Chapter 7 Using License Mobility with an SLA. In This Chapter . Overview. Requirements . Constraints . Using License Mobility on DM 6400 Devices .	
Chapter 6 Using License Mobility with One-time Move Licenses In This Chapter . Overview. Requirements Constraints Using License Mobility on DM 6400 Devices. Verifying License Availability Revoking All Licenses Managing Acknowledgement Codes Using License Mobility on CAP-1000 Devices Verifying License Availability Revoking All Licenses Managing Acknowledgement Codes Chapter 7 Using License Mobility with an SLA. In This Chapter Overview. Requirements Constraints Using License Mobility on DM 6400 Devices. Verifying License Mobility on DM 6400 Devices. Verifying License Availability.	
Chapter 6 Using License Mobility with One-time Move Licenses In This Chapter . Overview. Requirements . Constraints . Using License Mobility on DM 6400 Devices . Verifying License Availability . Revoking All Licenses . Managing Acknowledgement Codes . Using License Mobility on CAP-1000 Devices . Verifying License Availability . Revoking All Licenses . Managing Acknowledgement Codes . Chapter 7 Using License Mobility with an SLA. In This Chapter . Overview. Requirements . Constraints . Using License Mobility on DM 6400 Devices .	

Using License Mobility on CAP-1000 Devices Verifying License Availability Revoking Licenses Managing Acknowledgement Codes	
Chapter 8 Transferring Inventory	135
In This Chapter	
Overview	
Transferring Serial Numbers	
Transferring Software Licenses	137
Chapter 9 Decoding Licenses and Acknowledgement Codes	141
In This Chapter	
Overview	141
Decoding License Keys	141
Decoding Acknowledgement Codes	143

About This Guide

Purpose

The SLK User Guide v5.0 explains how to use the ARRIS Software License Key application.

Audience

This guide is intended for users of SLK who manage product serial numbers and software licenses.

Supported Devices

Information in this guide applies to the following devices:

- CAP-1000 and CAP-1010 CherryPicker Application Platform
- DM 6400 Digital Media Platform
- NE2500 Network Encryptor
- SE-6000 Series MPEG-4 AVC Encoder
- ST-6000 Series Multi-channel Video Transcoder

Related Documents

The following documents provide additional information on SLK:

- CAP-1000 Software Guide
- DM 6400 Software Guide
- NE2500 User Guide
- SE-6000 Series MPEG-4 AVC Encoders User Guide
- ST-6000 Series Multi-channel Video Transcoder Guide

Getting Help

Help with your product is available online and by phone.

Find technical documentation in the **CustomerCare 360 Documentation Center** (http://www.arrisi.com/cc360).

Get release updates and download software from **DigitalCM** (digitalcm.arrisi.com).

The **ARRIS Training Learning Portal** provides self-paced product training and course descriptions of instructor-led training classes at http://www.arris.com/support/training. In many cases training can be given at your location.

The **Technical Assistance Center** (TAC) provides assistance 24 hours a day, 7 days a week. To open a case, use one of these contact methods:

- Customers in North American should call the TAC at 888-944-HELP (888-944-4357).
- Customers outside North America should call the TAC at IDD (International Direct Dialing Number) + 1 + 215-323-2345.
- For Spanish language support, call 215-323-2346. Contact the TAC by e-mail at Tac.Helpdesk@arrisi.com.

Chapter 1 Overview

In This Chapter

- SLK
- Functions
- Requirements
- Training

SLK

SLK is a web-based, self-service tool for customers and business partners. Depending on approved roles, SLK lets you verify product and sales information, manage serial numbers, access software license inventory pools, generate product licenses for purchased inventory, use the license mobility feature, and perform other functions.

Functions

SLK provides the following functions:

- Generate permanent product licenses
- Manage hardware and software serial numbers
- Manage licensed hardware, licensed files or keys, and license inventory pools
- Query previously-generated software licenses, sales orders, and purchase orders
- Generate product inventory reports
- Transfer licensed hardware or license inventory
- Use the license mobility feature to revoke licenses to a pool and redeploy to other devices of the same model

- Create and edit your user profile
- Click a link to reset a forgotten password or user name
- Download SLK documentation
- Access comprehensive online help

Requirements

To use SLK, the following requirements apply:

- Internet connection with access to a web browser
- SLK user account

Training

The ARRIS Training Learning Portal provides self-paced product training and course descriptions of instructor-led training classes at http://www.arris.com/support/training. Alternatively, please contact slkadmin@arris.com for more information on SLK training opportunities.

Chapter 2 Getting Started

In This Chapter

- Overview
- Registering for a New SLK User Account
- Activating an Existing ARRIS User Account
- Requesting Access to SLK
- Logging in to Your SLK User Account
- Resetting a Forgotten Password
- Retrieving a Forgotten User Name
- Accessing SLK Help
- Accessing the SLK User Guide
- Logging Off SLK

Overview

SLK uses the ARRIS Single Sign-on (SSO) service for session control and user authentication. This section explains how to register for a new ARRIS SSO account. If you are new to SLK, you need to register for a new account and request access to SLK. Go to **"Registering for a New SLK User Account" on page 4** for information.

If you already have an ARRIS user account and need to migrate it to ARRIS SSO, go to "Activating an Existing ARRIS User Account" on page 8 for more information.

Note: SLK accepts users from approved MSO and Telco corporate accounts. A corporate email address is required for account approval. SLK accepts one corporate user name per email address. Multiple accounts referencing the same email address are not permitted.

Registering for a New SLK User Account

To register:

1. Log in to SLK:

https://slk.arris.com

The SLK Application Login page opens.

2. In the left side of the page, click **Register**.

NEW FEATURES! HELP LO		SLK		
Software Li	CENSE KEY GENER	ator & Serial Number R	POSITORY	ARRIS
ALREADY AN EXISTING USER, BUT FORGOT YOUR FASSWORD? Request a password RESE We have migrated to the J On service, if you haven't activate your existing acc NEW USER STEP : REGISTER if a AR On account them STEP 2: REQUEST access i NEED MORE INFORMATION? DOWNLOAD this User Guid Guide.	T. ARRIS Single Sign already you must ount. ACTIVATE RIS Single Sign to SLK.	Login We have mi		SINGLE SIGN-ON USER ID.) ervice, if you haven't already you must activate your existing . ACTIVATE
Conto 888-94		ical Assistance Center at A: 215-323-2345, Latin	© ARRIS 2017. All RIGHTS RESERVED.	PLEASE NOTE: THIS SITE USES JAVASCRIPT. Your browser must be configured to run JavaScript in order to have full functionality.

SLK Application Login

The ARRIS Single Sign On New User Registration page opens.

	A	RRIS	New User Registra		📸 🍱 English Help
PRODUCTS	SERVICES	SOLUTIONS	SUPPORT	INVESTORS	CONSUMERS
		To register a new account, ple	ase complete the following for	m.	
	First nam	ie*			
		- •			
	Last nam	e*			
	Street*				
	Suite				
	City*				
	State				
			•		
	Zip Code	/Postal Code			
	Countrat				
	Country*		×		
	Preferre	d Language			
			•		
	Telephor	ne Number*			
	Mobile N	umber			
	Fax Num	ber			
	Company	/Organization Name*			
	Title*				
	Email Ad	dress*			
	Usernam	e*			
	Confirm	Username*			
	New Passv				
	 Must b 	ord is case sensitive. e at least 8 characters long. assword may not have been used	d previously.		
	Continue	Cancel			

ARRIS Single Sign On New User Registration

3. Complete the personal information in the form.

Fields with asterisks are required.

Note: The password is case-sensitive, must be at least eight characters in length, and may not have been previously used.

4. Click Continue.

The Code Verification page opens.


		ARRIS	New User Registr	ration	🕋 📕 English Help
PRODUCTS	SERVICES	SOLUTIONS	SUPPORT	INVESTORS	CONSUMERS
	To verify your identity, Code		you. Please click the link in th code here.	e email or copy and paste the	

Code Verification

To verify your identify, a security code is sent to your email account.

- 5. Log in to your email account.
- 6. Open the email, **ARRIS New User Verification**.


If successful, an email similar to the following example displays:



ARRIS New User Registration Email

- 7. Review the instructions. Two options are available:
 - To continue registration using the link, go to **step 8**.
 - To continue registration if the link doesn't work, go to step 11.
- 8. To continue with your account registration, select the **click here** link.

The Please Wait page opens.



Please Wait

After the account is successfully configured, the Success page opens.

🦯 📈 A R R I S	Success
Your new user account has	s been successfully created.
Continue	

Success

9. Click **Continue**.

The Main Menu page opens.

	A F	RRIS	Main Menu		*	🕈 📑 English Help
PRODUCTS	SERVICES	SOLUTIONS	SUPPORT	INVESTORS		CONSUMERS
	Change Password		Change your	current password.		
	My Access		Manage	e My Access		
	Logout		L	ogout		

Main Menu

- 10. Go to the section, "Requesting Access to SLK" on page 11, to continue.
- 11. If the link doesn't work, do the following:
 - a. In the email, copy the verification code.
 - b. Return to the Code Verification page.
 - c. Paste the code in the **Code** field.
 - d. Click Check Code.

If the code verification is successful, the message, "Your new user account has been successfully created," displays.

e. Click Continue.

The Main Menu page opens.

f. Go to the section, "Requesting Access to SLK" on page 11, to continue.

Activating an Existing ARRIS User Account

SLK uses the ARRIS SSO service for session control and user authentication. If you have an existing ARRIS user account that needs to be reactivated, you can activate your pre-configured account and set a new password.

To activate:

1. Log in to SLK:

https://slk.arris.com

The SLK Application Login page opens.

- 2. Enter your User Name and Password.
- 3. Click Login.

4. In the right side of the page, click **Activate**.

New Features! HELP LOGIN Software License Key Gene	SLK ATOR & SERIAL NUMBER REPOSITORY
ALREADY AN EXSTING USER, BUT FORGOT YOUR PASSWORD? Request a password RESET. We have migrated to the ARRIS Single Sign On service, if you haven't already you must activate your existing account. ACTIVATE New USER? STEP 1: REGISTER for a ARRIS Single Sign On account then STEP 2: REQUEST access to SLK. NEED MORE INFORMATION? DOWNLOAD this User Guide: SLK Access Guide.	User Name: (PLEASE ENTER YOUR ARRIS SINGLE SIGN-ON USER ID.) Password: Login We have migrated to the ARRIS Single Sign On service, it you haven't already you must activate your existing accourt. Activate
NEED ASSISTANCE? Contact the ARRIS Tech 888-944-HELP(4357), EM America: 215-323-2346.	ical Assistance Center at A: 215-323-2345, Latin © ARRIS 2017. ALL RIGHTS RESERVED. PLEASE NOTE: THIS SITE USES JAVASCRIPT. Your browser must be configured to run JavaScript in order to have full functionality.

SLK Application Login

You are redirected to the following URL:

https://membership.arrisi.com/private/Login

The Please Log In page opens.

		RRIS	Please Log In		🕋 🎫 English Help
PRODUCTS	SERVICES	SOLUTIONS	SUPPORT	INVESTORS	CONSUMERS
	Username Current Pass Login Forgotten Password Forgotten Username Activate Account	Cancel Regain acce	ss to your account if you have Find your forgotten use	ername.	
	New User Registration	Activate a	pre-configured account and e		

Please Log In

5. Enter your User Name and Current Password.

6. Click Activate Account.

The Activate Account page opens.

		RRIS	Activate Account		🕋 🗏 English Help
PRODUCTS	SERVICES	SOLUTIONS	SUPPORT	INVESTORS	CONSUMERS
	Be su Userna	re to complete the process, or y me* ddress*	er account.		


Activate Account

- 7. Enter your User Name and Email Address.
- 8. Click Activate.

To verify your identify, an email is sent to your email account.

- 9. Log in to your email account.
- 10. Open the email, SLK 5.0.x User ID.

If successful, an email similar to the following example displays:



SLK 5.0.x User ID Email

11. Go to the section, "Requesting Access to SLK" on page 11, to continue.

Requesting Access to SLK

This section explains how to request access to SLK with the user name and password assigned to you during the ARRIS Single Sign On (SSO) registration process.

To request access:

1. Log in to SLK:

https://slk.arris.com

The SLK Application Login page opens.

2. In the left side of the page, click **Request**.

New Features! HELP LOGIN	SLK rator & Serial Number R	EPOSITORY	ARRIS
ALREADY AN EXISTING USER, BUT FORGOT YOUR PASSWORD? Request a password RESET. We have migrated to the ARRIS Single Sign On service, if you haven't already you must activate your existing account. ACTIVATE NEW USER? STEP 1: REGISTER for a ARRIS Single Sign On account them STEP 2: REQUEST or cess to SLK. NEED MORE INFORMATION? DOWNLOAD this User Guide: SLK Access Guide.	Login We have m	Password:	SINGLE SIGN-ON USER ID.) ervice, if you haven't already you must activate your existing . ACTIVATE
NEED ASSISTANCE? Contact the ARRIS Tech 888-944-HELP(4357), EM America: 215-323-2346.	nical Assistance Center at EA: 215-323-2345, Latin	© ARRIS 2017. All RIGHTS RESERVED.	PLEASE NOTE: THIS SITE USES JAVASCRIPT. Your browser must be configured to run JavaScript in order to have full functionality.

SLK Application Login

The SLK User Access Request page opens.

NEW FEATURES! HELP LOGIN	(
SOFTWARE LICENSE KEY GENERATOR & SERIAL NUMBER REPOSITORY		A	RRIS
	SLK USER ACCESS R	EQUEST	
PLEASE ENTER YOUR USER NAME AND PASSWORD. TO	Name:		
VALIDATE YOUR ARRIS SSO ACCOUNT.	Title:		
User Name:	Company:		
(PLEASE ENTER YOUR SINGLE SIGN-ON USER ID.)	Email Address:		
	Address:		
Password:	Address:		
Login	City:		
	State/Province:		
	Postal Code:		
	Country:		
	Office Phone:		
	FAX:		
	Mobile Phone:		
	To Edit Profile CLICK HERE		
	If this is your correct ARRIS S	O account information please click here to	SUBMIT YOUR SLK ACCESS REQUEST

SLK User Access Request

- 3. In the left side of the page, enter your **User Name** and **Password**.
- 4. Click Login.

Your personal information displays in the table.

	SLK USER A	CCESS REQUEST	
PLEASE ENTER YOUR USER NAME AND PASSWORD, TO VALIDATE	Name:	jane	
YOUR ARRIS SSO ACCOUNT.	Title:	Operator	
User Name:	Company:	ARRIS	
(Please enter your Single Sign-On User ID.)	Email Address:	jane@gmail.com	
	Address:	2450 Walsh A∨e	
Password:	Address:	2450 Walsh A∨e	
Login	City:	\$anta Clara	
	State/Province:	CA	
	Postal Code:	95051	
	Country:	USA	
	Office Phone:	(408) 235-5500	
	FAX:		
	Mobile Phone:	(408) 235-5500	
	To Edit Profile CUCK HERE		
	If this is your correct A	ARRIS SSO account information please click here to ACCESS REQUEST	

SLK User Access Request

5. Review the information in the table and ensure that it is correct.

If any of the information is incorrect, edit your user profile. Select the **To Edit Profile Click Here** link and make any necessary changes.

6. Click Submit Your SLK Access Request.

	SLK User Acces	is Request	
LEASE ENTER YOUR USER NAME AND PASSWORD, TO VAUDATE	Name:	jane	
YOUR ARRIS SSO ACCOUNT.	Title:	Operator	
User Name:	Company:	ARRIS	
(Please enter your Single Sign-On User ID.)	Email Address:	jane@gmail.com	
Password:	Address:	2450 Walsh A∨e	
Passwora:	Address:	2450 Walsh A∨e	
Login	City:	Santa Clara	
	State/Province:	CA	
	Postal Code:	95051	
	Country:	USA	
	Office Phone:	(408) 235-5500	
	FAX:		
	Mobile Phone:	(408) 235-5500	
	To Edit Profile CUCK HERE		
	If this is your correct ARRIS	SSO account information please click here to	SUBMIT YOUR SLK Access Request

SLK User Access Request

The following message displays at the top of the page:

"The request is currently being processed. When your account request has been approved an email with your user name will be sent to the email address given."

- 7. Log in to your email account.
- 8. Open the email, SLK 5.0.x User ID.

If successful, an email similar to the following example displays:

SL	K 5.0.x User ID Inbox x
-	SLK@arris.com to me
	Hello,
	Your request for Software License Key Generator access (user id: jane) has been approved. When you've login into SLK please review your profile to update your notification settings and request additional access permissions.
	SLK Application Support https://slk.arris.com/slk

SLK 5.0.x User ID Email

9. Review the information in the email.

You now have access to SLK.

Logging in to Your SLK User Account

To log in to SLK, you must have a pre-approved user account.

To log in:

1. In your web browser, enter the following URL:

https://slk.arris.com

The SLK Application Login page opens.


2. Enter your ARRIS SSO **User Name** and **Password**.

New Features! HELP LOGIN Software License Key Gener	SLK RATOR & SERIAL NUMBER RI	EPOSITORY	ARRIS
AREADY AN EXISTING USER, BUT FORGOT YOUR PASSWORD? Request a password RESET. We have migrated to the ARRIS Single Sign On service, if you haven't diready you must activate your existing account. ACTIVATE New User? STEP 1: REGISTER for a ARRIS Single Sign On account then STEP 2: REQUEST access to SLK. NEED MORE INFORMATION? DOWNLOAD this User Guide: SLK Access Guide.	Login We have mi		SINGLE SIGN-ON USER ID.) ervice, if you haven't already you must activate your existing . ACTIVATE
NEED ASSISTANCE? Contact the ARRIS Techr 888-944-HELP (4357), EMI America: 215-323-2346.	nical Assistance Center at EA: 215-323-2345, Latin	© ARRIS 2017. ALL RIGHTS RESERVED.	PLEASE NOTE: THIS SITE USES JAVASCRIPT. Your browser must be configured to run JavaScript in order to have full functionality.

SLK Application Login

3. Click Login.

Your SLK Account Home page opens and your user name displays in the upper-left corner. The menu options that appear may differ from the displayed image, depending upon your approved user role and permissions.



SLK Account Home

Resetting a Forgotten Password

To reset:

1. Log in to SLK:

https://slk.arris.com

The SLK Application Login page opens.

2. In the left side of the page, click **Reset**.

NEW FEATURES! HELP LOGIN	SLK		
Software License Key Gener	rator & Serial Number R	POSITORY	ARRIS
AIREADY AN EXSTING USER, BUT FORGOT YOUR PASSWORD? Request a password RESET. We have migrated to the ARRIS Single Sign On service, if you haven't already you must activate your existing account. ACTIVATE New USER? STEP 1: REGISTER for a ARRIS Single Sign On account then STEP 2: REQUEST access to SLK. NEED MORE INFORMATION? DOWNLOAD this User Guide: SLK Access Guide.	Login We have mi	User Name: (PLEASE ENTER YOUR ARRIS Password: grated to the ARRIS Single Sign On so account.	ervice, if you haven't already you must activate your existing
NEED ASSISTANCE? Contact the ARRIS Tech 888-944-HELP(4357), EMI America: 215-323-2346.	nical Assistance Center at EA: 215-323-2345, Latin	© ARRIS 2017. All Rights Reserved.	PLEASE NOTE: THIS SITE USES JAVASCRIPT. Your browser must be configured to run JavaScript in order to have full functionality.

SLK Application Login

The Forgotten Password page opens.

	\nearrow	ARRIS	Forgotten Passw	vord	삼 🗏 English Help
PRODUCTS	SERVICES	SOLUTIONS	SUPPORT	INVESTORS	CONSUMERS
			follow the prompts to reset yo	ur password.	

Forgotten Password

- 3. Enter your **Email Address** and **User Name**.
- 4. Click Search.

If the search is successful, the Code Verification page opens.

	 A	RRIS	Forgotten Password	d	👫 🎫 English Help
PRODUCTS	SERVICES	SOLUTIONS	SUPPORT	INVESTORS	CONSUMERS
	To verify your identity, a t		you. Plesse click the link in the er code here.	nail or copy and paste th	e

Code Verification

To verify your identify, a security code is sent to your email account.

- 5. Log in to your email account.
- 6. Open the email, ARRIS Forgotten Password Verification.


If successful, an email similar to the following example displays:

ARRIS Forgotten Password	Inbox x
Dear user,	
We received a request to change you user name jane.	ur password for your ARRIS account with
To continue with your password reset	, please <u>click here</u> .
If fof some reason this link doesn't wo code on the password reset form:	ork, you can copy and past the following
123AbC	
The code will be active for one hour. I password at this time, you do not nee	
Thank you, ARRIS Membership	

ARRIS Forgotten Password Email

- 7. Review the information in the email.
- 8. To continue with your password reset, select **click here**.


Your password reset request is sent to ARRIS. If the password reset is successful, the Success page opens.



Success

9. Open the email, **ARRIS Password Verification**.

If successful, an email similar to the following example displays:



ARRIS Password Notifier Email

10. Review the information in the email.

The new password is included in the email.

11. Record your password for future use.

Use this password to log in to SLK.

12. In the Success page, click **Continue** or close the page.

Retrieving a Forgotten User Name


To retrieve:

1. Access the ARRIS Support site:

http://www.arrisi.com/support

The ARRIS Support page opens.

Scroll the page and click **Create/Update Membership**.



Create/Update Membership

You are redirected to the following URL:

https://membership.arrisi.com/private/Login

The Please Log In page opens.

		RIS	Please Log In		🕋 🗏 English Help
PRODUCTS	SERVICES	SOLUTIONS	SUPPORT	INVESTORS	CONSUMERS
	Username Current Passu Login Forgotten Password	Cancel	ess to your account if you have	s forgotten your password.	
	Forgotten Username		Find your forgotten use	ername.	
	Activate Account	Activate a	pre-configured account and e	stablish a new password.	
	New User Registration		Create a new user ac	count.	

Please Log In

2. Click Forgotten User Name.

The Forgotten User Name page opens.

		RRIS	Forgotten Userna	ame	📸 📕 English Help
PRODUCTS	SERVICES	SOLUTIONS	SUPPORT	INVESTORS	CONSUMERS
			nation will be used to lookup y	our forgotten username.	

Forgotten User Name

- 3. Enter your **Email Address** and **Last Name**.
- 4. Click Search.

If the search is successful, the Success page opens and your use name displays.



Success

- 5. Record your user name for future use.
- 6. Click **Continue** to remain in SLK or close the page.

Accessing SLK Help

SLK provides several types of help to assist you as you go through SLK processes and procedures.

To access:

1. Log in to SLK:

https://slk.arris.com

2. Click **Help** in the upper-left page.

New Features! HELP LOGIN	SLK rator & Serial Number Repository	ARRIS
ALREADY AN EXISTING USER, BUT FORGOT YOUR PASSWORD? Request a password RESET. We have migrated to the ARRIS Single Sign On service, if you haven't already you must activate your existing account. ACTIVATE New User? STEP 1: REGISTER for a ARRIS Single Sign On account then STEP 2: REQUEST access to SLK. NEED MORE INFORMATION? DOWNLOAD this User Guide: SLK Access Guide.		SINGLE SIGN-ON USER ID.)
NEED ASSISTANCE? Contact the ARRIS Tech 888-944-HELP(4357), EM America: 215-323-2346.	nical Assistance Center at EA: 215-323-2345, Latin	PLEASE NOTE: THIS SITE USES JAVASCRIPT. Your browser must be configured to run JavaScript in order to have full functionality.

SLK Application Login

The Help page opens.

3. To access the Technical Assistance Center (TAC), see **"Getting Help" on page x** for more information.

Accessing the SLK User Guide

To access:

1. Log in to SLK:

https://slk.arris.com

2. Click **Download** in the lower-left section of the page.

New Features! HELP LOGIN Software License Key Genei	SLK rator & Serial Number R	EPOSITORY	ARRIS
ALREADY AN EXSTING USER, BUT FORCOT YOUR PASSWORD? Request a password RESET. We have migrated to the ARRIS Single Sign On service, if you haven't already you must activate your existing account. ACTIVATE NEW USER? STEEP 1: REGISTER for a ARRIS Single Sign On account then STEP 2: REQUEST access to SLK. NEED MORE INTERMANDON? DOWNLOAD to is User Guide: SLK Access Orde.	Login We have m	User Name: (PLEASE ENTER YOUR ARRIS Password: igrated to the ARRIS Single Sign On se account	ervice, if you haven't already you must activate your existing
NEED ASSISTANCE? Contact the ARRIS Tech 888-944-HELP(4357), EM America: 215-323-2346.	nical Assistance Center at EA: 215-323-2345, Latin	© ARRIS 2017. All RIGHTS RESERVED.	PLEASE NOTE: THIS SITE USES JAVASCRIPT. Your browser must be configured to run JavaScript in order to have full functionality.

SLK Application Login

The User Guide downloads to a location of your choice.

Logging Off SLK

To log off:

- 1. Do one of the following:
 - Click **Logout** in the upper-left corner.
 - Close the SLK web browser page.

ew Features! HELP LOGOUT SLK Software License Key Generator & Serial N	IMARER PEROSITORY	•	RF
ello jane Home Orders	Inventory	Generate Keys	Tools
\ /			
		Serial Number	Days till Expiration
		616291400001	29
		616291400006	29
- V		616381400028	29
		C937526300500913L304	21
	Concession of the local division of the loca	098CTW75Se702SC10464	20
and the second		616201200051	20
Construction of the Constr		616231200014	20
	-	616301100015	19
Children -		616490800015	18
		616231200006	18
		616231200023	18
		616231200044	18
		616261200023	18
		616261200005	18
2	and the second	616281200053	18
		616281200066	18
		1 2 3 4 5 > Last » Page	• 1 of 77 (1539 items)

Logout

The SLK session ends.

Chapter 3 Managing Site Access

In This Chapter

- Overview
- Requesting Site Access
- Removing Site Access

Overview

In SLK, a site refers to a company and its locations. To manage SLK license features and functions, you need approved access to the specific sites within SLK for your company. You can manage site access from your User Profile.

Requesting Site Access

To request:

1. Log in to SLK:

https://slk.arris.com

2. From the menu bar, click **Profile > My Profile**.

Your User Profile opens.

NEW FEATURES!	HELP LOGOUT	SLK				тм			
\$	Software License Ke	ey Generator & Serial N	NUMBER REPOSITORY		ARF	2 1 5			
Hello jane	Home	Orders	Inventory	Generate Keys	Tools	Profile			
User Profile									
				ARRIS ME	MBERSHIP ACCOUNT DATA				
	ACCESS REQUEST			Name:	jane				
	Please select the re	equired companies and sit	ed companies and sites.		tester				
	-				jane@gmail.com				
	Select Company:	ARRIS TEST ADD COMP	RRIS TEST V ADD COMPANY		2450 walsh				
	If the company na	name you were looking for did not appear in the drop down		Address:	2450 walsh				
	box SEND a request to have it added.			City:	santa clara				
			State/Province:	CA					
		REQUESTED COMPA	ANITE:	Postal Code:	95051				
		REQUESTED COMPA	ANIES.	Country:	USA				
				Office Phone:	408222-2222				
	Select Site: ARRIS T	EST 1 - ADD SITE		FAX:					
				Mobile Phone:	408222-2222				
					jane				
	ARRIS TEST	REQUESTED SITE ARRIS TEST 1	APPROVED	SLK Email Address:	jane@gmail.com				
	AKKISTEST	AKKIG IEGI I	ATTROVED	C	HANGE PASSWORD				
		Update		licenses in	cations for availability of inventory pool: button on the left to save the setting.)				

User Profile

3. In the **Select Company** menu, choose your company.

Note: If your company is not listed, click **Send** and email a request to add the company.

- 4. In the **Select Site** menu, choose the site you want.
- 5. Click Add Site.

NEW FEATURES!	HELP LOGOUT	SLK			
	Software License Key G	enerator & Serial N	NUMBER REPOSITORY		A R R I S
Hello jane	Home	Orders	Inventory	Generate Keys	Tools Profile
			User Profile		
	Access Request				BERSHIP ACCOUNT DATA
	Please select the require	d companies and site		Name:	jane
	Fiedse select the require	a companies and site	es.	Title: LDAP Email	tester jane@gmail.com
				Address:	Janosginaileon
	Select Company: ARRIS	TEST ADD COMPAN	NY	Address:	2450 walsh
	If the company name v	ou were looking for di	d not appear in the drop down	Address:	2450 walsh
	box SEND a request to ha			City:	santa clara
				State/Province:	CA
		Decurrent Course		Postal Code:	95051
		REQUESTED COMP.	ANIES:	Country:	USA
				Office Phone:	408222-2222
	Select Site: ARRIS TEST 3			FAX:	
	Select one. Arris 1201 0	ADD SILE		Mobile Phone:	408222-2222
				Login Name:	jane
		REQUESTED SIT	ES:	SLK Email Address:	jane@gmail.com
	ARRIS TEST	ARRIS TEST 1	APPROVED	CH/	ANGE PASSWORD
	ARRIS TEST	ARRIS TEST 2	APPROVED		
	ARRIS TEST	ARRIS TEST 3	REMOVE		
				Receive Notificatio	ons for availability of licenses
				in inve	entory pool: 🔲
				(Click the update	button on the left to save the setting.)
		Update			

Add Site Request


6. Click Update.

The site is added to the Requested Sites table and your request is sent to SLK Application Support.

7. Log in to your email account.

8. Open the email, SLK 5.0.x New Company/Site Request.

If successful, an email similar to the following example displays:



SLK 5.0.x New Company/Site Request Email

- 9. Return to your SLK Home page.
- 10. From the menu bar, click **Profile > My Profile**.

Under the **Requested Sites** section, your site request is now **Approved**.

jane		Key Generator & Serial I			A R R
June	Home	e Orders	Inventory	Generate Keys	Tools Profi
			USER PROFILE		
				ARRIS MEMB	ERSHIP ACCOUNT DATA
	ACCESS REQUEST			Name:	jane
	Please select the re	equired companies and sit	es.	Title:	tester
				LDAP Email Address:	jane@gmail.com
	Select Company:	ARRIS TEST ADD COMPA	NY	Address:	2450 walsh
	If the company no	ame vou were lookina for di	d not appear in the drop down	Address:	2450 walsh
		t to have it added.		City:	santa clara
				State/Province:	CA
				Postal Code:	95051
		REQUESTED COMP	ANIES:	Country:	USA
				Office Phone:	408222-2222
	Select Site: ARRIS			FAX:	
	Select sile: AKKIS	ADD SILE		Mobile Phone:	408222-2222
				Login Name:	jane
		REQUESTED SIT	ES:	SLK Email Address:	jane@gmail.com
	ARRIS TEST	ARRIS TEST 1	APPROVED	Сна	NGE PASSWORD
	ARRIS TEST	ARRIS TEST 2	APPROVED		
	ARRIS TEST	ARRIS TEST 3	APPROVED		
				Receive Notificatio	ns for availability of licenses
				in inve	ntory pool:
				(Click the update	button on the left to save the

Add Site Approved

Removing Site Access

Removing site access disables your access to a specific site.

To remove:

1. Log in to SLK:

https://slk.arris.com

2. From the menu bar, click **Profile > My Profile**.

Your User Profile opens.

3. Under **Requested Sites**, locate the site you want and click **Remove**.

NEW FEATURES!	HELP LOGOUT	SLK			
	Software License Ki	EY GENERATOR & SERIAL I	Number Repository		ARR
ello jane	Home	Orders	Inventory	Generate Keys	Tools P
			User Profile		
	ACCESS REQUEST			ARRIS MEA	ABERSHIP ACCOUNT DATA
				Name:	jane
	Please select the red	quired companies and sit	es.	Title:	tester
				LDAP Email Address:	jane@gmail.com
	Select Company: A	ARRIS TEST ADD COMPA	NY	Address:	2450 walsh
	If the company nam	ne vou were looking for di	id not appear in the drop down	Address:	2450 walsh
	box SEND a request			City:	santa clara
				State/Province:	CA
				Postal Code:	95051
		REQUESTED COMP	PANIES:	Country:	USA
				Office Phone:	408222-2222
	Select Site: ARRIS TE			FAX:	
	ARRIST			Mobile Phone:	408222-2222
				Login Name:	jane
		REQUESTED SIT	TES:	SLK Email Address	: jane@gmail.com
	ARRIS TEST	ARRIS TEST 1	APPROVED	Ci	IANGE PASSWORD
	ARRIS TEST	ARRIS TEST 2	APPROVED		
	ARRIS TEST	ARRIS TEST 3	REMOVE		
				Receive Notificat	ions for availability of licenses
					ventory pool:
					e button on the left to save the setting.)
		Update			
		opudie			

Remove Site Request

4. Click Update.

The site is immediately removed from your User Profile.

Chapter 4 Managing Inventory

In This Chapter

- Overview
- Requesting Email Notification of Inventory Changes
- Searching SLK
- Viewing Sales and Purchase Orders
- Viewing License Pools
- Comparing Software Inventory
- Viewing Licensed Hardware
- Viewing License Mobility Product Pools
- Generating Reports

Overview

SLK provides some useful functions for requesting inventory changes, searching, viewing, and managing your purchased licensed inventory.

Requesting Email Notification of Inventory Changes

You can request an email notification whenever inventory changes in SLK. When new or transferred sales order inventories are made available in site locations to which you have access, SLK will send an automated email notification to you.

To request:

1. Log in to SLK:

https://slk.arris.com

2. In the toolbar, click **Profile > My Profile**.Your User Profile opens.

NEW FEATURES!	HELP LOGOUT					
		SLK				тм
	Software License Ke	y Generator & Serial N	Number Repository		ARR	
Hello jane	Home	Orders	Inventory	Generate Keys	Tools Profil	e
			USER PROFILE			
	Access Request			ARRIS ME	MBERSHIP ACCOUNT DATA	
				Name:	jane	
	Please select the re	quired companies and si	tes.	Title:	tester	
				LDAP Email Address:	jane@gmail.com	
	Select Company: /	ARRIS TEST ADD COMP	ANY	Address:	2450 walsh	
	If the company nar	me vou were looking for c	did not appear in the drop dow	n Address:	2450 walsh	
	box SEND a request			City:	santa clara	
				State/Province:	CA	
				Postal Code:	95051	
		REQUESTED COMP	ANIES:	Country:	USA	
				Office Phone:	408222-2222	
	Select Site: ARRIS T	EST 1 - ADD SITE		FAX:		
	Select Sile. AKKIS II	ADD SITE		Mobile Phone:	408222-2222	
				Login Name:	jane	
		REQUESTED SITE		SLK Email Address:	jane@gmail.com	
	ARRIS TEST	ARRIS TEST 1	APPROVED	Ci	HANGE PASSWORD	
				licenses in	ations for availability of inventory pool: 🔲 sulton on the left to save the	
		Update			setting.)	

User Profile

3. Scroll to the bottom of the page and select **Receive Notifications for availability of licenses in inventory pool**.

4. Click Update.

Your changes are saved.

Searching SLK

The Search function in SLK enables you to search for:

- Serial Numbers
- Sales orders
- Purchase orders

To search:

1. Log in to SLK:

https://slk.arris.com

2. From the menu bar, click **Tools > Search**.

The Search Options page opens.

NEW FEATURES!	HELP LOGOUT SLK SOFTWARE LICENSE KEY GENERATOR & SERIAL NUMBER REPOSITORY	ARRIS
Hello jane	Home Orders Inventory	Generate Keys Tools Profile
	Search	Options
	LICENSE KEY SEARCH Enter the serial number and select the appropriate serial number type you would like to search for license information on below. Serial Number:	SALES ORDER/PURCHASE ORDER SEARCH Enter the Sales Order/Purchase Order Number you would like to search for information on below. Number: Search By: Sales Order
	 DFSN - DM products, CAP products UcenseGuard and corresponding External DFSN - CAP products CFSN - Compact Flash - External DFSN, DM products 	Search
	© Chassis - MPEG-4 Encoders, Network Encrypters, DM products, CAP products Search	

Search Options

- 3. To search for a license key, do the following:
 - a. Under License Key Search, enter the Serial Number of your device.
 - b. Select the **Type** you want.
 - c. Click Search.

Search results display on the page. Information for the site displays in tabular format.

			SLK					_		
	SOFTWAI	re License K	(ey Generator & S	erial Nume	ER REPOSITORY		l l	∖ F	2	RI
o jane		Home	Orders	;	Inventory	(Generate Keys	Тоо	ls	Profile
	ARRIS TES	T ARRIS TES	T 2							
	REGENERA		D: 194638, Serial Nun Et	NBER: 616511:	200047		Revoke Related SN			CLONE SN TRANSFER
			Кеу Туре	Qua	Unit	License	License Key	E L		
	Exp	iration Date	e:							
	_		EAS ALERTS	1	Chassis	1	AIRP26IQ23H	P€	1	I
			BISS ENCRYPTI	1	Chassis	1	IEYEGWGFR	P€	1	1
			CHERRYPI REDUNDA	1	Chassis	1	TLCIEPLPD2H	P€	l.	I.
		UPGR	MPEG-4/A HD RATESHAPI	2	Channel	16	CXXIH44PL5	Pŧ	I	I
			MPEG-2 HD RATESHAPI	96	Channel	96	QZNPPC6UQ	P€	I.	T
		UPGR	CALM Act Audio Leveling	100	Service	384	PIDEC4MXITY	Pe	1	T
		UPGR	MPEG-2 AD	178	Channel	384	AFPLVAQ3J2	P€	1	I
	1							Baaa	1 of 1	(9 items)

License Key Search Details

- 4. To search for an order, do the following:
 - a. Under Sales Order/Purchase Order Search, enter the order number.
 - b. In the Search By menu, select Sales Order or Purchase Order.
 - c. Click Search.

Search results display on the page. Information for the site displays in tabular format.

W FEATURES!	HELP LOGO	SLK						
\$	OFTWARE LICE	NSE KEY GENERATOR	& SERIAL NUMBE	er Repository		F	٩R	RΙ
llo jane	Н	ome Or	ders	Inventory	Generate Keys		Tools	Profile
ARRIS TEST A	RRIS TEST 2							
		r 221636 Transfered II End User	Product	Qty Orde r ed	Qty Shipped	Actual Ship Date	HW Serial numb	pers
LINE ITEM DETAIL	s For Sales Orde	End				Ship	HW Serial numb	bers

Sales Order/Purchase Order Search Details

Viewing Related Hardware Serial Numbers

• If you need to view the unlicensed hardware serial number that shipped with a bundle, you can use the Related SN function in SLK.

To view:

1. Log in to SLK:

https://slk.arris.com

2. From the menu bar, click **Tools > Search**.

The Search Options page opens.

NEW FEATURES!								
	SLK						тм	
	SOFTWARE LICENSE KEY GENERATOR & SERIAL NUMBE	R REPOSITORY		Α	R	R		S
Hello jane	Home Orders	Inventory	Generate Keys		Tools	Pro		
		SEARCH OPTIC	NS					
	LICENSE KEY SEARCH		SALES ORDER/P		r Sfarch			
	Enter the serial number and select the appropriate s number type you would like to search for license information on below.	serial	Enter the Sales Order/Purc like to search for information	chase Order N		vould		
	Serial Number:							
	Type: O DFSN - DM products, CAP products		Search By: Sales Order Search	•				
	© LicenseGuard and corresponding External DFSN products	I - CAP						
	🔘 CFSN - Compact Flash - External DFSN, DM prod	lucts						
	Chassis - MPEG-4 Encoders, Network Encrypters, products, CAP products	DM						
	Search							

Search Options

- 3. In the **Serial Number** field, enter the serial number for the DM 6400 device.
- 4. Under **Type**, select the product type.
- 5. Click Search.

A table displays with the search results.

6. Click Related SN.

NEW FEATURES!	HELP												
				SLK	(
	Software License Key Generator & Serial Number Repository								ARRI				
lello jane		Hom	ne	0	rders	Inventory	Genera	te Keys		Tools	Profile		
ARRIS	TEST AF	RIS TEST 2											
			0/1.5m	. Numer	. 100010 - 1100	-1000							
	FOR LICEN		7761, SERU	AL NUMBEI	R: 103912J1103	Q1226		-			CLONE SN		
DOWNL	OAD XM	L DATASET							RELATED SN		TRANSFER		
		Кеу Туре	Quant	Unit	License Key	License Key		Expiration [License Ty	Mode			
Exj	piration	Date:											
	Upg	GigE PORT ACTIVATION	2	Port	4	NXDZW2M4TEVGTCE5	SYU7VXT54MWS		Perpetual	DM	INVENTORY DE		
	Upg	PSIP AGGRE	4	Multi	8	VINVMHA2AGG54JDL	IAJGDMYYK3FS		Perpetual	DM	INVENTORY DE		
		4X ASI MODULE	8	Port	8	XRRB5RGTC524TQZC0	DQMG2ZIZRVL5		Perpetual	DM	INVENTORY DE		
		HD RATESHA	16	Cha	16	4GYEBWV2FPSVOZN7	JBXESTRHSOHM		Perpetual	DM	INVENTORY DE		
Ex	piration	Date: 11/28	8/2013										
	UPG	LICENSE MOBILITY SETUP	1	Chassis	1	LBZQNVMLYGHHARIM	QUPZ23HZ4Y35	11/28/2013	Trial	DM	INVENTORY DE		

Serial Number Details

7.

The Related Serial Numbers page opens.

Relati∨e Serial Number	Serial Number Type
616441500001	LicenseGuard
CF41521499500911LT04	DFSN
1	Page 1 of 1 (2 item

Related Serial Numbers

Viewing Sales and Purchase Orders

You can view historical sales order data using the Orders menu in SLK. The information includes the following:

- Sales order number
- Order date
- Reseller name
- Company name
- Purchase order number
- Sold to name
- Shipped to name

To view:

1. Log in to SLK:

https://slk.arris.com

2. From the menu bar, click **Orders**.

The Orders page opens.

IEW FEATUREST HELP LOGO	UT SOFTWARE LICENSE KEY GENERATOR &	& Serial Number Repo	OSITORY			AR	RIS
Hello jane	Home	Orders	Inventory	Generat	te Keys	Tools	Profile
REFRESH LIST	ARRIS TEST		0		0.00		60.1
ARRIS TEST 1	Sales Order	Order Date	Reseller	Company	Purchase Order	Sold To	Shipped To
ARRIS TEST 2	90701514 TRANSFERED IN	VENTORY 11/07/2014	Comcast Cable Communications	ARRIS GROUP, INC.	2030043	Comcast Cable Communications	ARRIS - RA Decrement Pool
	90317197 TRANSFERED IN	VENTORY 10/24/2007	ARRIS GROUP, INC.	ARRIS GROUP, INC.	000245	TEXCOM CHILE S.A.	ARRIS - Identified as Customer Lost
	222099 TRANSFERED INV	VENTORY 11/08/2007	ARRIS GROUP, INC.	ARRIS GROUP, INC.	Adj. SLK Inv. 20071108	ARRIS GROUP, INC.	ARRIS (Motorola) - SANTA CLARA CA 2
	222099 TRANSFERED INV	VENTORY 11/08/2007	ARRIS GROUP, INC.	ARRIS GROUP, INC.	Adj. SLK Inv. 20071108	ARRIS GROUP, INC.	ARRIS - RA Decrement Pool
	222085 TRANSFERED INV	VENTORY 10/23/2007	Comcast Cable Communications	ARRIS GROUP, INC.	587260	Comcast Cable Communications	ARRIS - RA Decrement Pool
	222070 TRANSFERED INV	VENTORY 10/19/2007	ARRIS GROUP, INC.	ARRIS GROUP, INC.	224729	Cox Communications	ARRIS (Motorola) - SANTA CLARA CA 1

Orders

- 3. If you have more than one site, click the **Expand** button in the left panel.
- 4. Select the site you want.

Orders for the site display in tabular format.

- 5. To view the table, do the following:
 - To expand the entire table, click Refresh List in the left panel (if available).
 - To expand a column, select and drag it to the width you want.
 - To sort a column in alphanumeric order, click the column title.

Viewing License Pools

You can view unconsumed software inventory using the License Pool menu in SLK. The information includes the following:

- Site name
- Sales order number
- Key type
- License description
- Available unit quantity
- Platform

To view:

1. Log in to SLK:

https://slk.arris.com

2. From the menu bar, click **Inventory > License Pool**.

The License Pool Inventory page opens.

NEW FEATURES! HELP LOGOL	oftware License Key Gei	SLK	Serial Number Rep	OSITORY		ARRI				
Hello jane	Home	Orders		Inventory Generate				ools	Profile	
REFRESH LIST	ARRIS TEST									
ARRIS TEST 1	End User Key Type:		Sales Order	Кеу Туре	Description	Available Unit Qty	Platform			
	ARRIS (INF BANGALO		90485014 Transfered Inventory Line 6	1080P	6XXX-SLK-1080P,6XXX SERIES ENCODER 1080P 50/60 OPTIONAL FEATURE LICENSE FINISHED GOOD	3	SE-NE-SLK	GENERATE KEY	TRANSFER	
	ARRIS (Mo BASINGSTO	torola) - DKE GB UK 4	61013370 SO Line 1.1	1080P	6XXX-SLK-1080P,6XXX SERIES ENCODER 1080P 50/60 OPTIONAL FEATURE LICENSE FINISHED GOOD	5	SE-NE-SLK	GENERATE KEY	TRANSFER	
	ARRIS (Mo SAN DIEGO		90482858 Transfered Inventory Line 14	1080P	6XXX-SLK-1080P,6XXX SERIES ENCODER 1080P 50/60 OPTIONAL FEATURE LICENSE FINISHED GOOD	1	SE-NE-SLK	GENERATE KEY	TRANSFER	
	ARRIS (Mo SAN DIEGO		90485014 Transfered Inventory Line 1	1080P	6XXX-SLK-1080P,6XXX SERIES ENCODER 1080P 50/60 OPTIONAL FEATURE LICENSE FINISHED GOOD	22	SE-NE-SLK	GENERATE KEY	TRANSFER	

License Pool

- 3. If you have access to more than one site, click the **Expand** button in the left panel.
- 4. Select the site you want.

The license pool for the site display in tabular format.

- 5. To view the table, do the following:
 - To expand the entire table, click **Refresh List** in the left panel (if available).
 - To expand a column, select and drag it to the width you want.
 - To sort a column in alphanumeric order, click the column title.

Comparing Software Inventory

SLK provides a function that enables you to compare software inventory among devices within a product platform. This function is useful when you need to verify what software is installed on two or more devices. The information includes the following:

- License key inventory
- End user
- Serial number
- Platform

To compare:

1. Log in to SLK:

https://slk.arris.com

2. From the menu bar, click **Inventory > License Key Sets**.

The License Key Inventory and Serial Number page opens.

		SLK					TM
S	SOFTWARE LICENS	E KEY GENERATOR & SERIA	L NUMBER REPO	SITORY		ARF	R I 1
Hello jane	Home	Orders		Inventory G	ienerate Keys	Tools	Prof
Refresh List	ARRIS TE	EST ARRIS TEST 1					
ARRIS TEST						COMPARE	
ARRIS TEST 1	Selec	License Key Inventory I	End User	Serial Number	Platform	Transfer	
 ARRIS TEST 1 ARRIS TEST 2 	Selec	License Key Inventory 159961	End User ARRIS TEST 1	Serial Number 103912J1103Q1226	Platform DM	Transfer TRANSFER	
	Selec	The second second	The second second second second		DM		
		159961	ARRIS TEST 1	103912J1103Q1226	DM 2 DM	TRANSFER	
		159961 171781	ARRIS TEST 1 ARRIS TEST 1	103912J1103Q1226 437cTR75sk702sc00302	DM 2 DM	TRANSFER TRANSFER	
		159961 171781 173408	ARRIS TEST 1 ARRIS TEST 1 ARRIS TEST 1	103912J1103Q1226 437CTR75sk702sc00302 B8363195VJ310F179X00	DM 2 DM 3 DM 5E-4000	Transfer Transfer Transfer	

License Key Inventory and Serial Number

3. Under **Select**, select the check boxes associated with the device you want to compare.

4. Click Compare.

The Serial Numbers & License Key Types page opens. The serial numbers for the selected products appear in separate columns in the table.

Product	103912J1103Q1226	B8363195VJ310F179X00	
MPEG-2 AD INSERTION	64	0	~
4X ASI MODULE	8	4	
GigE PORT ACTIVATION	2	2	
GIGE PIPE CONTENT AGG	1	1	
HD RATESHAPING	16	4	
POWER BLOCK - SD RATE	64	16	
PSIP AGGREGATION	4	5	
STAT MUX POOL	1	1	
PSI/SI SPOOLING FOR NMX	19	19	
SDI-BASED MOTION GRAP	0	2	
STATIC GRAPHIC OVERLAY	0	16	-

Serial Numbers & License Key Types

Viewing Licensed Hardware

You can view licensed hardware inventory using the License Key Set menu in SLK. The information includes the following:

- License key inventory ID
- End user name
- Serial number
- Platform

To view:

1. Log in to SLK:

https://slk.arris.com

2. From the menu bar, click **Inventory > License Key Sets**. The License Key Inventory and Serial Number page opens.

SLK ERATOR & SERIAL NUMBER RE Orders EST 1	Inventory G	Senerate Keys	A R F Tools	RIS Profile
Orders EST 1	Inventory G	Generate Keys	Tools	
EST 1		G enerate Keys		Profile
	9		Compare	
			COMPARE	
Cey Inventory End User	Serial Number	Platform	Transfer	
ARRIS TEST	103912J1103Q1226	DM	TRANSFER	
ARRIS TEST	437CTR75sk702sc00302	2 DM	TRANSFER	
ARRIS TEST	B8363195VJ310F179X00	DM	TRANSFER	
ARRIS TEST	3308680287037571	SE-4000	TRANSFER	
ARRIS TEST	34127542090001570211	1 NE-2500	TRANSFER	
ARRIS TEST	6543876578902764	SE-6000	TRANSFER	
	ARRIS TEST 1	ARRIS TEST 1 3412754209000157021	ARRIS TEST 1 34127542090001570211 NE-2500	ARRIS TEST 34127542090001570211 NE-2500 TRANSFER

License Key Inventory and Serial Number

- 3. If you have access to more than one site, click the **Expand** button in the left panel.
- 4. Select the site you want.

The licensed hardware for the site displays in tabular format.

- 5. To view the table, do the following:
 - To expand the entire table, click **Refresh List** in the left panel (if available).
 - To expand a column, select and drag it to the width you want.
 - To sort a column in alphanumeric order, click the column title.

For information on transferring licensed hardware, refer to Chapter 8, "Transferring Inventory."

Viewing License Mobility Product Pools

You can view license mobility service products for the CAP-1000 and DM 6400 using the License Mobility Product Pool menu in SLK. The information includes the following:

- End user name
- Sales order number
- License description
- Available unit quantity
- Platform

To view:

1. Log in to SLK:

https://slk.arris.com

2. From the menu bar, click **Inventory > License Mobility Product Pool**.

The License Mobility Product Pool page opens.

	SLK						
	SOFTWARE LICENSE KEY GENERATOR			RI			
Hello jane	Home Ord	ers In	ventory Ger	nerate Keys		Tools	Profile
ARRIS TEST	ARRIS TEST Show License Mobility Service Pr	ODUCTS					
ARRIS TEST 2	End User	Sales Order	Description	Available Unit Qty	Platform		
	ARRIS-ELK GROVE CA US	90641941 Transfered Inventory Line 1	CAP1-SLK- MOVE,ELECTRONICALLY XFR SW LIC	45	CAP-1000	REVOKE LICENSES	TRANSFER
	ARRIS EXPENSE INTERNAL MIXED - Santa Clara 95051-1303 US	20086482 SO Line 1.1	CAP1-SLK- MOVE,ELECTRONICALLY XFR SW LIC	10	CAP-1000	REVOKE LICENSES	TRANSFER
	ARRIS EXPENSE INTERNAL MIXED - Santa Clara CA US	20105328 SO Line 3.1	CAP1-SLK- MOVE,ELECTRONICALLY XFR SW LIC	1	CAP-1010	REVOKE LICENSES	TRANSFER
	1						Page 1 of 1 (3 item:

License Mobility Product Pool

- 3. If you have access to more than one site, click the **Expand** button in the left panel.
- 4. Select the site you want.

The one-time license mobility licenses for the site display in tabular format.

- 5. To view the table, do the following:
 - To expand the entire table, click Refresh List in the left panel (if available).
 - To expand a column, select and drag it to the width you want.
 - To sort a column in alphanumeric order, click the column title.

Generating Reports

Using the Reports menu in SLK, you can generate many different types of useful reports. Depending on your user role and access, the types of reports that are available to you will differ.

To generate:

1. Log in to SLK:

https://slk.arris.com

2. From the menu bar, click **Tools > Reports** and select the report you want.

The Reports page opens.

3. Enter the data required for the selected report.

This data can include Company Name, Site Selection, Sales Order, Serial Number, etc.

	P LOGOUT	SLK					/
Sor	TWARE LICENSE KEY G	Generator & Serial Nu	MBER REPOSITORY		AR	RI!	S
ello jane 123	Home	Orders	Inventory	Generate Keys	Tools	Profile	
SLK Available Invent	IORY R EPORT						
Select a Compo	iny:			ARRIS GROUP, INC.			•
	- Milton Keynes Uł port Customer Se	rvice) - SINGAPORE	sg = ->	Selected Site(s): ARRIS (Motorola) - PLE ARRIS (Motorola) - SAN			-
ARRIS (Bax G ARRIS (Broad ARRIS (EXPEN ARRIS (Flash L ARRIS (Flash L	lobal) - SYDNEY A bus) - BOXBOROU ISE INTERNAL MIXE .ogistics) - ADVOC .ogistics) - AMSTER	GH MA ED) - SUWANEE GA CATE HARBOUR CN RDAM NL NL	CA	ARRIS (Motorola) - SAN ARRIS (Motorola) - San ARRIS (Motorola) - SAN ARRIS (Motorola) - SAN ARRIS (Motorola) - SAN	N DIEGO CA US 2 1 Diego CA US 3 NTA CLARA CA 1 NTA CLARA CA 2 NTIAGO CL		
ARRIS (Bax G ARRIS (Broad ARRIS (EXPEN ARRIS (Flash L ARRIS (Flash L ARRIS (Flash L	lobal) - SYDNEY A bus) - BOXBOROU ISE INTERNAL MIXE .ogistics) - ADVOC .ogistics) - AMSTEF .ogistics) - AZCAP	GH MA EDJ - SUWANEE GA CATE HARBOUR CN RDAM NL NL OTZALCO DISTRITO	US CA	ARRIS (Motorola) - SAN ARRIS (Motorola) - San ARRIS (Motorola) - SAN ARRIS (Motorola) - SAN	N DIEGO CA US 2 1 Diego CA US 3 NTA CLARA CA 1 NTA CLARA CA 2 NTIAGO CL		Ŧ

Reports

4. Click Generate Report.

After a few moments, the report is generated. Options to navigate, print, and export the report display at the bottom of the page.

NEW FEATURES! HELP LO	DGOUT SLK			
Softwar	RE LICENSE KEY GENERATOR & SER	ial Number Repository		ARRIS
Hello jane	Home Orders	Inventory	Generate Keys	Tools Profile
License Key SN Report Hide Filter				
Select a Company:		ARRIS TEST		
Select Site(s):		Selected Site(s): ARRIS TEST 1 ARRIS TEST 2 >> <		×
Generate Report				
	$f^1 > \bigcirc \bigcirc 100\%$		FIND NEXT	
•	Ш			4

Generated Report Options

Chapter 5 Generating Permanent Licenses

In This Chapter

- Overview
- Accessing the License Key Generation Wizard
- Generating Permanent Licenses for DM 6400 Devices
- Generating Permanent Licenses for CAP-1000 Devices
- Generating Permanent Licenses for SE-6000 Series and ST-6000 Series Devices
- Generating Permanent Licenses for NE2500 Devices
- Regenerating Permanent Licenses

Overview

This chapter explains how to generate and manage permanent licenses for the following devices:

- CAP-1000 CherryPicker Application Platform
- DM 6400 Digital Media Platform
- NE2500 Network Encryptor
- SE-6000 Series MPEG-4 AVC Encoder
- ST-6000 Series Multi-channel Video Transcoder

Note: If you purchased your device through ARRIS, contact your sales or customer service representative to purchase additional licenses. If you purchased your device through a reseller, contact your reseller to purchase additional licenses.

Accessing the License Key Generation Wizard

This section explains how to access the License Key Generation Wizard in SLK. The wizard provides an easy-to-use and convenient method for generating permanent license keys for CherryPicker products.

Three options are available for accessing the License Key Generation Wizard:

- Using the Generate Keys Option
- Using the License Pool Option
- Using the License Key Sets Option

Choose the option you prefer.

Using the Generate Keys Option

To use:

1. Log in to SLK:

https://slk.arris.com

2. From the menu bar, click **Generate Keys > Permanent**.

The License Key Generation Wizard opens.

NEW FEATURES	! HELP LOGOUT	SLK				T
	Software License Key Gi		AR	RIS		
Hello jane	Home	Orders	Inventory	Generate Keys	Tools	Profile
	LICENSE KEY GENERATION	N WIZARD				
	SELECT LOCATION OF SYSTEM. ARRIS - Eng Labs Show Next >	More Locations				

License Key Generation Wizard

- 3. Do one of the following:
 - To generate permanent licenses for DM 6400 devices, go to "Generating Permanent Licenses for DM 6400 Devices" on page 53 for more information.
 - To generate permanent licenses for CAP-1000 devices, go to **"Generating Permanent** Licenses for CAP-1000 Devices" on page 63 for more information.

- To generate permanent licenses for SE and ST devices, go to "Generating Permanent Licenses for SE-6000 Series and ST-6000 Series Devices" on page 73 for more information.
- To generate permanent license for NE2500 devices, go to "Generating Permanent Licenses for NE2500 Devices" on page 78 for more information.

Using the License Pool Option

The SLK License Pool is an inventory of unconsumed, purchased software by company and site location.

To use:

1. Log in to SLK:

https://slk.arris.com

2. From the menu bar, click **Inventory > License Pool**.

License pool information displays in tabular format.

ATURES! HELP LC		R	R I S				
e	Home	Orders	I	nventory	Generate Keys		Tools
IS GROUP, INC.	ARRIS GROUP, I	NC. ARRIS - Eng La	bs				
	End User	Sales Order	Кеу Туре	Description	A∨ailable Unit Qty	Platform	
	Key Type: ARRIS - Eng Labs		AI-M2	AD INSERTION - 1 SERVICE	100	BP-5100	GENERATE KEY
	ARRIS - Eng Labs	9999999991 TS Line 430.1	AI-M2	Enables Ad Insertion of 48 channels MPEG-2	76	CAP-1000	GENERATE KEY
	ARRIS - Eng Labs	9999999991 TS Line 250.1	AI-M2	Enables Ad Insertion of 12 channels MPEG-2	48	CAP-1000	GENERATE KEY
	4000	999999991 TS	AI-M2	Enables Ad Insertion with	100	CAP-1000	GENERATE KEY
	ARRIS - Eng Labs	Line 383.1		MPEG-2 Rate Shaping over 1 SD stream			

License Pool

3. Locate on the **Key Type** you want.

4. Select Generate Key.

The License Key Generation Wizard opens.



License Key Generation Wizard

- 5. Do one of the following:
 - To generate permanent licenses for DM 6400 devices, go to "Generating Permanent Licenses for DM 6400 Devices" on page 53 for more information.
 - To generate permanent licenses for CAP-1000 devices, go to "Generating Permanent Licenses for CAP-1000 Devices" on page 63 for more information.
 - To generate permanent licenses for SE and ST devices, go to "Generating Permanent Licenses for SE-6000 Series and ST-6000 Series Devices" on page 73 for more information.
 - To generate permanent license for NE2500 devices, go to "Generating Permanent Licenses for NE2500 Devices" on page 78 for more information.

Using the License Key Sets Option

License key sets include a list of all the data flash cards.

To use:


1. Log in to SLK:

https://slk.arris.com

2. From the menu bar, click **Inventory > License Key Sets**.

License key set information displays in tabular format.

NEW FEATURES! HELI	P LOGOUT	SLK					
So	ftware License Key Ge	enerator & Serial N	UMBER REPOSIT	ORY		A R	R
Hello jane	Home	Orders	Invento	ry Genera	te Keys	Tools	Profil
REFRESH LIST		ARRIS TEST 2	End User	Seríal Number	Compare	Transfer	
	Selec Lic	ARRIS TEST 2 cense Key Inventory 3408	End User ARRIS TEST 2	Serial Number B8363195vJ310P179X00		Transfer Transfer	
	Selec Lic	cense Key Inventory			Platform		
	Selec Lid	cense Key Inventory 3408	ARRIS TEST 2	B8363195VJ310F179X00	Platform DM	TRANSFER	



3. Select the Serial Number you want.

The License Key Details page opens.

		SLK						-		
	SOFTWARE LICENSE	Key Generator &	SERIAL NU	MBER REP	DSITORY			A	R	RI
jane	Home	Order	ſS	Inv	ventory	Generate Keys			Tools	Profile
	ARRIS TEST ARRIS TES	Т 2								
	Detail for License Key ID: Regenerate Keys Download XML DataSet	194638, Serial Num	BER: 616511	200047			Re	ATED SN		CLONE SN TRANSFER
		Key Type	Quan	Unit	License	License Key	Expira	Licen	Model	
	Expiration Date:									
		EAS ALERTS	1	Cha	1	AIRP26IQ23H2F		Perp	CAP-1000	IN
		BISS ENCRYPTI	1	Cha	1	IEYEGWGFRSFP		Perp	CAP-1000	IN
		CHERRYPI REDUNDA	1	Cha	1	TLCIEPLPD2HNX		Perp	CAP-1000	IN
	Upgrade	MPEG- 4/AVC HD RATESHA	2	Cha	16	CXXIH44PL5OX		Perp	CAP-1000	IN
	Upgrade	MPEG-2 AD INSERTION	78	Cha	384	AFPLVAQ3J2YRP		Perp	CAP-1000	IN
	Upgrade	CALM Act Audio Leveling	100	Ser	384	PIDEC4MXITY7J		Perp	CAP-1000	In
	Expiration Date:	7/23/2017								
	Upgrade	EBIF FILTERING- MERGING	384	Cha	384	FYVLFPFNIFN56	7/23/	Eval	CAP-1000	In
	1								Page	1 of 1 (9 items)

License Key Details

4. Locate the **Key Type** you want.

Note: Only key types that have inventory available to generate show in blue.

5. Click **Upgrade**.

The License Key Generation Wizard opens.

NEW FEATURES!	! HELP LOG	Ουτ	SLK				т
	Software Lic	ense Key Gen		AR	RIS		
Hello jane		Home	Orders	Inventory	Generate Keys	Tools	Profile
	SELECT LOCATIO						

License Key Generation Wizard

- 6. Do one of the following:
 - To generate permanent licenses for DM 6400 devices, go to "Generating Permanent Licenses for DM 6400 Devices" on page 53 for more information.
 - To generate permanent licenses for CAP-1000 devices, go to "Generating Permanent Licenses for CAP-1000 Devices" on page 63 for more information.
 - To generate permanent licenses for SE and ST devices, go to "Generating Permanent Licenses for SE-6000 Series and ST-6000 Series Devices" on page 73 for more information.
 - To generate permanent license for NE2500 devices, go to "Generating Permanent Licenses for NE2500 Devices" on page 78 for more information.

Generating Permanent Licenses for DM 6400 Devices

This section explains how to generate permanent license keys for feature and functions of the DM 6400 device. Refer to the procedure for your software version number.

- To generate a license without license mobility and software version less than 5.6, go to "Generating Permanent Licenses for Software Version less than 5.6" on page 53.
- To generate a license with License Mobility and software version greater than or equal to 5.6, go to "Generating Permanent Licenses for Software Version 5.6 or Greater" on page 58.

Generating Permanent Licenses for Software Version less than 5.6

Use this procedure to generate permanent license keys for DM 6400 devices running software version less than 5.6.

To generate:

1. Access the License Key Generation Wizard.

Go to "Accessing the License Key Generation Wizard" on page 48 for information.

The License Key Wizard opens and the current system location displays in the Locations menu.

NEW FEATURES!	! HELP LOGOUT	SLK				тм
	Software License Key G	ENERATOR & SERIAL I		AR	RIS	
Hello jane	Home	Orders	Inventory	Generate Keys	Tools	Profile
	LICENSE KEY GENERATION	N WIZARD				
	SELECT LOCATION OF SYSTEM.					
	ARRIS - Eng Labs Show Next >	More Locations				

Select Location

- 2. If you have more than one location, select **Show More Locations** and choose your location.
- 3. Click Next.

The Select Serial Number page opens.

NEW FEATURES!	HELP LOGOUT				
	SLK				тм
	SOFTWARE LICENSE KEY GENERATOR & SERIAL NU	IMBER REPOSITORY		AR	RIS
Hello jane	Home Orders	Inventory	Generate Keys	Tools	Profile
	License Key Generation Wizard				
	SELECT SERIAL NUMBER WHERE NEW LICENSE WILL BE INSTAL	LED.			
	Chassis: 2173690090026949- 5E-6401_01 Chassis: 2173699064000356- 5E-6601R_01 Chassis: 2173699064000486- 5E-6601R_01 Chassis: 2173699064000486- 5E-6601R_01 Chassis: 2173699064000592- 5E-6601R_01 Chassis: 2173699064000592- 5E-6601R_01 Chassis: 337566022500210- 5E-6601A_02 Chassis: 337566022500210- 5E-6601A_02 Chassis: 337566022000216- 5E-6601A_02 DFSN: 003201H990250519- DM-6400 DFSN: 00330H99023220- DM-6400 DFSN: 003310L1604A0008- DM-6400 DFSN: 003310L1604A0008- DM-6400 DFSN: 003110L105(2562-DM-6400 DFSN: 011407D160412425- DM-6400 V	e drop down above, pleas	e contact the ARRIS Techn	ical Assistance Center	
	888-944-HELP (4357). ((First) < Previous) Next >				

Select Serial Number

4. In the **Select Serial Number** menu, select the serial number of the device on which you want to generate the license key.

Note: If you do not see your serial number listed in the menu, contact the ARRIS Technical Assistance Center for help. See "Getting Help" on page x for more information.

5. Click Next.

The Select DM 6400 Software Version Preference page opens.

6. From the License Key Generation Wizard page, select the **Without License Mobility (Please** select this option if the software version of your unit is below Version 5.6) option.

NEW FEATURES!	HELP LOGOUT	SLK				TM
	SLK Software License Key Generator & Serial Number Repository			A R I	RIS	
Hello jane	Home	Orders	Inventory	Generate Keys	Tools	Profile
	LICENSE KEY GENERATION	WIZARD				
	PLEASE SELECT YOUR PREFERENCE	CE BELOW				
	Generate license - With	out License Mobility(Pl	ease select this option if th	e software version of your unit below	Version 5.6)	
	Cenerate license - With	License Mobility(Pleas	e select this option if the so	oftware version of your unit greater th	an or equal to Version 5.6)	
	« First < Previous	s Next >				

Select DM 6400 Software Version Preference

7. Click Next.

The License Pool Inventory page opens.

NEW FEATURES!	HELP LOGOUT	К			
	SOFTWARE LICENSE KEY GENERATO	or & Serial Number Repository		AR	RIS
Hello jane	Home C	Orders Inventory	Generate Keys	Tools	Profile
	License Key Generation Wizaf	RD			
	SELECT LICENSE POOL INVENTORY TO BE	USED.			
	Location: ARRIS TEST 1				
	DM-AG-GPA, GIGEPIPE AGGREG DM-AJ, MPEO-2 AD INSERTION (1 DM-AG-EXT, PSI/SI POOLING (19 DM-AG-PSIP, PSIP AGGREGATION DM-PB-4, SD RATESHAPING (16 CI DM-PB-4, SD RATESHAPING (16 CI DM-PB-4, SD RATESHAPING (16 CI	N (1 Port) Available Units: 1 SO:221578 SATION (1 Chassis) Available Units: 1 SC Channel) Available Units: 5 SO:90376 Y Multiplex) Available Units: 1 SO:221578 (1 Multiplex) Available Units: 1 SO:215918 Shannel) Available Units: 1 SO:21578 Chansis) Available Units: 1 SO:221578 Chassis) Available Units: 1 SO:221578	D:221578 LineNo:3 033 LineNo:1 78 LineNo:4 1578 LineNo:1 LineNo:5 LineNo:1 LineNo:8		
	« First < Previous	Next >			

Select License Pool Inventory

8. Select the license pool inventory you want to generate and click Next.

The Calculate License Quantities page opens.

NEW FEATURES! HE		SLK				
Soft	ware License Key Gen		IMBER REPOSITORY		AR	RIS
Hello jane	Home	Orders	Inventory	Generate Keys	Tools	Profile
LICENSE KEY GE	NERATION WIZARD					
GENERATE LICENSE	Key/s					
Location: ARRIS	TEST 1					
Serial Number: 1	FSN: 437CTR75sk702sc	00302- DM-6400				
License Type MPEG-2 AD INSE	Value	Qty Current Unit Value 1) + 1	Resulting Unit Value = 2 (The u	nit qty per serial number for this	license type must be betw	een 1 and 64.)
< Previous	Calculate					
Generate Key/s	S					

Calculate License Quantities

- 9. Enter the quantity of licenses you want to generate.
- 10. Click Calculate.

SLK calculates the resulting quantity per serial number for this license type.

• If the unit quantity is insufficient, you cannot continue. An error message similar to the following appears:

The Qty selected exceeded the maximum unit count of nn allowed for this license type $% \left({{{\left[{nn} \right]}_{n}}} \right)$

In this case, you need to purchase additional license keys. Contact the ARRIS Technical Assistance Center for help. See **"Getting Help" on page x** for more information.

• If the unit quantity is sufficient, the **Resulting Unit Value** updates. You can continue with generating license keys.

11. Click Generate Keys.

A confirmation page opens.

12. Click **OK** to submit the request.

After a few moments, a table displays with the license key(s).

NEW FEATURES! HE		SLK				
SOFT	ware License Key Gi		UMBER REPOSITORY		AR	RIS
Hello jane	Home	Orders	Inventory	Generate Keys	Tools	Profile
LICENSE KEY GE	NERATION WIZARD					
GENERATE LICENSE	Key/s					
Location: ARRIS	TEST 1					
Serial Number: D	FSN: 437CTR75Sk7025	SC00302- DM-6400				
License Type MPEG-2 AD INSE	Unit Value	Qty Current Unit Value	Unit Value		17	
MPEG-2 AD INSE	RTION (1 × [1 🔹) + 1	= 2 (ine unit qty p	er serial number for this	license type must be betv	veen 1 and 64.)
License Keys G	enerated Successful	ly				
КеуТуре	a To	otalQuantity		Licens	seKey	
AI-M2	2		V3QUDIWJUNXZMPKWGGE	DJFVSAPE		
< Previous	Recalculate					
Generate Key/s	s					
RESTART WIZARD						

Generated License Keys

13. Under the **License Key** column, select the license key and paste it in the Accounts tab of the DM 6400 GUI.

	nfiguration	Grooming Setup View/Edit		Analysis Stream Program		Alarms List Options	Administrat Accounts Log Out	ion Help V Customize Exit		
		Ch	erryPicker	DM610060900	092 👻					
User Accounts										
User Na	me 🔻		Fu	II Name			Description			
Admin The Admin						the user who can	do everything			
Product Licenses										
Туре	License Ke	y	Enabled	Used	Expiration Da	ite	Acknowledgeme	ent Code		
MPEG-2 Ad Insertion	QOOEWOXE6T2QEBCPH0		0	0	None			T5YTG2BBIOQ67E		
HD Recoding	TLN2KQNMZDXDSPNBG		0	0	None	NZOUZDE	BHG235ALR4T3RZF	W7KADP7SSKNH		
SD Recoding	ANMXUVXUNYRK7ADXB		64	15	None					
PSIP	MWKGMYVJXNKPMRCRN		64	0	None					
Stat Mux Pool GigE Port Activation	MJ75GL7437TVZTG6YUPE LODTNKN5HCKZTLEGAD		1	0	None					
Horizontal Resolution Change			4	2	None					
GigePipe Aggregation	PYRGKG75LWYTHY77PTW		10	0	None					
ASI Output Port Activation	540FLPGZF35DAFLOREKF		19	1	None					
External PSI/SI Spooling	RBFY6HZBW6RAU6ZAM		64	Ô	None					
SCTE 30 to 35 Conversion	IHB7KVAIMTZ5M63NOD		16	Ő	None			·		
								Enter License		
03-Feb-2017	11:11:44 PM UTC Site 1	434053722355	Us	er: Admin	Mode:Norn	nal	CPR: NA	Alarm: On		

DM 6400—Accounts

Refer to the DM 6400 Software Guide for information on installing the license key.

Generating Permanent Licenses for Software Version 5.6 or Greater

Use this procedure to generate permanent license keys for DM 6400 devices running software version 5.6 or greater.

To generate:

1. Access the License Key Generation Wizard.

Go to "Accessing the License Key Generation Wizard" on page 48 for information.

The License Key Wizard opens and the current system location displays in the Locations menu.

NEW FEATURES!	HELP LOGOUT	SLK				ТМ
	SOFTWARE LICENSE KEY GI	enerator & Serial N	NUMBER REPOSITORY		AR	RIS
Hello jane	Home	Orders	Inventory	Generate Keys	Tools	Profile
	LICENSE KEY GENERATION SELECT LOCATION OF SYSTEM.	N WIZARD				
	ARRIS - Eng Labs ▼ Show Next >	More Locations				

Select Location

- 2. If you have more than one location, select **Show More Locations** and choose your location.
- 3. Click Next.

The Select Serial Number page opens.

NEW FEATURES!	HELP LOGOUT	SLK				
	Software License Key Gei		umber Repository		AR	RIS
Hello jane	Home	Orders	Inventory	Generate Keys	Tools	Profile
	LICENSE KEY GENERATION	WIZARD				
	SELECT SERIAL NUMBER WHERE N	W UCENSE WILL BE INSTA	LLED.			
	Location: ARRIS - Eng Lab	s				
	Chassis: 2173480090024949 Chassis: 21734890400036- Chassis: 217348904400046- Chassis: 217348904400046- Chassis: 2173489044000592- Chassis: 2173489044000592- Chassis: 3375640228000286- DFSN: 001921L0704P2815- DFSN:	SE-6601R_01 SE-6601R_01 SE-6601R_01 SE-6601R_01 SE-6601R_02 SE-6601A_02 SE-6601A_02 SE-6601A_02 M-6400 M-6400 M-6400 M-6400 M-6400 M-6400	e drop down above, ple	ase contact the ARRIS Tech	nical Assistance Center	
	888-944-HELP (4357).					
	« First < Previou	s Next >				

Select Serial Number

4. In the **Select Serial Number** menu, select the serial number of the device on which you want to generate the license key.

Note: If you do not see your serial number listed in the menu, contact the ARRIS Technical Assistance Center for help. See "Getting Help" on page x for more information.

5. Click Next.

The Select DM 6400 Software Version Preference page opens.

6. From the License Key Generation Wizard page, select the **With License Mobility (Please select this option if the software version of your unit is greater than or equal to Version 5.6)** option.

NEW FEATURES!	HELP LOGOUT	SLK				ТМ
	Software License Key Ger	NERATOR & SERIAL N	umber Repository		ARI	r i s
Hello jane	Home	Orders	Inventory	Generate Keys	Tools	Profile
	LICENSE KEY GENERATION	WIZARD				
	PLEASE SELECT YOUR PREFERENCE	CE BELOW				
				e software version of your unit below '		1
	Generate license - With	License Mobility(Pleas	e select this option if the so	oftware version of your unit greater the	an or equal to Version 5.6)	J
	« First < Previous	s Next >				

Select DM 6400 Software Version Preference

7. Click Next.

The Select License Pool Inventory page opens.

NEW FEATURES!	HELP LOGOUT	SLK						TM
	Software License Key Gene	RATOR & SERIAL N	UMBER REPOSITORY		Α	R	RΙ	S
Hello jane	Home	Orders	Inventory	Generate Keys		Tools	Profile	
	LICENSE KEY GENERATION V	WIZARD						
	SELECT LICENSE POOL INVENTORY	TO BE USED.						
	Location: ARRIS TEST 1							
	DM-GIGE, GIGE PORT ACTIV DM-AG-GPA, GIGEPIPE AGC DM-AI, MPEG-2 AD INSERTIC DM-AG-EXT, PSI/SI SPOOLINV DM-AG-PSIP, PSIP AGGREG, DM-P8-4, SD RATESHAPING DM-P8-4, SD RATESHAPING DM-P8-4, SD RATESHAPING DM-AG-SMP, STAT MUX POOL	GREGATION (1 Chas DN (1 Channel) Ava G (19 Multiplex) Ava ATION (1 Multiplex) (16 Channel) Availa (16 Channel) Availa (16 Channel) Availa	sis) Available Units: 1 SO: ilable Units: 5 SO:903760: illable Units: 1 SO:21576 Available Units: 4 SO:221 bble Units: 1 SO:215916 Li ibble Units: 1 SO:216918 Li ible Units: 1 SO:221578 Li	221578 LineNo:3 33 LineNo:1 31 LineNo:4 578 LineNo:1 neNo:5 neNo:1 neNo:8				
	« First < Previous	Next >						

Select License Pool Inventory

8. Select the license pool inventory you want to generate and click **Next**.

The Calculate License Quantities page opens.

EW FEATURES! HE	ELP LOGOUT	SLK					
Soft	ware License Key Ge	NERATOR & SERIAL NU		ARRI			
ello jane	Home	Orders	Inventory	Generate Keys	Tools	Profile	
LICENSE KEY G	Generation Wizard						
GENERATE LICENS	SE KEY/S						
Location: ARR	RIS TEST 1						
Serial Number	:DFSN: B8363195VJ310	F179X00- DM-6400					
License Type	Unit Value	Qty Current Unit Value	Resulting Unit Value				
PSIP AGGREG	ATION (1 ×	1) + 4 =	5 (The unit c	ty per serial number for this li	icense type must be betw	een 1 and 8.)	
< Previous	Calculate						
Generate Ke	v/s						

Calculate License Quantities

- 9. Enter the quantity of licenses you want to generate.
- 10. Click Calculate.

SLK calculates the resulting quantity per serial number for this license type.

• If the unit quantity is insufficient, you cannot continue. An error message similar to the following appears:

The Qty selected exceeded the maximum unit count of nn allowed for this license type

In this case, you need to purchase additional license keys. Contact the ARRIS Technical Assistance Center for help. See **"Getting Help" on page x** for more information.

• If the unit quantity is sufficient, the **Resulting Unit Value** updates. You can continue with generating license keys.

11. Click Generate Keys.

A confirmation page opens.

12. Click **OK** to submit the request.

After a few moments, a table displays with the license key(s).

NEW FEATURES! HELP		SLK				
Softwar	RE LICENSE KEY C	Generator & Serial N	UMBER REPOSITORY		AF	RIS
lello jane	Home	Orders	Inventory	Generate Keys	Тоо	
LICENSE KEY GENE	ERATION WIZARD					
GENERATE LICENSE KE						
Location: ARRIS TE Serial Number: DFS		10F179X00- DM-6400				
License Type PSIP AGGREGATIO	Unit Value N (1 ×	Qty Current Unit Value 1) + 4	Resulting Unit Value = 5 (The unit qty per	serial number for this	license type must be b	petween 1 and 8.)
License Keys Ge	nerated Succes	sfully				
KeyType PSIP-AG	5	uantity CKGKLH	Q642RF5N53HZHRXKP2K7G55	LicenseKey TTEYJHB3TI	1	
< Previous R	Recalculate					
Generate Key/s]					
RESTART WIZARD						

Generated License Keys

13. Under the **License Key** column, select the license key and paste it in the Accounts tab of the DM 6400 GUI.

	nfiguration	Grooming Setup View/Edit		Analysis Stream Program		Alarms List Options	Administration Accounts Log Out	Help V Customize Exit	
		Ch	erryPicker	OM610060900	092 👻				
User Accounts									
User Name 🔻			Full Name			Description			
Admin The Admin						the user who can	e user who can do everything		
Product Licenses							Add User Edit User		
Type	License Key		Enabled	Used	Expiration Da	te	Acknowledgement Code		
MPEG-2 Ad Insertion		BCPHGEYY3RYWUR	0	0	None		4VYWAPEZ5RVMT5YT		
HD Recoding		NBGPL23KD6QF33	Ō	Ō	None		HG235ALR4T3RZFW7k		
SD Recoding		ADXB6P74SO6PERC	64	15	None				
PSIP		RCRN5HZ6YNLET4	64	0	None				
Stat Mux Pool	MJ75GL7437TVZTG		1	0	None				
GigE Port Activation		EGAD2SIMXZKK4N	4	2	None				
Horizontal Resolution Change			16	0	None				
GigePipe Aggregation		77PTW3LUP35U27P	1	0	None				
ASI Output Port Activation		OREKFMBIZ45OBDF	19	1	None				
External PSI/SI Spooling SCTE 30 to 35 Conversion	IHB7KVAIMTZ5M6	ZAMM4S2NYWBP3	64 16	0	None				
SULE SULO 35 COnversion		SINUTITINU44AHYIT	In	U	None			Enter License	
03-Feb-2017	11:11:44 PM UTC	Site 1434053722355		ser: Admin	Mode:Norm	al	CPR: NA	Alarm: On	

DM 6400—Accounts

Refer to the DM 6400 Software Guide for information on installing the license key.

Generating Permanent Licenses for CAP-1000 Devices

This section explains how to generate permanent license keys for feature and functions of the CAP-1000 device. Refer to the procedure for your software version number.

- To generate a license without license mobility and software version less 4.0, go to "Generating Permanent Licenses for Software Version Less Than 4.0" on page 63.
- To generate a license with license mobility and software version greater than or equal to version 4.0, go to "Generating Permanent Licenses for Software Version 4.0 or Greater" on page 68.

Generating Permanent Licenses for Software Version Less Than 4.0

Use this procedure to generate permanent license keys for CAP-1000 devices running software version less than 4.0.

To generate:

1. Access the License Key Generation Wizard.

Go to "Accessing the License Key Generation Wizard" on page 48 for information.

The License Key Wizard opens and the current system location displays in the Locations menu.

NEW FEATURES!	HELP LOGOUT	SLK				ТМ
	Software License Key Ge	NERATOR & SERIAL	NUMBER REPOSITORY		AR	RIS
Hello jane	Home	Orders	Inventory	Generate Keys	Tools	Profile
	LICENSE KEY GENERATION SELECT LOCATION OF SYSTEM. ARRIS - Eng Labs V Show Next >					

Select Location

- 2. If you have more than one location, select **Show More Locations** and choose your location.
- 3. Click Next.

The Select Serial Number page opens.

NEW FEATURES!	HELP LOGOUT
	SOFTWARE LICENSE KEY GENERATOR & SERIAL NUMBER REPOSITORY
Hello jane	Home Orders Inventory Generate Keys Tools Profile
	LICENSE KEY GENERATION WIZARD
	SELECT SERIAL NUMBER WHERE NEW LICENSE WILL BE INSTALLED.
	Location: ARRIS - Eng Labs
	Chossis: 21736904000365 :5E-6601R_01 Chossis: 2173689044000356 :5E-6601R_01 Chossis: 2173689044000400 :5E-661R_01 Chossis: 217368904400059 : SE-6601R_01 Chossis: 217368904400059 : SE-6601R_01 Chossis: 337566022500210 : SE-6601R_02 Chossis: 337566022500236 : SE-6601R_02 DFSN: 001921L0704P2815 : DM-6400 DFSN: 003301H0902325 : DM-6400 DFSN: 003310L15042008 : DM-6400 DFSN: 00311021050266 : DM-6400 DFSN: 01617A28081231 - DM-6400 DFSN: 011407D160412425 - DM-6400 DFSN: 011407D160412425 - DM-6400
	If you do not see your serial number listed in the drop down above, please contact the ARRIS Technical Assistance Center 888-944-HELP (4357).
	« First < Previous

Select Serial Number

4. In the **Select Serial Number** menu, select the serial number of the device on which you want to generate the license key.

Note: If you do not see your serial number listed in the menu, contact the ARRIS Technical Assistance Center for help. See "Getting Help" on page x for more information.

5. Click Next.

The Select CAP-1000 Software Version Preference page opens.

6. From the License Key Generation Wizard page, select the **Without License Mobility (Please** select this option if the software version of your unit is below Version 4.0) option.

NEW FEATURES!	HELP LOGOUT	SLK				Т
Software License Key Generator & Serial Number Repository					A R	R I S
Hello jane	Home	Orders	Inventory	Generate Keys	Tools	Profile
	LICENSE KEY GENERATION	WIZARD				
	PLEASE SELECT YOUR PREFERENCE	CE BELOW				
	Generate license - With	out License Mobility(Ple	ease select this option if the	e software version of your unit below	Version 4.0)	
	O Generate license - With	License Mobility(Please	e select this option if the sc	ftware version of your unit greater th	an or equal to Version 4.0)	
	« First < Previous	s Next >				

Select CAP-1000 Software Version Preference

7. Click Next.

The Select License Pool Inventory page opens.

		LK or & Serial Number Repository	Δ	R	RIS
Hello jane	Home	Orders Inventory	Generate Keys	Tools	Profile
	License Key Generation Wiza	ARD			
	SELECT LICENSE POOL INVENTORY TO BE Location: ARRIS TEST 1	E USED.			
	CAP1-SLK-EAS, CHERRYPICKER E CAP1-SLK-RS-384, M2 SD RS BUN CAP1-SLK-RS-MP4, M4 RATE SHA CAP1-SLK-AI-48, MPEG-2 AD INSE	EAS ENCRYPTION/DECRYPTION FG (1 CH NDLE - 96 HD AND 384 SD CHANNELS (0 APING BUNDLE - 1 HD CHANNEL (0) Avc IERTION - 48 CHANNELS (48 Channel) A	nassis) Available Units: 5 SO:90655091 Line nassis) Available Units: 1 SO:90619183 Line) Available Units: 1 SO:999999991 LineNo: allable Units: 16 SO:999999991 LineNo:4 vailable Units: 1 SO:999999991 LineNo:5 al) Available Units: 2 SO:90655091 LineNo:	No:1 :6	
	« First < Previous	Next >			

Select License Pool Inventory

8. Select the license pool inventory you want and click Next.

The Calculate License Quantities page opens.

P LOGOUT	SIK				
		luura Danaaraa			
ARE LICENSE KEY GEN	IERATOR & SERIAL D	NUMBER REPOSITORY		AR	K I D
Home	Orders	Inventory	Generate Keys	Tools	Profile
ENERATION WIZARD					
Key/s					
S TEST 1					
LicenseGuard: 61651	1200047				
		Resulting			
Value	Unit Value	Unit Value			
ERTION (48 ×	1) + 130	= 178 (The unit qty	per serial number for this licen	ase type must be between	1 and 384.)
Recalculate					
's					
	ARE LICENSE KEY GEN Home ENERATION WIZARD Key/s STEST 1 LicenseGuard: 61651: Unit C Value ERTION (48 × Recolculate	SLK ARE LICENSE KEY GENERATOR & SERIAL N MORE Orders ENERATION WIZARD KEY/S STEST 1 LicenseGuard: 616511200047 Unit Gty Current Value ERTION { 48 × 1 } + 130 Recalculate	SLK ARE LICENSE KEY GENERATOR & SERIAL NUMBER REPOSITORY Home Orders Inventory Home Orders Inventory ENERATION WIZARD Key/s STEST 1 LicenseGuard: 616511200047 Unit Unit Value Unit Unit Unit Value Unit Unit Unit ERTION { 48 × 1 + 130 = 178 (The unit qty Recalculate </th <th>SLK ARE LICENSE KEY GENERATOR & SERIAL NUMBER REPOSITORY Home Orders Inventory Generate Keys ENERATION WIZARD Ker/s STEST 1 LicenseGuard: 616511200047 Unit Quit Unit Unit Value Unit Unit Value ERTION (48 × 1) + 130 = 178< (The unit qty per serial number for this licent Recolculate</th> <th>SLK ARE LICENSE KEY GENERATOR & SERIAL NUMBER REPOSITORY Mome Orders Image: Non-operative description Mome Orders Image: Non-operative description Ker/s STEST 1 LicenseGuard: 616511200047 Unit Current Resulting Value Value Value Value Value Value ERTION (48 × 1) + 130 Recolculate</th>	SLK ARE LICENSE KEY GENERATOR & SERIAL NUMBER REPOSITORY Home Orders Inventory Generate Keys ENERATION WIZARD Ker/s STEST 1 LicenseGuard: 616511200047 Unit Quit Unit Unit Value Unit Unit Value ERTION (48 × 1) + 130 = 178< (The unit qty per serial number for this licent Recolculate	SLK ARE LICENSE KEY GENERATOR & SERIAL NUMBER REPOSITORY Mome Orders Image: Non-operative description Mome Orders Image: Non-operative description Ker/s STEST 1 LicenseGuard: 616511200047 Unit Current Resulting Value Value Value Value Value Value ERTION (48 × 1) + 130 Recolculate

Calculate License Quantities

9. Enter the quantity of licenses you want to generate.

10. Click Calculate.

SLK determines the unit quantity per serial number for this license type.

• If the unit quantity is insufficient, you cannot continue. An error message similar to the following appears:

The Qty selected exceeded the maximum unit count of nn allowed for this license type $% \left({{{\left[{n_{1}} \right]}_{n}}} \right)$

In this case, you need to purchase additional license keys. Contact the ARRIS Technical Assistance Center for help. See **"Getting Help" on page x** for more information.

• If the unit quantity is sufficient, the **Resulting Unit Value** updates. You can continue with generating license keys.


11. Click Generate Keys.

A confirmation page opens.

12. Click **OK** to submit the request.

After a few moments, a table displays with the license key(s).

FEATURES! HEL	P LOGOUT	SLK				
Softw	are License Key Ge	NERATOR & SERIAL NU	UMBER REPOSITORY		AR	RΙ
o jane	Home	Orders	Inventory	Generate Keys	Tools	Profile
LICENSE KEY GE	NERATION WIZARD					
GENERATE LICENSE						
Location: ARRIS	TEST 1					
Serial Number: 1	LicenseGuard: 6165	11200047				
License Type	Unit Value	Qty Current Unit Value	Resulting Unit Value			
MPEG-2 AD INSE	ERTION (48 ×	1) + 130 =		per serial number for this licen	se type must be betwee	n 1 and 384.)
License Keys G	enerated Successf	ully				
KeyTyp Al-M2	178	TotalQuantity	AFPLVAQ3J2YRP/	Licens	eKey	
< Previous	Recalculate					
Generate Key/	s					



13. Under the **License Key** column, select the license key and paste it in the Licenses tab of the CAP-1000 GUI.

Setup Trigg System Licer	-	Content Picking		Analysis		
	ises	Permissions	Redundancy	Files	DVB Simulcrypt Preferences	
Product Licenses	_					
Туре		Total	Available	Expiration Date	License Key	Acknowledgement Code
DVB ASI Output Port Activation	0		0	None	TU4BWFM0EAD00K4XJWRGCPU0XBMWKVMYL240ESY	MQQQBQOSTGOY373AFTWM4TKBKAHTCTATQUODLC
IPEG-4/AVC HD Recoding	0		0	None	ZSI30EWJVJ46PQQ6FQXSLWANRJVF2B6DYSKY2JQ	52RJ2ZV5ZEJPFDDPDWDMA6FST2WMFAGBQJLSEEI
IPEG-2 HD Recoding	96		87	None	E4Y6WE6A4T34W5QNMQO677PQ6SQJ7FRE3UBX4EI	
IPEG-2 SD Recoding	384		350	None	OTTRI2N5VJNJABAFMT7BJVKIXM7HAZ5M6LCGDQY	
IPEG-4/AVC Ad Insertion	256		256	None	6IUU4WMIBAWMKO4KJ54LYEEBBMGQY677WXLKA6I	
IPEG-2 Ad Insertion	384		384	None	HB3TJPDBY2R2PHMGNQ5MY0G5JH2FFNDE3XHUCWI	
CherryPicker Redundancy	1		0	None	5S7C536FFAXJWSL6BLEWXDUX2ISWPF32CNVWIQ	
Ad Insertion Protection	1		1	None	OHOIDWTX6HTZ2NNG4L46E5KNSOJYXIGOBLNDAUI	
BIF Filtering/Merging	300		299	None	XUG5GDHFI03EQHLKX76KHXPXKZKBLZBKHBS3CSI	
IISS	1		1	None	U33QL6LJ7XSIUKPS4TCIQWVBIBYFB4KSJMC6YSY	
AS Switching	1		1	None	NW4CKYPK242VJNDNA2VOVKIIB5/6XQOSOJ3BF0A	
ALM	284		284	None	RVFNAZ7T6TAUW2THLTIMX2TNDYS5RHCVIVPJSDA	

CAP-1000—Licenses

Refer to the CAP-1000 Software Guide for information on installing the license key.

Generating Permanent Licenses for Software Version 4.0 or Greater

Use this procedure to generate permanent license keys for CAP-1000 devices running software version 4.0 or greater.

To generate:

1. Access the License Key Generation Wizard.

Go to "Accessing the License Key Generation Wizard" on page 48 for information.

The License Key Wizard opens and the current system location displays in the Locations menu.

NEW FEATURES!	HELP LOGOUT	SLK				TM
	Software License Key Gi	enerator & Serial N	NUMBER REPOSITORY		AR	RIS
Hello jane	Home	Orders	Inventory	Generate Keys	Tools	Profile
	LICENSE KEY GENERATION SELECT LOCATION OF SYSTEM. ARRIS - Eng Labs SHOW Next >					

Select Location

- 2. If you have more than one location, select **Show More Locations** and choose your location.
- 3. Click Next.

The Select Serial Number page opens.

NEW FEATURES!	HELP LOGOUT	SLK				
	Software License Key Gen		UMBER REPOSITORY		AR	RIS
Hello jane	Home	Orders	Inventory	Generate Keys	Tools	Profile
	LICENSE KEY GENERATION	WIZARD				
	SELECT SERIAL NUMBER WHERE N	EW LICENSE WILL BE INSTA	LLED.			
	Location: ARRIS - Eng Labs					
	Chassis: 2173650070026959 Chassis: 2173689064000366 Chassis: 2173689064000400 Chassis: 2173689064000592 Chassis: 2173689064000592 Chassis: 2173689064000592 Chassis: 337566022500210- DFSN: 001921L0704P2815- DN DFSN: 00320110704P2815- DN DFSN: 0032011090250519- DN DFSN: 003306H9092X3220- DN DFSN: 003310D1604A0009- DN DFSN: 00331101404A0009- DN DFSN: 003110210502656- D DFSN: 010617A260812316- DM DFSN: 011407D160412425- DN	E=6601R_01 E=6601R_01 E=6601R_01 E=6601R_01 E=6601R_01 E=6601A_02 E=6601A_02 E=6400 A=6400 A=6400 M=6400 H				
	888-944-HELP (4357).	I number listed in th	e drop down above, ple	ase contact the ARRIS Tech	nical Assistance Center	
	« First < Previous	Next >				

Select Serial Number

- 4. From the **Locations** menu, select the serial number of the device on which you want to generate the license key.
- 5. Click Next.

The Select CAP-1000 Software Version Preference page opens.

Note: If you do not see your serial number listed in the menu, contact the ARRIS Technical Assistance Center for help. See "Getting Help" on page x for more information.

6. From the License Key Generation Wizard page, select the **With License Mobility (Please select this option if the software version of your unit is greater than or equal to Version 4.0)** option.

NEW FEATURES!	HELP LOGOUT	SLK				
	Software License Key Ge	NERATOR & SERIAL N	umber Repository		A R	RIS
Hello jane	Home	Orders	Inventory	Generate Keys	Tools	Profile
	LICENSE KEY GENERATION	I WIZARD				
	PLEASE SELECT YOUR PREFERENCE	CE BELOW				
	Cenerate license - With	out License Mobility(Ple	ease select this option if th	e software version of your unit below	Version 4.0)	
	Generate license - With	License Mobility(Please	e select this option if the so	ftware version of your unit greater the	an or equal to Version 4.0)	
	« First / Previou:	s Next >				

Select CAP-1000 Software Version Preference

7. Click Next.

The Select License Pool Inventory page opens.

NEW FEATURES!	! HELP LOGOUT SLK				тм
	Software License Key Generator & Serial Number Repository	Α	R	RΙ	S
Hello jane	Home Orders Inventory Generate Keys		Tools	Profile	
	License Key Generation Wizard				
	SELECT LICENSE POOL INVENTORY TO BE USED.				
	Location: ARRIS TEST 1				
	CAP1-SLK-BISS, CHERRYPICKER BISS ENCRYPTION/DECRYPTION FG (1 Chassis) Available Units: 5 \$0:906. CAP1-SLK-EAS, CHERRYPICKER EAS ENCRYPTION/DECRYPTION FG (1 Chassis) Available Units: 1 \$0:9061 CAP1-SLK-RS-384, M2 SD RS BUNDLE - 96 HD AND 384 SD CHANNELS (0) Available Units: 1 \$0:9999999 CAP1-SLK-RS-M4, M4 FATE SHAPING BUNDLE - 1 HD CHANNEL (0) Available Units: 1 \$0:99999991	19183 LineNo:1 91 LineNo:6	•		
	CAP1-SLK-AI-MP4, MPEG-4/AVC AD INSERTION - 1 CHANNEL (1 Channel) Available Units: 2 \$0:906550	91 LineNo:2			
			-		
	« First < Previous Next >				

Select License Pool Inventory

8. Select the license pool inventory you want and click Next.

The Calculate License Quantities page opens.

NEW FEATURES! HELP 1	LOGOUT SLK			>
Softwar	E LICENSE KEY GENERATOR & S	erial Number Repository	ARRIS	;
Hello jane	Home Order	s Inventory	Generate Keys Tools Profile	
LICENSE KEY GENERATIO	ON WIZARD			
GENERATE LICENSE KEY/S				
Location: ARRIS TEST 1				
Serial Number: License	Guard: 616511200047			
License Type MPEG-4/AVC HD RATESI	Unit Qty Value HAPING (1 × 1	Current Resulting Unit Unit Value Value) + 0 = 1 (The unit.	qty per serial number for this license type must be between 1 and 16.)	
MILEO AFATO HE RAILUI		7 · · · · · (neonin	gy per selen normeen of missicense type most be between it and top	
<pre>< Previous</pre> Calcul	ate			
Generate Key/s				

Calculate License Quantities

9. Enter the quantity of licenses you want to generate.

10. Click Calculate.

SLK determines the unit quantity per serial number for this license type.

• If the unit quantity is insufficient, you cannot continue. An error message similar to the following appears:

The Qty selected exceeded the maximum unit count of nn allowed for this license type

In this case, you need to log on to the source device and revoke the license key you need. Revoking the license key on the source device makes it available for use on the destination device. Refer to the *CAP-1000 Software Guide* for information on revoking license keys.

• If the unit quantity is sufficient, the **Resulting Unit Value** updates. You can continue with generating license keys.

11. Click Generate Keys.

A confirmation page opens.

12. Click **OK** to submit the request.

After a few moments, a table displays with the license key(s).

New Features! HELP		SLK				
		SLK				TM
SOFT	ware License Key Ge	ENERATOR & SERIAL	NUMBER REPOSITORY		ARR	IS
Hello jane	Home	Orders	Inventory	Generate Keys	Tools Prot	
LICENSE KEY GENER	RATION WIZARD					
Generate License Key	/s					
Location: ARRIS TES	τı					
Serial Number: Lice	enseGuard: 61651120	0047				
License Type	Unit Value	Qty	Current Resulting Unit Unit Value Value			
MPEG-4/AVC HD R	ATESHAPING (1	× 2 ÷) +		nit qty per serial number for	this license type must be between 1 and	16.)
License Keys Gen	erated Successfully					
KeyType RS-M4-HD	2 TotalQu		H44PL5OXHXXW4VPEGVJYH		ey	
((3-1014-11D	2	C/All				
< Previous Re	calculate					
Generate Key/s						
RESTART WIZARD						

Generated License Keys

13. Under the **License Key** column, select the license key and paste it in the Licenses tab of the CAP-1000 GUI.

Setup	Triggers	Content Picking	Alarms	Analysis			
System	Licenses	Permissions	Redundanc	y Files	DVB Simulcrypt	Preferences	
Product Licenses							
Туре		Total	Available	Expiration Date	Licens	se Key	Acknowledgement Code
OVB ASI Output Port Activation	n 0		0	None	TU4BWFM0EAD00K4XJWRG	CPUOXBMWKVMYL240ESY	MQQQBQOSTGOY373AFTWM4TKBKAHTCTATQUODLC
MPEG-4/AVC HD Recoding	0		0	None	ZSI30EWJVJ46PQQ6FQXSLV	VANRJVF2B6DYSKY2JQ	52RJ2ZV5ZEJPFDDPDWDMA6FST2WMFAGBQJLSEEI
IPEG-2 HD Recoding	96	1	87	None	E4Y6WE6A4T34W5QNMQO67	77PQ6SQJ7FRE3UBX4EI	
IPEG-2 SD Recoding	384	:	350	None	OTTRI2N5VJNJABAFMT7BJVI	KIXM7HAZ5M6LCGDQY	
IPEG-4/AVC Ad Insertion	256	:	256	None	6IUU4WMIBAWMKO4KJ54LYE	EBBMGQY677WXLKA6I	
IPEG-2 Ad Insertion	384	;	384	None	HB3TJPDBY2R2PHMGNQ5MY	OG5JH2FFNDE3XHUCWI	
CherryPicker Redundancy	1	(0	None	5S7C536FFAXJWSL6BLEWX0	DUX2ISWPF32CNVWIQ	
Ad Insertion Protection	1		1	None	OHOIDWTX6HTZ2NNG4L46E5	KNSOJYXIGOBLNDAUI	
BIF Filtering/Merging	300	:	299	None	XUG5GDHFI03EQHLKX76KHX	(PXKZKBLZBKHBS3CSI	
IISS	1		1	None	U33QL6LJ7XSIUKPS4TCIQWV	/BIBYFB4KSJMC6YSY	
AS Switching	1		1	None	NW4CKYPK242VJNDNA2VOV	/KIIB5I6XQOSOJ3BFOA	
ALM	284	:	284	None	RVFNAZ7T6TAUW2THLTIMX2	2TNDYS5RHCVIVPJSDA	

CAP-1000—License Key Installation

Refer to the CAP-1000 Software Guide for information on installing the license key.

Generating Permanent Licenses for SE-6000 Series and ST-6000 Series Devices

This procedure explains how to generate permanent license files for SE-6000 Series and ST-6000 Series devices running software version 3.1 or less or software version 4.1 or greater.

To generate:

1. Access the License Key Generation Wizard.

Go to "Accessing the License Key Generation Wizard" on page 48 for information.

The License Key Wizard opens and the current system location displays in the Locations menu.

NEW FEATURES!	HELP LOGOUT	SLK				ТМ
	Software License Key Gi	enerator & Serial M	NUMBER REPOSITORY		AR	RIS
Hello jane	Home	Orders	Inventory	Generate Keys	Tools	Profile
	License Key Generation	N WIZARD				
	SELECT LOCATION OF SYSTEM.					
	ARRIS - Eng Labs 🔻 Show	MORE LOCATIONS				
	Next >					

Select Location

2. If you have more than one location, select **Show More Locations** and choose your location.

3. Click Next.

The Select Serial Number page opens.

Note: Illustrations in this procedure depict the SE-6000 Series device.

NEW FEATURES!	HELP LOGOUT					
		SLK				тм
	Software License Key Gener	rator & Serial Nu	mber Repository		AR	RIS
Hello jane	Home	Orders	Inventory	Generate Keys	Tools	Profile
	LICENSE KEY GENERATION W	VIZARD				
	SELECT SERIAL NUMBER WHERE NEW	V UCENSE WILL BE INSTALL	ED.			
	Location: ARRIS - Eng Labs					
	Chassis: 2173690040026969-35 Chassis: 217369906400356-35 Chassis: 2173699064000400-35 Chassis: 2173689064000400-35 Chassis: 2173689064000592-35 Chassis: 2173689064000592-35 Chassis: 337560228000210-35 Chassis: 337560228000286-35 DFSN: 001921L0704P2815- DM- DFSN: 00330161909230519- DM- DFSN: 003301619023220- DM- DFSN: 003310L1604A008- DM- DFSN: 0031021502656- DM DFSN: 010617A2600[2316- DM- DFSN: 011407D1604[2425- DM-	5-6601R_01 -6601R_01 -6601R_01 -6601R_01 -6601R_01 -6601A_02 -6601A_02 -6601A_02 -6600 -640				
	lf you do not see your serial 888-944-HELP (4357).	number listed in the	drop down above, please	contact the ARRIS Tech	nical Assistance Center	
	«First < Previous	Next >				

Select Serial Number

4. In the **Select Serial Number** menu, select the serial number of the device on which you want to install the license file.

Note: If you do not see your serial number listed in the menu, contact the ARRIS Technical Assistance Center for help. See "Getting Help" on page x for more information.

5. Click Next.

The Select SE/ST Software Version Preference page opens.

- 6. Do one of the following:
 - Select the Generate licenses for software 3.1 or less option.
 - Select the Generate licenses for software 4.4 or greater option.

NEW FEATURES!	HELP LOGOUT	SLK				ТМ
Software License Key Generator & Serial Number Repository						RIS
Hello jane	Home	Orders	Inventory	Generate Keys	Tools	Profile
	LICENSE KEY GENERATION	I WIZARD				
	PLEASE SELECT YOUR PREFERENCE	CE BELOW				
	Generate licenses for so O Generate licenses for so					
	« First / Previou	s Next >				

Select SE/ST Software Version Preference

7. Click Next.

The Select License Pool page opens.

NEW FEATURES!	HELP LOGOUT				TM
Sc	oftware License Key Generator & Si	erial Number Repository		AR	RIS
Hello jane	Home Orders	Inventory	Generate Keys	Tools	Profile
	LICENSE KEY GENERATION WIZARD				
	SELECT LICENSE POOL INVENTORY TO BE USED.				
	Location: ARRIS TEST 1				
	572993-007-00, 6500-SLK-KEYS3 (0) Avc 556944-024-00, SE-NE-SLK-1080P-STD (1 556944-015-00, SE-NE-SLK-2CH-STD (1 C 556944-006-00, SE-NE-SLK-AVC-STD (1 C 556944-005-00, SE-NE-SLK-PIP-STD (1 Ch	Chassis) Available Units: 4 SO:99999 hassis) Available Units: 20 SO:999999 hassis) Available Units: 3 SO:9056473	999 LineNo:1 999 LineNo:2 39 LineNo:1		
	« First < Previous Next >	>			

Select License Pool Inventory

8. Select the license pool inventory you want and click Next.

The Calculate License Quantities page opens.

NEW FEATURES! HELP	LOGOUT	SLK				
Softwar	E LICENSE KEY GENI	erator & Serial Nu	IMBER REPOSITORY		AR	RIS
Hello jane	Home	Orders	Inventory	Generate Keys	Tools	Profile
LICENSE KEY GER	NERATION WIZARD					
GENERATE LICENSE	CEY/S					
Location: ARRIS	TEST 1					
Serial Number: C	massis: 6543876578	902764- SE-6501				
License Type	Unit G Value	ty Current Unit Value	Resulting Unit Value			
2 CHANNEL SUPP	ORT (1 ×	1)+0=	1 (The unit	qty per serial number for this lice	ense type must be betwe	een 1 and 1.)
< Previous	Calculate					
Generate Key/s						

Calculate License Quantities

- 9. Enter the quantity of licenses you want to generate.
- 10. Click Calculate.

SLK determines the unit quantity per serial number for this license type.

• If the unit quantity is insufficient, you cannot continue. An error message similar to the following appears:

The Qty selected exceeded the maximum unit count of nn allowed for this license type

In this case, you need to purchase additional licenses. Contact the ARRIS Technical Assistance Center for more information. See **"Getting Help" on page x** for more information.

- If the unit quantity is sufficient, the **Resulting Unit Value** updates. You can continue with generating the license file.
- 11. Click Generate Keys.

A confirmation page opens.

12. Click **OK** to submit the request.

After a few moments, the message, "License File is Generated. Please download it," displays.

13. Click **Download License File**.

New Fi	EATURES! HELP LOG	OUT	0 11/				
			SLK				тм
	SOFTWARE LICE	ense Key G	ENERATOR & SERIAL	NUMBER REPOSITORY		AR	RIS
Hello j	jane H	Home	Orders	Inventory	Generate Keys	Tools	Profile
	LICENSE KEY GENERATI	ON WIZARE	þ				
	GENERATE LICENSE KEY/S						
	Location: ARRIS TEST 1						
	Serial Number: Chassis	s: 6543876	578902764- SE-650	1			
	License Type	Unit Value	Qty Current Unit Value	Resulting Unit Value			
	2 CHANNEL SUPPORT	(1×	1)+0	= 1 (The unit qty	per serial number for this lic	ense type must be betw	een 1 and 1.)
Ľ	DOWNLOAD LICENSE FI	LE					
	License File is Genero	ated, Pleas	e Download it				
	< Previous Recal	culate					
	Generate Key/s						
	RESTART WIZARD						

Download License File

14. Save the license file to a location of your choice.

The license file is now available to install on the destination device.

	Current License Information			
Platform	Feature	License Number	Version	Expiry
SE6601-R	SD HD PVP AAC DD2 CFCBR STATMUX PIP HD2SD AC3xAAC AC3xDD+ AVCDEC DExDD+ DD+ MPEG2 1080P AVC CLM	3371662347010201	3.0	Never
Upload New License File:	Choose File No file chosen			

SE-6000—License File Installation

Refer to the SE-6000 Series MPEG-4 AVC Encoders User Guide for information on installing the license file

Generating Permanent Licenses for NE2500 Devices

This procedure explains how to generate permanent license files for NE2500 Network Encryptor devices running software version 1.1.0 or below of any software version greater than 1.1.0.

To generate:

1. Access the License Key Generation Wizard.

Go to "Accessing the License Key Generation Wizard" on page 48 for information.

The License Key Wizard opens and the current system location displays in the Locations menu.

NEW FEATURES!	HELP LOGOUT	SLK				Тм
	Software License Key Gei	NERATOR & SERIAL N		AR	RIS	
Hello jane	Home	Orders	Inventory	Generate Keys	Tools	Profile
	LICENSE KEY GENERATION SELECT LOCATION OF SYSTEM. ARRIS - Eng Labs V Show / Next >					

Select Location

- 2. If you have more than one location, select **Show More Locations** and choose your location.
- 3. Click Next.

The Select Serial Number page opens.

NEW FEATURES!	HELP LOGOUT				
	SOFTWARE LICENSE KEY GENERATOR & SERIA	AL NUMBER REPOSITORY		AR	RIS
Hello jane	Home Orders	Inventory	Generate Keys	Tools	Profile
	License Key Generation Wizard				
	SELECT SERIAL NUMBER WHERE NEW LICENSE WILL BE Location: ARRIS - Eng Labs	INSTALLED.			
	Chatsit: 2173680090026959-5E-6601_01 Chassis: 2173689064000366-5E-6601R_01 Chassis: 2173689064000400-5E-6601R_01 Chassis: 2173689064000486-5E-6601R_01 Chassis: 2173689064000592-5E-6601R_01 Chassis: 2173689064000592-5E-6601R_01 Chassis: 337660025000210-5E-6601R_02 Chassis: 337660025000210-5E-6601R_02 Chassis: 337660025000266-5E-6601R_02 DFSN: 0032014090230519- DM-6400 DFSN: 00330614090230519- DM-6400 DFSN: 003510L1604A0008- DM-6400 DFSN: 003510L1604A0008- DM-6400 DFSN: 0017420812316- DM-6400 DFSN: 011407D160412425- DM-6400 TSN: 011407D160412425- DM-6400				
	If you do not see your serial number listed 888-944-HELP (4357). « First <pre> <pre< td=""><td>in the drop down above, ple</td><td>ase contact the ARRIS Tech</td><td>nical Assistance Center</td><td></td></pre<></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre>	in the drop down above, ple	ase contact the ARRIS Tech	nical Assistance Center	

Select Serial Number

4. In the **Select Serial Number** menu, select the serial number of the device on which you want to generate the license file.

Note: If you do not see your serial number listed in the menu, contact the ARRIS Technical Assistance Center for help. See "Getting Help" on page x for more information.

5. Click Next.

The Select NE2500 Software Version Preference page opens.

- 6. Do one of the following:
 - Select File format 1 (select if NE 2500 is running software version 1.1.0 or below) option.
 - Select File format 2 (select if NE 2500 is running any software version greater than 1.1.0) option.

NEW FEATURES!	HELP LOGOUT	SLK				т
	Software License Key Gen	NERATOR & SERIAL N	Iumber Repository		AR	RIS
Hello jane	Home	Orders	Inventory	Generate Keys	Tools	Profile
	LICENSE KEY GENERATION	WIZARD				
	PLEASE SELECT YOUR PREFERENCE	E BELOW		_		
	File format 1 (select if NE	22500 is running SW ve	rsion 1.1.0 or below)			
	File format 2 (select if NE	2500 is running any SV	V version greater than 1.1.0)			
	« First / Previous	Next >				

Select NE2500 Software Version Preference

7. Click Next.

The License Pool Inventory page opens.

NEW FEATURES!	HELP LOGOUT	SLK				ТМ
:	SOFTWARE LICENSE KEY GE	NERATOR & SERIAL N	Iumber Repository		AR	RIS
Hello jane	Home	Orders	Inventory	Generate Keys	Tools	Profile
	LICENSE KEY GENERATION	I WIZARD				
	SELECT LICENSE POOL INVENTOR	RY TO BE USED.				
	Location: ARRIS TEST 1					
			ole Units: 15 SO:99999999 Ible Units: 15 SO:99999999			

Select License Pool Inventory

8. Select the license pool inventory you want and click Next.

The Calculate License Quantities page opens.

NEW FEATURES! HELP					
		SLK			ТМ
Softw	are License Key Gene	RATOR & SERIAL N	UMBER REPOSITORY		ARRIS
Hello jane123	Home	Orders	Inventory	Generate Keys	Tools Profile
GENERATI	KEY GENERATION WIZ : LICENSE KEY/S :: ARRIS TEST 1 Imber: Chassis: 3412 Unit Qty Value	7542090001570211- Current Resu	NE-2500 lifting		
IPPV < Previ	(1 × 1) ous Recalculate	Value Va	lue	rial number for this license typ	pe must be between 1 and 1.)

Generate License Keys

- 9. Enter the quantity of licenses you want to generate.
- 10. Click Calculate.

SLK determines the unit quantity per serial number for this license type.

• If the unit quantity is insufficient, you cannot continue. An error message similar to the following appears:

The Qty selected exceeded the maximum unit count of nn allowed for this license type

In this case, you need to purchase additional licenses. Contact the ARRIS Technical Assistance Center for more information. See **"Getting Help" on page x** for more information.

- If the unit quantity is sufficient, the **Resulting Unit Value** updates. You can continue with generating the license file.
- 11. Click Generate Keys.

A confirmation page opens.

12. Click **OK** to submit the request.

After a few moments, the message, "License File is Generated. Please download it," displays.

13. Click **Download License File**.

NEW FEATURE	RES! HELP LOGOUT	
	SLK	ТМ
	Software License Key Generator & Serial Number Repository	ARRIS
Hello jane	Home Orders Inventory Gen	erate Keys Tools Profile
	LICENSE KEY GENERATION WIZARD	
	GENERATE LICENSE KEY/S	
	Location: ARRIS TEST 1	
	Serial Number: Chassis: 34127542090001570211- NE-2500	
	License Unit Qty Current Resulting	
	Type Value Unit Unit Value Value	
	IPPV (1×1) + 0 = 1 (The unit qty per serial number for	or this license type must be between 1 and 1.)
	DOWNLOAD LICENSE FILE	
	License File is Generated, Please Download it	
	< Previous Recalculate	
	Generate Key/s	
	Restart Wizard	

Download License File

14. Save the license file to a location of your choice.

The license file is now available to install on the destination device.

ME2500 Element Manager Version 1.	.1.0 - 168.84.247.23
System Configuration SimulCrypt	S <u>t</u> atus
Reboot	
Administration	
Download Config	
Install License	
About A R	RIS
Exit	
Product Name :	NE2500
Product Type :	NE2500
Product Version :	1.1.0

NE2500—License File Installation

Refer to the NE2500 User Guide for information on installing the license file.

Regenerating Permanent Licenses

To successfully install a license key, it must use the correct format for the device and software version. Licenses that do not have the correct software format cannot be installed on a device.

Under certain circumstances; however, you may need to regenerate a license key for your CherryPicker product to ensure that the correct license key format is used. Depending on your device and software version, the license key format can vary in character length.

The regenerate function lets you regenerate existing license keys to the format needed based on the software version for your DM 6400 or CAP-1000 devices. Refer to the procedure that is appropriate for your device:

- Regenerating Permanent Licenses for DM 6400 Devices
- Regenerating Permanent Licenses for CAP-1000 Devices

Note: Only SLK administrators are authorized to regenerate permanent licenses for NE2500, SE-6000 Series, and ST-6000 Series devices. If you need to regenerate a license for any of these devices, contact the Technical Assistance Center. See "Getting Help" on page x for more information.

Regenerating Permanent Licenses for DM 6400 Devices

Based on the current software version installed on a DM 6400 device, you may need to regenerate the license.

To regenerate:

1. Log in to SLK:

https://slk.arris.com

2. From the menu bar, click **Tools > Search**.

The Search Options page opens.

NEW FEATURES!	HELP LOGOUT	SLK				
		JLK				
	SOFTWARE LICENSE KEY GE	NERATOR & SERIAL N	UMBER REPOSITORY		AR	RIS
Hello jane	Home	Orders	Inventory	Generate Keys	Tools	Profile
			SEARCH OF	TIONS		
	LICEN	ISE KEY SEARCH		SALES ORDER/P	URCHASE ORDER SEARCH	
	Enter the serial number a			Enter the Sales Order/Purc		would
	number type you would I information on below.	ike to search for licen	se	like to search for informatio	on on below.	
	Serial Number:			Number:		
	Type:			Search By: Sales Order	•	
	DFSN - DM products,			Search		
	LicenseGuard and co		DESN - CAP			
	products	shosponialing Extornal	Brott of			
	CFSN - Compact Flas	h - External DFSN, DM	products			
	Chassis - MPEG-4 Enc	oders, Network Encry	oters, DM			
	products, CAP products					
	Search					

Search Options

- 3. In the **Serial Number** field, enter the serial number for the DM 6400 device.
- 4. Under **Type**, select the product type.
- 5. Click Search.

A table displays with the search results.

6. Click Regenerate Keys.

				SL	(-	
	SOFT	vare License	Key Ge	NERATO	r & Serial Nu	MBER REPOSITORY			4	RR
jane		Home	e	0	rders	Inventory	Generate Keys			ols Profil
,	ARRIS TEST	ARRIS TEST 1								
			171781, 5	ERIAL NUM	MBER: 437CTR75	sk702sc00302		_		
	REGENERATE DOWNLOAD	KEYS XML DATASET						REVOKE RELATED SN		CLONE SN
[Кеу Туре	Quant	Unit	License Key	License Key	Expiration [License Ty	Mode	
	UPG		1	Cha	2	7YU4YA3EGGAOKTUNQVZ7UK	VUTKKL	Perpetual		INVENTORY DE
		CHERRYP PROGRAM REDUND	1	Cha	1	4ISUW7ZJ3YWRPVKCE2UFQ7S	DMCR	Perpetual	DM	INVENTORY DE
		EVENT MANAGER	1	Cha	1	TOAPSUNXRQ6HJK4F3374PYY	BHBTM2	Perpetual	DM	INVENTORY DE
	UPG	4X ASI MODULE	1	Port	8	WQHCA2QCBFWKUZXKAWLF	AUTCL	Perpetual	DM	INVENTORY DE
	UPG	MPEG-2 AD	2	Cha	64	V3QUDIWJUNXZM7MGLLKXZY	X6VNF	Perpetual	DM	INVENTORY DE
	UPG	GIGE PORT ACTIVATION	2	Port	4	DR422TC3KTKKA47LXMIO47G	OUZCH	Perpetual	DM	INVENTORY DE
										Page 1 of 1 (9 items)

License Key Search Details

The Choose Format page opens.

REGENERATE LICENSES - CHOOSE FORMAT	r 🛛
Regenerate Lice	enses for Serial Number: 437CTR75Sk702SC00302
© Generate license - Without Lic your unit below Version 5.6)	cense Mobility(Please select this option if the software version of
Generate license - With Licensul unit greater than or equal to Versi	se Mobility(Please select this option if the software version of your ion 5.6)
	Regenerate

Choose Format

- 7. Do one of the following:
 - To generate a license key with software version below 5.6, select **Generate license Without** License Mobility (Please select this option if the software version of your unit is below Version 5.6).

• To generate a license key with software version 5.6 or greater, select **Generate license - With** License Mobility (Please select this option if the software version of your unit is greater than or equal to Version 5.6).

If successful, a "Regenerate Successful" message appears. The license key(s) display in the page.

The regenerated license keys are now ready to be installed on Accounts tab of your DM 6400 GUI. Refer to the *DM 6400 Software Guide* for information on installing license keys.

Regenerating Permanent Licenses for CAP-1000 Devices

Based on the current software version installed on a CAP-1000 device, you may need to regenerate the license.

To regenerate:

1. Log in to SLK:

https://slk.arris.com

2. From the menu bar, click **Tools > Search**.

The Search Options page opens.

NEW FEATURES! HELP LOGOUT	SLK		/
Software License Key Gi	ENERATOR & SERIAL NUMBER REPOSITORY	ARRI	5
Hello jane Home	Orders Inventory	Generate Keys Tools Profile	
Enter the serial number of number type you would information on below. Serial Number: Type: © DFSN - DM products, © LicenseGuard and of products	NSE KEY SEARCH Ind select the appropriate serial like to search for license CAP products orresponding External DFSN - CAP	SALES ORDER/PURCHASE ORDER SEARCH Enter the Sales Order/Purchase Order Number you would like to search for information on below. Number: Search By: Sales Order	
	sh - External DFSN, DM products coders, Network Encrypters, DM		

Search Options

- 3. In the Serial Number field, enter the serial number for the CAP-1000 device.
- 4. Under **Type**, select the product type.
- 5. Click Search.

A table displays with the search results.

6. Click **Regenerate Keys**.

A table displays with the search results.

			SLK						
S	OFTWARE LICE	ense Key Genera	TOR & SERIAL NU	MBER R	EPOSITORY			\ F	RR
ane		Home	Orders	Inv	ventory	Generate I		Тоо	
AR	RIS TEST ARRI	S TEST 1							
			RIAL NUMBER: 616511	200041	1				
	GENERATE KEYS WNLOAD XML D	ATASET					REVOKE RELATED SN		CLONE SN
		Кеу Туре	G	U	Lice	License Key	Ex Li	I	
	Expiration	Date:							
		EAS ALERTS	1	Cł	1	AIRP26IQ2	Pe	С	I
		BISS ENCRYPTIO	1	Cł	1	IEYEGWGF	Pe	С	I
		CHERRYPIC REDUNDANCY	1	Cł	1	TLCIEPLPD	Pe	С	L
	UP	MPEG-4/AVC HD RATESHAPING	2	Cł	16	CXXIH44PL	Pe	С	I
		ASI PORT ACTIVATION	8	Pc	8	D5ZH3NW	Pe	с	I
		MPEG-2 HD RATESHAPING	96	Cł	96	QZNPPC6	Pe	С	I
	UP	CALM Act Audio Leveling	10	Se	384	PIDEC4MX	Pe	С	I
	UP	MPEG-2 AD	17	Cł	384	AFPLVAQ3	Pe	с	I
1								Pag	e 1 of 1 (11 items)

License Key Search Details

The Choose Format page opens.

REGENERATE LICENSES - CHOOSE FORMAT	X
Regenerate License	s for Serial Number: DSNUAFF7VTRAR8GLWL2P
© Generate license - Without Licen your unit below Version 4.0)	se Mobility(Please select this option if the software version of
Generate license - With License A unit greater than or equal to Version	Mobility(Please select this option if the software version of your 4.0)
	Regenerate

Choose Format

- 7. Do one of the following:
 - To generate a license key with software version below 4.0, select **Generate license Without** License Mobility (Please select this option if the software version of your unit is below Version 4.0).
 - To generate a license key with software version 4.0 or greater, select **Generate license With** License Mobility (Please select this option if the software version of your unit is greater than or equal to Version 4.0).

If successful, a "Regenerate Successful" message appears. The license key(s) display in the page.

The regenerates license keys are now ready to install in the Licenses tab of the CAP-1000 GUI. Refer to the *CAP-1000 Software Guide* for information on installing license keys.

Chapter 6 Using License Mobility with Onetime Move Licenses

In This Chapter

- Overview
- Using License Mobility on DM 6400 Devices
- Using License Mobility on CAP-1000 Devices

Overview

This chapter explains how to use license mobility to consume one-time move licenses on DM 6400 or CAP-1000 devices. When you purchase a one-time move license, ARRIS requires that all licenses be removed from your device at time of use. You can then redeploy them as needed on any device of the same platform.

Requirements

To use SLK, the following requirements apply:

- Administrator access to DM 6400, CAP-1000, CAP-1010, NE2500, SE-6000 Series, or ST-6000 Series device GUI.
- CAP-1000 units must be running software version 4.0 or greater.
- DM 6400 units must be running software version 5.6 or greater.

Constraints

When using license mobility, the following constraints apply:

- License mobility does not enable the sharing of licenses between DM 6400 and CAP-1000 systems.
- Once a system has used license mobility, it cannot be downgraded.

• When DM 6400 or CAP-1000 devices are configured for CPR, the primary unit must be operating correctly and not in failover mode. License mobility cannot be used on an active backup system.

Using License Mobility on DM 6400 Devices

To use the one-time move license option with a DM 6400, the device must be running software version 5.6 or greater. If it is running less than version 5.6, you need to upgrade the unit. Refer to the *DM 6400 Software Guide* for more information.

This section explains the following procedures:

- Verifying License Availability
- Revoking All Licenses
- Managing Acknowledgement Codes

To perform the procedures in this section, you will work with the DM 6400 Element Manager GUI and the License Mobility Wizard.

Verifying License Availability

To verify:

- 1. Log on to the DM 6400 device on which you want to revoke licenses.
- 2. Click Accounts.
- 3. In the **Used** column, ensure that all license types show **0**.

CherryPicker®								n Help 🔻		
Configure		Setup			Stream		List Accounts			
	File Editor	View/Edit				Options	Log Out	Exit		
			Cherr	yPicker o	im00d08804c144	-				
Admin		The Admin	1	-		the user w	ho can do everything	_		
							Add User Edit Us	er Delete User		
Product Licenses					•		Data Flash Serial # 1	03912J1103Q1226		
Type		License Key	Enabl.	. Used	Expiration Date	n Date Acknowledgement Code				
MPEG-2 Ad Insertion HD Recoding SD Recoding PSIP GIGE Port Activation ASI Output Port Activation	4GYEBWV2 HHXVHU5 VINVMHA2 NXDZW2N	SPU4FHAOUEWRFT iPpSVOZN7JBXESTR CCAIP5H4SOOOO AGG54JDUAIGDM ITEVGTCESVTVTX C524TOZCOOMG2			None None None None None			Enter License		
20-Feb-2017	7:00:33 PM UTC	Site 1484843172249	0 [ser: Admin	Mode:Normal	CPR: NA	Alarm: On		

DM 6400—Accounts

Next, you need to revoke all licenses on the device.

4. Go to "Revoking All Licenses" on page 91 to continue.

Revoking All Licenses

To revoke:

1. Log in to SLK:

https://slk.arris.com

2. From the menu bar, click **Inventory > License Mobility Product Pool**.

The License Mobility Product Pool page opens.

NEW FEATURES! HEL		SLK					TM
S	oftware License Key (Generator & Seria	L NUMBER REPOSITORY		Α	R R	I S
Hello jane	Home	Orders	Inventory	Generate Keys		Tools	Profile
			License Pool				
			License Key Sets				
REFRESH LIST	ARRIS TEST AR	RRIS TEST 1	License Mobility Product Pool				
	Show License M	OBILITY SERVICE PRODUC	Acknowledgement Code Entry	icense Mobility Servi	ice Product Poc	1	
ARRIS TES1	End User	Sales Order	Description	A∨ailable	Platform		
ARRIS TES1			Description	Unit Qty	- Idiroini		
	ARRIS TEST 1	20086482 SO Line 13.1	DM-SLK-MOVE,ELECTRONICALLY XFR S LIC	W 8	DM-6400	REVOKE LICENSES	
	1					Page 1 o	f 1 (1 items)

License Mobility Product Pool

3. If more than one site is available, select the site you want.

The one-time move licenses for the site display in tabular format.

- 4. To view the table, do the following:
 - To expand the entire table, click **Refresh List** in the left panel (if available).
 - To expand a column, select and drag it to the width you want.
 - To sort a column in alphanumeric order, click the column title.
- 5. Click **Revoke Licenses**.

NEW FEATURES!	HELP LOGOUT	SLK				тм	
	Software License Key (Generator & Serial	NUMBER REPOSITORY		Α	R R	I S
Hello jane	Home	Orders	Inventory	Generate Keys		Tools	Profile
REFRESH LIST	ARRIS TEST AF	RRIS TEST 1	s				
 ARRIS TES1 ARRIS TES1 	End User	Sales Order	Description	A∨ailable Unit Qty	Platform		
	ARRIS TEST 1	20086482 SO Line 13.1	DM-SLK-MOVE,ELECTRONICALLY XFR SW LIC	V 8	DM-6400	REVOKE LICENSES	
	1					Page 1 c	of 1 (1 items)

Revoke Licenses

The License Mobility Wizard opens and the current system location displays in the Locations menu.

NEW FEATURES!	HELP LOGOUT	SLK				TM
	Software License Key Gen	NERATOR & SERIAL N	UMBER REPOSITORY		ARR	I S
Hello jane	Home	Orders	Inventory	Generate Keys	Tools Profi	e
	SLK LICENSE MOBILITY WI	ZARD				
	SELECT LOCATION OF SYSTEM.					
	ARRIS TEST 2 Show More					
	confirm your License Mobil	lity Product inventory	before beginning this tro	ally consumed as appropriate with t ansaction CUCK HERE. Company/Sites ture is enabled by the SLA.		
	Next >					

Select Location

- 6. If you have more than one location, select **Show More Locations** and choose your location.
- 7. Click Next.

The Select Serial Number page opens.



Select Serial Number

8. In the **Select Serial Number** menu, select the serial number of the device on which you want to revoke the license.

Note: If you do not see your serial number listed in the menu, contact the ARRIS Technical Assistance Center for help. See "Getting Help" on page x for more information.

9. Click Next.

The Select DM 6400 Software Version Preference page opens.

- 10. Do one of the following:
 - If the software version of your unit is running version 5.6 or above, click **Yes**.
 - If the software version of your unit is running less than version 5.6, click **No**.

IMPORTANT: To use License Mobility, the DM 6400 device must be running software version 5.6 or greater. If it is running less than version 5.6, you need to upgrade the unit. Refer to the DM 6400 Software Guide for more information.

New Features!	HELP LOGOUT	SLK				TM
	Software License Key Ge	NERATOR & SERIAL N	umber Repository		A R	RIS
Hello jane	Home	Orders	Inventory	Generate Keys	Tools	Profile
	SLK LICENSE MOBILITY W	IZARD				
	PLEASE SELECT YOUR PREFEREN	ICE BELOW				
	Is the software version of	your unit running Ver	sion 5.6 or above?			
	O Yes					
	© No					
	« First < Previou	us Next >				

Select DM 6400 Software Version Preference

11. Click Next.

The Select Licenses to Revoke page opens.

New Features!	HELP LOGOUT	SLK				Т
	Software License Key Ge	NERATOR & SERIAL NUM	ABER REPOSITORY		AR	r i s
Hello jane	Home	Orders	Inventory	Generate Keys	Tools	Profile
	SLK LICENSE MOBILITY W	lizard				
	SELECT LICENSES TO REVOKE					
	Licenses selected which transaction.	were generated as part	of a bundle will cause	all licenses in the orginal bundle	to be included in this	
	4xASI-4X ASI MODULE AI-M2-MPEG-2 AD INS GIGE-GigE PORT ACT HD-HD RATESHAPING	ERTION Quantity - 64 VATION Quantity - 2	ł			
	< First < Previou	us Next >				

Select Licenses to Revoke

12. Select all licenses to revoke and click Next.

The Inventory Data page opens.

NEW FEATURES!	HELP LOGOUT								
	Software License Key Generator & Si	erial Numb	ER REPO	OSITORY			Α)
Hello jane	Home Orders		Inver	ntory	G	enerate Keys		Tools I	Profi
	SLK LICENSE MOBILITY WIZARD								
	REVOKE SELECTED LICENSES								
	PLEASE FIND THE INVENTORY AND CORRESPONDE	NG QUANTITY 1	O BE REV	OKED LISTE	ED BELOW.				
	Location: ARRIS TEST 1 Serial Number: DFSN: 103912J1103Q12 :	26- DM-640	D						
	HD RATESHAPING has dependent key	type : POW	ER BLC	CK - SD	RATESHAPING	e			
	КеуТуре	Qty	Unit Val	Current Val	Resultant feature Val	Sales Order	Line Number	Product Name	
	4X ASI MODULE	0 ‡	4	8	8	999999991	23	DM-4A-4	
	MPEG-2 AD INSERTION	0 ÷	32	64	64	999999991	17	DM-AI-32	
	GIGE PORT ACTIVATION	0 ‡	1	2	2	999999991	22	DM-GIGE-PORT1	
	HD RATESHAPING	0 ‡	16	16	16	999999991	18	DM-HD-16	
	POWER BLOCK - SD RATESHAPING	0 ‡	48	64	64	999999991	19	DM-PB-12	
	POWER BLOCK - SD RATESHAPING	0 ‡	16	64	64	999999991	20	DM-PB-4	
	PSIP AGGREGATION	0 ‡	1	4	4	999999991	21	DM-AG-PSIP	
	WARNING: ONCE A LICENSE MOBILITY REVOKE IN SLK. Previous Calculate	KEY HAS BEEN	ISSUED, 1	YOU WILL N	O LONGER HAVE 1	The ability to gene	RATE OLDER NON U	CENSE MOBILITY KEY TYPES	
	Submit								
	After you install the license/s on the unit to your pool.	enter the A	cknowl	edgemei	nt code HERE to	complete the	transaction and	I return the inventory	

Inventory Data

13. For each licensed service, select the entire quantity of licenses to revoke.

14. Click Calculate.

SLK calculates the quantity of licenses to revoke and displays a table with the **Resultant Feature Value**. The **Resultant Feature Value** must equal to zero.

ello jane	SLK Software License Key Generator & S							
lello jane		ERIAL NUME	er Rei	POSITORY			Α	RF
	Home Orders	5	Inve	entory	e	Generate Keys		Tools
	SLK LICENSE MOBILITY WIZARD							
	REVOKE SELECTED LICENSES							
	PLEASE FIND THE INVENTORY AND CORRESPOND		IO BE RI	EVOKED LISTI	ED BELOW.			
	Location: ARRIS TEST 1 Serial Number: DFSN: 103912J1103Q12	226- DM-640	0					
	HD RATESHAPING has dependent ker							
	КеуТуре	Qty		Current Val	Resultant feature Val	Sales Order	Line Number	Product Name
	4X ASI MODULE	2 ‡	4	8	0	999999991	23	DM-4A-4
	MPEG-2 AD INSERTION	2 ‡	32	64	0	999999991	17	DM-AI-32
	GigE PORT ACTIVATION	2 ‡	1	2	0	999999991	22	DM-GIGE-PORT1
	HD RATESHAPING	1 🜲	16	16	0	999999991	18	DM-HD-16
	POWER BLOCK - SD RATESHAPING	1 ‡	48	64	16	999999991	19	DM-PB-12
	POWER BLOCK - SD RATESHAPING	1 🜲	16	64	48	999999991	20	DM-PB-4
	PSIP AGGREGATION	4 🔹	1	4	0	999999991	21	DM-AG-PSIP
	WARNING: ONCE A LICENSE MOBILITY REVOKE	E KEY HAS BEEN	ISSUED.	YOU WILL N	O LONGER HAVE 1	THE ABILITY TO GENI	FRATE OLDER NON II	CENSE MOBILITY KEY TYPES
	IN SLK.							
	< Previous Recalculate							
	КеуТуре						Resultant feature Val	
	4X ASI MODULE							0
	MPEG-2 AD INSERTION							0
	GIGE PORT ACTIVATION							0
	HD RATESHAPING							1
	POWER BLOCK - SD RATESHAPING							0
	PSIP AGGREGATION							2
	Submit						L	
	After you install the license/s on the un	it enter the A	cknov	vledgeme	ent code HERE t	o complete the	transaction and	d return the inventory
	to your pool.			0				,

Inventory Data

15. Click Submit.

A confirmation page opens.

16. Click **OK** to submit the request.

After a few moments, a table displays with the revoked license key(s).

	GOUT SLK							
SOFTWARE L	CENSE KEY GENERATOR &	ERIAL NUMB	er Rep	OSITORY			Α	RF
	Home Order	5	Inve	ntory	G	ienerate Keys	-	Tools
-								
SLK LICEN	se Mobility Wizard							
REVOKE SELE	CTED LICENSES							
PLEASE FIND	THE INVENTORY AND CORRESPOND	ING QUANTITY T	O BE RE	VOKED LISTE	D BELOW.			
Location: Serial Num	ARRIS TEST 1 Der: DFSN: 103912J1103Q1	226- DM-640)					
HD RATESH	IAPING has dependent ke	ytype : POW	ER BLC	OCK - SD	RATESHAPING			
КеуТуре		Qty	Unit Val	Current Val	Resultant feature Val	Sales Order	Line Number	Product Name
4X ASI MO	DULE	2 ‡	4	8	0	999999991	23	DM-4A-4
MPEG-2 AI	D INSERTION	2 ‡	32	64	0	999999991	17	DM-AI-32
GigE PORT	ACTIVATION	2 ‡	1	2	0	999999991	22	DM-GIGE-PORT1
HD RATESH	APING	1 🜲	16	16	0	999999991	18	DM-HD-16
POWER BL	OCK - SD RATESHAPING	1 ‡	48	64	16	999999991	19	DM-PB-12
POWER BL	OCK - SD RATESHAPING	1 🗘	16	64	48	999999991	20	DM-PB-4
PSIP AGGR	EGATION	4 ‡	1	4	0	999999991	21	DM-AG-PSIP
IN SLK. < Previou Submit PLEASE INSTA	ONCE A LICENSE MOBILITY REVOR IS Recalculate LI THE REVOKE LICENSE KEYS LISTED WIEDGEMENT IS GENERATED IN TI RRIS.COM/SLK/LICENSEREVOKEA	BELOW IN THE I	INIT GUI	TO RETRIEVE	ACKNOWLEDGEM	IENT CODE.		
HTTPS://SLK.A								
https://slk.# KeyTyp		AGYERW//2P	PSVPC	REQ7BY 17		LicenseKey		
https://slk.a KeyTyp HD	0				3DKR4WH4GS	XE3OEQA		
https://slk.# KeyTyp	0	4T4EMTECSP	U4ESFI	J35IOC3S	3DKR4WH4GS) DJCG5PAQITHI	XE3OEQA 5P2Y		
https://slk.a Keytyp HD Al-M2	0	4T4EMTECSP HHXVHU5JC	U4ESFU	J35IOC3S MCZWYOE	3DKR4WH4GS	XE3OEQA 5P2Y SSAJXT4I		
HTTPS://SLK.A HTD HD AI-M2 SD	0 0 0	4T4EMTECSF HHXVHU5JC NXDZW2M4	U4ESFU CALPN TEVGTF	J35IOC3S MCZWYOE RYJ6ONW	3DKR4WH4GS) DJCG5PAQITHI 14SSSN4JS7OB6	XE3OEQA 5P2Y SSAJXT4I 8UOU6H3JDI		

Inventory Data

After obtaining the revoke license keys, you need to enter them into the DM 6400 GUI to obtain acknowledgement codes.

17. Go to "Managing Acknowledgement Codes" on page 109 to continue.

Managing Acknowledgement Codes

After obtaining all revoke license keys from SLK, you need to copy them, one at a time, into the Accounts tab of the DM 6400 GUI. The system will generate one acknowledgement code for each revoke license key entered in the DM 6400 GUI.

Once an acknowledgement is code is generated in the GUI, you need to copy it, return to SLK, and paste it in the SLK Acknowledgement Code Entry page. You'll need to repeat this procedure for each acknowledgement code that is generated in the DM 6400 GUI.

To manage:

- 1. Log on to the DM 6400 device on which you want to enter the revoke license key.
- 2. In the Element Manager GUI, click **Accounts**.
- 3. Click Enter License.

CherryPicker®	cker® Configuration		Grooming		Analysis	Alarms		Administration	Help 🗸
	Configure		Setup		Stream	List		Accounts	Customize
	File Editor	View/Edit			Program	Options		Log Out	Exit
			Cherry	yPicker	dm00d08804c144 👻				
Admin		The Admin				the user w	/ho can do ev	rerything	-
							Add	User Edit User	Delete User
Product Licenses							Data	Flash Serial # 103912	110301226
Туре		License Key	Enabl	Used	Expiration Date		Acknowled	gement Code	
MPEG-2 Ad Insertion HD Recoding SD Recoding PSIP Giat Port Activation ASI Output Port Activation	4GYEBWV HHXVHU5 VINVMHA NXDZW21	SPU4FHAOUEWRFT 2FPSVOZN7JBXESTR JCCALP5H4SOOOO 2AGG54JDUAJGDM 4ATEVGTCESVU7VX C524TOZCOOMG2	64 16 64 4 2 8		None None None None None				ter License
20-Feb-2017	7:00:33 PM UTC	Site 1484843172249	0		Jser: Admin	Mode:Normal	1	R: NA	Alarm: On

DM 6400—Accounts

The Enter License window opens.

Enter Lice	ense Key	×
	License Key OK Cancel	

Enter License Key

- 4. In the Enter License field, paste the revoke license key.
- 5. Click Apply License.

An acknowledgement code displays in the Acknowledgement Code column of the Product Licenses table.

CherryPicker®	Configuratio	n	Grooming			Analysis		Alarms		Administra	ation	Help 🔻
	Configure		Setup			Stream		List		Account	s 🤺	Customize.
	File Editor		View/Edit		[Program		Options		Log Ou	t J	Exit
				Cherr	vPicker	dm00d08804c14	1 -					
Admin			The Admin		, rener (_	the user wh	no can do	o everything		
									A	dd User Edit	User De	lete User
Product Licenses									D	ata Flash Serial #	103912J11	03Q1226
Туре		Li	cense Key	Enabl	. Used	Expiration Dat	e 🔟		Acknow	ledaement Code		
MPEG-2 Ad Insertion		4T4EMTECS	PU4FHAOUEWRFT	64	0	None		GNTMNMVJSMULBJJ3	3 KAKPWI	LVOFJU3WNZEYT	KSZOXHFZC	CMOM.
HD Recoding	4	4GYEBWV2F	PSVOZN7JBXESTR	16	0	None						
SD Recoding	- F	HHXVHU5JC	CALP5H4SOOQQ	64	0	None						
PSIP	1	VINVMHA2A	AGG54JDUAJGDM	4	0	None						
GigE Port Activation			TEVGTCE5YU7VX	2	0	None						
ASI Output Port Activation	n)	KRRB5RGTC	524TQZCOQMG2	8	0	None						
											Enter	License
20-Feb-2017	7:00:33 PI	II UTC	Site 1484843172249	6	ι	Jser: Admin		Mode:Normal		CPR: NA	Ala	rm: On

DM 6400—Accounts

6. Copy the acknowledgement code you want to paste in SLK.

Tip: To copy the acknowledgement code, double-click the code and press CTRL+C. Ensure that you do not include blank spaces or extraneous characters.

Note: You can also obtain the acknowledgement code via telnet by using the ConfigDisplay -1 command.

You are now ready to return to SLK and enter the acknowledgement code.

7. Log in to SLK:

https://slk.arris.com

8. Click Inventory > Acknowledgement Code Entry.

The License Revoke Acknowledgement page opens.

NEW FEATURES!	· · · ·	SLK				
	Software License Key Genera	tor & Serial N	NUMBER REPOSITORY		AR	RIS
Hello jane	Home	Orders	Inventory	Generate Keys	Tools	Profile
	LICENSE REVOKE ACKNOWLED Serial Number Serial Number Type Acknowledgment Code Submit	Selec	t.		•	

License Revoke Acknowledgement

- 9. In the **Serial Number** field, enter the serial number of the DM 6400 for which the acknowledgement code was generated.
- 10. From the Serial Number Type menu, select the DFSN option.
- 11. In the **Acknowledgement Code** field, paste the acknowledgement code obtained from the DM 6400 device.
- 12. Click Submit.

If successful, the message, "License Revoke Acknowledgement and inventory credit successful," displays.

Your revoked license inventory is returned to your SLK inventory pool.

- 13. Repeat steps 3 to 12 for each acknowledgement code provided in the GUI.
- 14. Verify your available license inventory in your license pool.

Go to "Viewing License Pools" on page 39 for information.

After all licenses are returned to the pool, you can select the type and quantity of licenses you need and redeploy them on one or more DM 6400 devices as needed.

Using License Mobility on CAP-1000 Devices

To use the one-time move license option on a CAP-1000, the device must be running software version 4.0 or greater. If it is running less than version 4.0, you need to upgrade the unit. Refer to the *CAP-1000 Software Guide* for more information.

This section explains the following procedures:

- Verifying License Availability
- Revoking All Licenses
- Managing Acknowledgement Codes

To perform the procedures in this section, you will work with the CAP-1000 Element Manager GUI and the License Mobility Wizard.

Verifying License Availability

To verify:

- 1. Log on to the CAP-1000 device on which you want to revoke licenses.
- 2. Click **Setup > Licenses**.
- 3. In the **Available** column, ensure that all license types are available to revoke.

The quantity in the **Available** column should match the quantity in the **Total** column.

Setup	Triggers	Content Picking	Alarms	Analysis		
System	Licenses	Permissions	Redundancy	Files	DVB Simulcrypt Preferences	
roduct Licenses				1		
Туре		Total	Available	Expiration Date	License Key	Acknowledgement Code
VB ASI Output Port Activation	1		l i i i i i i i i i i i i i i i i i i i	None	D5ZH3NWUF4XK4KSWK4JM3RFTTZCX3ZJ5OPGLHWA	Í.
PEG-4/AVC HD Recoding	2	1	2	None	CXXIH44PL50XHYZ76SVD55FUNMV63BEBYZ3CJ0I	
PEG-2 HD Recoding	96	9	16	None	QZNPPC6UQWWMPE3W2HOWBDANUOEX24BZE63KZYY	
PEG-2 SD Recoding	384	:	384	None	5NM3POB3SXLDRWR42UC26BFDY3XMZ4SU7E6YBEI	
PEG-4/AVC Ad Insertion	1		l i i i i i i i i i i i i i i i i i i i	None	PWK63UUSLLWR7JUICZAL6OXXE7RV5VKUKUC5M5A	
PEG-2 Ad Insertion	178		178	None	AFPLVAQ3J2YRP5TLVF0FIHPBAWU5G5BIBIG7ELQ	
herryPicker Redundancy	1		l	None	TLCIEPLPD2HNX6ROAFZORTFN2CPPVLX3W0Q5VUA	
d Insertion Protection	1		l i i i i i i i i i i i i i i i i i i i	None	GUCLWV5APJV7WSSINISBCQQTM2P5F6KVHTCNH3A	
BIF Filtering/Merging	384	:	384	None	FYVLFPFNIFN56SE36BGAT3I7VBMEPM7IRIEYBYI	
ISS	1		l i i i i i i i i i i i i i i i i i i i	None	IEYEGWGFRSFPA4N2E4ZX3B4INCOKDSQUCGHNLBY	
AS Switching	1		l .	None	AIRP26IQ23H2FHULTLDKRNM7HXVE4YN7P76G4OQ	
ALM	100		100	None	PIDEC4MXITY7JHDELFIX42YVUTHQUPMARN7A56Y	

CAP-1000—Licenses

Next, you need to revoke all licenses on the device.

4. Go to "Revoking All Licenses" on page 102 to continue.

Revoking All Licenses

To revoke:

1. Log in to SLK:

https://slk.arris.com

2. From the menu bar, click **Inventory > License Mobility Product Pool**.

The License Mobility Product Pool page opens.

NEW FEATURES! HELP LC	SLK						
	SLK						11
	SOFTWARE LICENSE KEY GENERATOR	& SERIAL NUMBER REPO	SITORY				RI
Hello jane	Home Ore	ders In	ventory Gen	ierate Keys		Tools	Profile
REFRESH LIST	ARRIS TEST						
ARRIS TEST ARRIS TEST 1	Show License Mobility Service P	RODUCTS					
ARRIS TEST 2	End User	Sales Order	Description	Available Unit Qty	Platform		
	ARRIS-ELK GROVE CA US	90641941 Transfered Inventory Line 1	CAP1-SLK- MOVE,ELECTRONICALLY XFR SW LIC	45	CAP-1000	REVOKE LICENSES	TRANSFER
	ARRIS EXPENSE INTERNAL MIXED - Santa Clara 95051-1303 US	20086482 SO Line 1.1	CAP1-SLK- MOVE,ELECTRONICALLY XFR SW UC	10	CAP-1000	REVOKE LICENSES	TRANSFER
	ARRIS EXPENSE INTERNAL MIXED - Santa Clara CA US	20105328 SO Line 3.1	CAP1-SLK- MOVE,ELECTRONICALLY XFR SW UC	1	CAP-1010	REVOKE LICENSES	TRANSFER
	1						Page 1 of 1 (3 items)

License Mobility Product Pool

3. If more than one site is available, select the site you want.

The mobile licenses for the site display in tabular format.

- 4. To view the table, do the following:
 - To expand the entire table, click **Refresh List** in the left panel (if available).
 - To expand a column, select and drag it to the width you want.
 - To sort a column in alphanumeric order, click the column title.
- 5. Click Revoke Licenses.

NEW FEATURES! HELP LOGOUT	SL	(_	
SOFTW	are License Key Generato	r & Serial Number Repo	SITORY			AR	R R I
Hello jane	Home Or	ders	Inventory Ge	nerate Keys		Tools	Profile
REFRESH LIST	ARRIS TEST						
ARRIS TEST	SHOW LICENSE MOBILITY SERVICE F	RODUCTS					
ARRIS EXPENSE INTERNAL MIX		Sales Order	Description	Available	Platform		
ARRIS EXPENSE INTERNAL MIX				Unit Qty			
ARRIS-ELK GROVE CA US	ARRIS-ELK GROVE CA US	90641941 Transfered Inventory Line 1	CAP1-SLK- MOVE,ELECTRONICALLY XFR SW LIC	45	CAP-1000	REVOKE LICENSES	TRANSFER
	ARRIS EXPENSE INTERNAL MIXED - Santa Clara 95051-1303 US	20086482 SO Line 1.1	CAP1-SLK- MOVE,ELECTRONICALLY XFR SW LIC	10	CAP-1000	REVOKE LICENSES	TRANSFER
	ARRIS EXPENSE INTERNAL MIXED - Santa Clara CA US	20105328 SO Line 3.1	CAP1-SLK- MOVE,ELECTRONICALLY XFR SW LIC	1	CAP-1010	REVOKE LICENSES	TRANSFER
							Page 1 of 1 (3 item

Revoke Licenses

The License Mobility Wizard opens and the current system location displays in the Locations menu.

NEW FEATURES!	HELP LOGOUT	SLK				TM
	SOFTWARE LICENSE KEY GE	NERATOR & SERIAL N	UMBER REPOSITORY		A R	RIS
Hello jane	Home	Orders	Inventory	Generate Keys	Tools	Profile
	SLK LICENSE MOBILITY W	IZARD				
	SELECT LOCATION OF SYSTEM.					
	ARRIS TEST 2 - Show More					
	confirm your License Mob	ility Product inventor	y before beginning this tro	ally consumed as appropriate with t ansaction CUCK HERE. Company/Sites ture is enabled by the SLA.		
	Next >					

Select Location

- 6. If you have more than one location, select **Show More Locations** and choose your location.
- 7. Click Next.

The Select Serial Number page opens.



Select Serial Number

8. In the **Select Serial Number** menu, select the serial number of the device on which you want to revoke the license key.

Note: If you do not see your serial number listed in the menu, contact the ARRIS Technical Assistance Center for help. See "Getting Help" on page x for more information.

9. Click Next.

The Select CAP-1000 Software Version Preference page opens.

- 10. Do one of the following:
 - If the software version of your unit is running version 4.0 or above, click **Yes**.
 - If the software version of your unit is running less than version 4.0, click **No**.

IMPORTANT: To use License Mobility, the CAP-1000 device must be running software version 4.0 or greater. If it is running less than version 4.0, you need to upgrade the unit. Refer to the CAP-1000 Software Guide for more information.

NEW FEATURES!	HELP LOGOUT	SLK				тм
	Software License Key Gei	NERATOR & SERIAL N	UMBER REPOSITORY		AR	RIS
Hello jane	Home	Orders	Inventory	Generate Keys	Tools	Profile
	SLK LICENSE MOBILITY WI	ZARD				
	PLEASE SELECT YOUR PREFERENC	E BELOW				
	Is the software version of y	our unit running Versio	on 4.0 or above?			
	• Yes					
	© №					
	« First < Previous	Next >				

Select CAP-1000 Software Version Preference

11. Click Next.

The Select Licenses to Revoke page opens.

NEW FEATURES!	HELP LOGOUT	SLK				тм
	Software License Key Geni	erator & Serial Nu	MBER REPOSITORY		A R I	RIS
Hello jane	Home	Orders	Inventory	Generate Keys	Tools	Profile
	SLK LICENSE MOBILITY WIZ	ARD				
	Select Licenses to Revoke					
	Licenses selected which we transaction.	ere generated as par	t of a bundle will cause a	II licenses in the orginal bundle	to be included in this	
	AI-M2-MPEG-2 AD INSE AI-M4-MPEG-4/AVC AD					
	ASI-ASI PORT ACTIVAT	ION Quantity - 8				
	BISS-BISS ENCRYPTION	DECRYPTION Qua	ntity - 1 📼			
	<pre><< First </pre> <pre></pre> <pre></pre>	Next >				

Select Licenses to Revoke

12. Select all licenses to revoke and click Next.

The Inventory Data page opens.

NEW FEATURES!	HELP LOGOUT								
	SOFTWARE LICENSE KEY GENERATOR 8	SERIAL NU	JMBER	REPOSITO	DRY			ARF	ε Î S
Hello jane	Home Ord	ers		Inventory	/	Generate Ke	eys	Tools	Profile
	SLK LICENSE MOBILITY WIZARD								
	REVOKE SELECTED LICENSES								
	PLEASE FIND THE INVENTORY AND CORRESPON	NDING QUANTI	ITY TO B	E REVOKED	USTED BELOW.				
	Location: ARRIS - Eng Labs Serial Number: LicenseGuard: 6160	21000012-	CAP-1	000					
	КеуТуре	Qty	Unit Val	Current Val	Resultant feature Val	Sales Order	Line Number	Product Name	
	MPEG-4/AVC AD INSERTION	4 ‡	1	4	4	999999991	211.1	CAP1-SLK-AI-MP4	
	AD INSERTION PROTECTION	0 ‡	1	1	1	999999991	212.1	CAP1-SLK-AIP	
	AD INSERTION PROTECTION	0 ‡	1	1	1	999999991	219.1	CAP1-SLR	
	CHERRYPICKER REDUNDANCY	0 ‡	1	1	1	999999991	219.1	CAP1-SLR	
	BISS ENCRYPTION/DECRYPTION	0 ‡	1	1	1	999999991	537.2	CAP1-SLK-BISS	
	WARNING: ONCE A LICENSE MOBILITY REVO SLK. < Previous Recalculate Submit	KE KEY HAS BI	EEN ISSU	ied, you wi	L NO LONGER HA	ve the ability to ge	INERATE OLDER NON	LICENSE MOBILITY KEY TYPES IN	

- 13. For each licensed service, select the entire quantity of licenses to revoke.
- 14. Click Calculate.

SLK calculates the quantity of licenses to revoke and displays a table with the **Resultant Feature Value**. The **Resultant Feature Value** must equal to zero.

	SOFTWARE LICENSE KEY GENERAT	OR SE OLIVIAL IN		iter Oarlo				ARF	
jane	Home	Orders		Inventory	1	Generate Ke	eys	Tools	Profile
	SLK LICENSE MOBILITY WIZARD								
	REVOKE SELECTED LICENSES								
	PLEASE FIND THE INVENTORY AND CORRI Location: ARRIS - Eng Labs Serial Number: LicenseGuard: (USTED BELOW.				
	КеуТуре	Qty	Unit Val	Current Val	Resultant feature Val	Sales Order	Line Number	Product Name	
	MPEG-4/AVC AD INSERTION	4 ‡	1	4	0	999999991	211.1	CAP1-SLK-AI-MP4	
	AD INSERTION PROTECTION	1 🜲	1	1	0	999999991	212.1	CAP1-SLK-AIP	
	AD INSERTION PROTECTION	1 🜲	1	1	0	999999991	219.1	CAP1-SLR	
	CHERRYPICKER REDUNDANCY	1 2	1	1	0	999999991	219.1	CAP1-SLR	
	BISS ENCRYPTION/DECRYPTION	1 🗘	1	1	0	999999991	537.2	CAP1-SLK-BISS	
	WARNING: ONCE A LICENSE MOBILITY SLK. <pre></pre>	REVOKE KEY HAS B	EEN ISSU	ied, you wil	l no longer ha'	ve the ability to ge	ENERATE OLDER NON	I LICENSE MOBILITY KEY TYPES IN	
	КеуТуре						Resultant feature Val		
	MPEG-4/AVC AD INSERTION							0	
	AD INSERTION PROTECTION							0	
	CHERRYPICKER REDUNDANCY							2	
	BISS ENCRYPTION/DECRYPTION							0	
	Submit						L		

15. Click Submit.

A confirmation page opens.

16. Click **OK** to submit the request.

After a few moments, a table displays with the revoked license keys.

	HELP LOGOUT	LK						
S	OFTWARE LICENSE KEY GENERAT	for & Serial N	UMBER	REPOSITO	DRY			ARF
ine	Home	Orders		Inventor	1	Generate K	-	Tools
	SLK LICENSE MOBILITY WIZARD							
	REVOKE SELECTED LICENSES							
	PLEASE FIND THE INVENTORY AND COR	RESPONDING QUAN		E REVOKED	LISTED BELOW.			
	Location: ARRIS - Eng Labs Serial Number: LicenseGuard:	616021000012-	CAP-1	.000				
	КеуТуре	Qty	Unit Val	Current Val	Resultant feature Val	Sales Order	Line Number	Product Name
	MPEG-4/AVC AD INSERTION	4 ‡	1	4	0	999999991	211.1	CAP1-SLK-AI-MP4
	AD INSERTION PROTECTION	1 🗘	1	1	0	999999991	212.1	CAP1-SLK-AIP
	AD INSERTION PROTECTION	1 ‡	1	1	0	999999991	219.1	CAP1-SLR
	CHERRYPICKER REDUNDANCY	1 🗘	1	1	0	999999991	219.1	CAP1-SLR
	BISS ENCRYPTION/DECRYPTION	1 ≑	1	1	0	999999991	537.2	CAP1-SLK-BISS
	WARNING: ONCE A LICENSE MOBILITY SLK. Previous Recalculate	Y REVOKE KEY HAS E	EEN ISS	JED, YOU W	LL NO LONGER HA'	ve the ability to g	ENERATE OLDER NO	n license mobility key types in
	Submit							
	PLEASE INSTALL THE REVOKE LICENSE KI ONCE ACKNOWLEDGEMENT IS GENERA HTTPS://SLK.ARRIS.COM/SLK/LICENSER	TED IN THE GUI, PLE					WLEDGEMENT CODE	ENTRY HERE:
Г	KeyType TotalQua	intity				LicenseKe	ey .	
	MPEG-4 0		NI6FAI	SQ2IBXSHI	BZSFTH745VBP5			
	AIP 0	BXHV	VRDIKT	THECGKIC	QMAUVJGZQD	5F2ZBBHDL7QI		
	All U							
	BISS 0 CPR 0	BZSFT	H745V	BP5JNYLSI	M2EX6KLYMU5ZI	NUMEDX7PQ		

After obtaining the revoke license keys, you need to enter them into the CAP-1000 GUI to obtain acknowledgement codes.

17. Go to **"Managing Acknowledgement Codes" on page 109** to continue.

Managing Acknowledgement Codes

After obtaining all revoke license keys from SLK, you need to copy them, one at a time, on the Licenses tab of the CAP-1000 GUI. The system will generate one acknowledgement code for each revoke license key entered in the CAP-1000 GUI.

Once an acknowledgement is code is generated in the GUI, you need to copy it, return to SLK, and paste it in the SLK Acknowledgement Code Entry page. You'll need to repeat this procedure for each acknowledgement code that is generated in the CAP-1000 GUI.

To manage:

- 1. Log on to the CAP-1000 device on which you want to enter the revoke license key.
- 2. In the Element Manager GUI, click **Setup > Licenses**.
- 3. In the Enter a New License Key field, enter the revoke license key.

CherryPicker [®] Eleme	nt Manager						Groups Logs Help About Logo
Setup Tr	iggers	Content Picking	g Alarms	Analysis			
System Li	censes	Permissions	Redundancy	/ Files	DVB Simulcrypt	Preferences	
Product Licenses							
Туре		Total	Available	Expiration Date	Licens	e Key	Acknowledgement Code
VB ASI Output Port Activation	1		1	None	D5ZH3NWUF4XK4KSWK4JM3	RFTTZCX3ZJ50PGLHWA	
IPEG-4/AVC HD Recoding	2		2	None	CXXIH44PL50XHYZ76SVD55F	FUNMV63BEBYZ3CJOI	
IPEG-2 HD Recoding	96		96	None	QZNPPC6UQWWMPE3W2HOW	BDANUOEX24BZE63KZYY	
IPEG-2 SD Recoding	384		384	None	5NM3POB3SXLDRWR42UC268	BFDY3XMZ4SU7E6YBEI	
IPEG-4/AVC Ad Insertion	1		1	None	PWK63UUSLLWR7JUICZAL60	XXE7RV5VKUKUC5M5A	
IPEG-2 Ad Insertion	178		178	None	AFPLVAQ3J2YRP5TLVF0FIHF	PBAWU5G5BIBIG7ELQ	
CherryPicker Redundancy	1		1	None	TLCIEPLPD2HNX6ROAFZORTF	N2CPPVLX3W0Q5VUA	
Ad Insertion Protection	1		1	None	GUCLWV5APJV7WSSINISBC0	QTM2P5F6KVHTCNH3A	
BIF Filtering/Merging	384		384	None	FYVLFPFNIFN56SE36BGAT317	VBMEPM7IRIEYBYI	
IISS	1		1	None	EYEGWGFRSFPA4N2E4ZX3B	4INCOKDSQUCGHNLBY	
AS Switching	1		1	None	AIRP26IQ23H2FHULTLDKRNM	7HXVE4YN7P76G4OQ	
ALM	100		100	None	PIDEC4MXITY7JHDELFIX42YV	UTHQUPMARN7A56Y	
Active License Guard Serial N	lumber: 616	511200047	Enter a new licens	se key:			Apply License

CAP-1000—Licenses

4. Click Apply License.

An acknowledgement code displays in the Acknowledgement Code column of the License table.

Setup	Triggers	Content Picking	Alarms	Analys		
System	Licenses	Permissions	Redundancy	Files	DVB Simulcrypt Preferer	ices
roduct Licenses						
Туре		Total	Available	Expiration Date	License Key	Acknowledgement Code
/B ASI Output Port Activation	1		1	None	TU4BWFMOEADOOK4XJWRGCPUOXBMWKV	MYL240ESY MQQQBQ0STG0Y373AFTWM4TKBKAHTCTATQUOD
PEG-4/AVC HD Recoding	2		2	None	ZSI30EWJVJ46PQQ6FQXSLWANRJVF2B6D)	SKY2JQ 52RJ2ZV5ZEJPFDDPDWDMA6FST2WMFAGBQJLSEEI
PEG-2 HD Recoding	96		96	None	E4Y6WE6A4T34W5QNMQO677PQ6SQJ7FRE	3UBX4EI
PEG-2 SD Recoding	384	4	384	None	OTTRI2N5VJNJABAFMT7BJVKIXM7HAZ5M6L	CGDQY
PEG-4/AVC Ad Insertion	1		1	None	6IUU4WMIBAWMK04KJ54LYEEBBMGQY677	VXLKA6I
PEG-2 Ad Insertion	178	3	178	None	HB3TJPDBY2R2PHMGNQ5MY0G5JH2FFNDE3	IXHUCWI
nerryPicker Redundancy	1		1	None	5S7C536FFAXJWSL6BLEWXDJX2ISWPF32C	NVWIQ
d Insertion Protection	1		1	None	OHOIDWTX6HTZ2NNG4L46E5KNS0JYXIG0B	LNDAUI
BIF Filtering/Merging	384	4	384	None	XUG5GDHFI03EQHLKX76KHXPXKZKBLZBKH	BS3CSI
SS	1		1	None	U33QL6LJ7XSIUKPS4TCIQWVBIBYFB4KSJM0	26YSY
AS Switching	1		1	None	NW4CKYPK242VJNDNA2VOVKIIB5/6XQOSO.	J3BFOA
ALM	100	D	100	None	RVFNAZ7T6TAUW2THLTIMX2TNDYS5RHCV/	VPJSDA

CAP-1000—Licences

5. Copy the acknowledgement code you want to paste in SLK.

Tip: To copy the acknowledgement code, double-click the code and press CTRL+C. Ensure that you do not include blank spaces or extraneous characters.

Note: You can also obtain an acknowledgement code via telnet by using the ConfigDisplay -1 command.

You are now ready to return to SLK and enter the acknowledgement code.

6. Log in to SLK:

https://slk.arris.com

7. Click Inventory > Acknowledgement Code Entry.

The License Revoke Acknowledgement page opens.

NEW FEATURES!	HELP LOGOUT	SLK				
\$	Software License Key Gener	ATOR & SERIAL	NUMBER REPOSITORY		AR	RIS
Hello jane	Home	Orders	Inventory	Generate Keys	Tools	Profile
	LICENSE REVOKE ACKNOWLE Serial Number Serial Number Type Acknowledgment Code Submit	EDGEMENT Sele	ct		¥	

License Revoke Acknowledgement

- 8. In the **Serial Number** field, enter the serial number of the CAP-1000 requiring the revoke license key.
- 9. From the Serial Number Type menu, select the License Guard option.
- 10. In the **Acknowledgement Code** field, paste the acknowledgement code obtained from the CAP-1000.
- 11. Click Submit.

If successful, the message, "License Revoke Acknowledgement and inventory credit successful," displays.

Your revoked license inventory is returned to your SLK inventory pool.

- 12. Repeat steps 3 to 11 for each acknowledgement code provided in the GUI.
- 13. Verify your available license inventory in your license pool.

Go to "Viewing License Pools" on page 39 for information.

After all licenses are returned to the pool, you can select the type and quantity of licenses you need and redeploy them on one or more CAP-1000 devices as needed.

Chapter 7 Using License Mobility with an SLA

In This Chapter

- Overview
- Using License Mobility on DM 6400 Devices
- Using License Mobility on CAP-1000 Devices

Overview

This chapter explains how to use license mobility with a purchased support-level agreement (SLA). With an SLA, you can choose the licenses you want to revoke on a DM 6400 or CAP-1000 device, return them to the license inventory pool, and redeploy them on any device of the same platform as needed.

Requirements

To use SLK, the following requirements apply:

- Administrator access to DM 6400, CAP-1000, CAP-1010, NE2500, SE-6000 Series, or ST-6000 Series device GUI.
- CAP-1000 units must be running software version 4.0 or greater.
- DM 6400 units must be running software version 5.6 or greater.

Constraints

When using license mobility, the following constraints apply:

- License mobility does not enable the sharing of licenses between DM 6400 and CAP-1000 systems.
- Once a system has used license mobility, it cannot be downgraded.

• When DM 6400 or CAP-1000 devices are configured for CPR, the primary unit must be operating correctly and not in failover mode. License mobility cannot be used on an active backup system.

Using License Mobility on DM 6400 Devices

To use license mobility with an SLA on a DM 6400, the device must be running software version 5.6 or greater. If it is running less than version 5.6, you need to upgrade the unit. Refer to the *DM 6400 Software Guide* for more information.

This section explains the following procedures:

- Verifying License Availability
- Revoking Licenses
- Managing Acknowledgement Codes

To perform the procedures in this section, you will work with the DM 6400 Element Manager GUI and the License Mobility Wizard.

Verifying License Availability

To verify:

- 1. Log on to the DM 6400 device on which you want to revoke licenses.
- 2. Click Accounts.
- 3. In the **Used** column, ensure that the licenses types you want **to revoke are available. The Enable Qty Minus Used Qty equals the Qty Available To Revoke.**

CherryPicker®	Configuration	Grooming			Analysis	Alarms		Administration	Help 🔻
	Configure	Setup			Stream	List		Accounts	Customize
	File Editor	View/Edit		Program		Options		Log Out	Exit
			Cherr	vPicker	im00d08804c144	J			
IAdmin		The Admir		yr leker e			/ho can do ev	onthing	
Autim		The Authin				the user w		/eryuning	Ē
							Add	User Edit User	Delete User
A							7100		
Product Licenses							Data	Flash Serial # 103912	J1103Q1226
Туре		License Key	Enabl	. Used	Expiration Date		Acknowled	gement Code	
MPEG-2 Ad Insertion		SPU4FHAOUEWRFT	64	0	None			-	
HD Recoding		2FPSVOZN7JBXESTR		0	None				
SD Recoding		JCCALP5H4SOOQQ	64	0	None				
PSIP		2AGG54JDUAJGDM	4	0	None				
GigE Port Activation		14TEVGTCE5YU7VX	2	0	None				
ASI Output Port Activation	XRRB5RGT	C524TQZCOQMG2	8	0	None				
								En	ter License
00 Feb 0047	7.00.00 00 070	01-01-01010170010	01		a an A daria	Madadiaasal	1		
20-Feb-2017	7:00:33 PM UTC	Site 1484843172249			ser: Admin	Mode:Normal	CP CP	R: NA	Alarm: On

DM 6400—Accounts

Next, you need to revoke the selected licenses on the device.

4. Go to "Revoking Licenses" on page 115 to continue.

Revoking Licenses

To revoke:

1. Log in to SLK:


https://slk.arris.com

2. From the menu bar, click **Generate Keys > License Mobility**.



SLK Account Home

The License Mobility Wizard opens and the current system location displays in the Locations menu.



Select Location

3. If you have more than one location, select **Show More Locations** and choose your location.

4. Click Next.

The Select Serial Number page opens.

New Features!	HELP LOGOUT					
		SLK				тм
	Software License Key Gen	NERATOR & SERIAL N	UMBER REPOSITORY		A R	RIS
Hello jane	Home	Orders	Inventory	Generate Keys	Tools	Profile
	SLK LICENSE MOBILITY WI	ZARD				
	SELECT SERIAL NUMBER WHERE N	EW LICENSE WILL BE INSTAL	LED.			
	Location: ARRIS TEST 1					
	DFSN: 103912J1103Q1226- D	M-6400 🔻				
	Serial numbers listed are a	pplicable to the licer	nse service pool inventor	y selected.		
	lf you do not see your seric 888-944-HELP (4357).	I number listed in the	e drop down above, ple	ase contact the ARRIS Technical Assist	ance Center at	
	<pre><first< pre=""> <pre><previous< pre=""></previous<></pre></first<></pre>	Next >				

Select Serial Number

5. In the **Select Serial Number** menu, select the serial number of the device on which you want to revoke the license.

Note: If you do not see your serial number listed in the menu, contact the ARRIS Technical Assistance Center for help. See "Getting Help" on page x for more information.

6. Click Next.

The Select DM 6400 Software Version Preference page opens.

- 7. Do one of the following:
 - If the software version of your unit is running version 5.6 or above, click **Yes**.
 - If the software version of your unit is running less than version 5.6, click **No**.

IMPORTANT: To use License Mobility, the DM 6400 device must be running software version 5.6 or greater. If it is running less than version 5.6, you need to upgrade the unit. Refer to the DM 6400 Software Guide for more information.

-						
NEW FEATURES!	HELP LOGOUT	SLK				
		JLK				тм
	Software License Key Ge	enerator & Serial N	lumber Repository		AR	RIS
Hello jane	Home	Orders	Inventory	Generate Keys	Tools	Profile
	SLK LICENSE MOBILITY V	VIZARD				
	PLEASE SELECT YOUR PREFEREN	NCE BELOW				
	Is the software version of	your unit running Ver	sion 5.6 or above?			
	© Yes					
	© №					
	« First < Previo	Next >				

Select DM 6400 Software Version Preference

8. Click Next.

The Select Licenses to Revoke page opens.

New Features!	HELP LOGOUT	SLK				
	Software License Key Ge	nerator & Serial Num	BER REPOSITORY		AR	RIS
Hello jane	Home	Orders	Inventory	Generate Keys	Tools	Profile
	SLK LICENSE MOBILITY W	lizard				
	Select Licenses to Revoke					
	Licenses selected which transaction.	were generated as part	of a bundle will cause	e all licenses in the orginal bundle t	o be included in this	
	4xASI-4X ASI MODULE AI-M2-MPEG-2 AD INS	· ·				
	GIGE-GigE PORT ACT	VATION Quantity - 2				
	HD-HD RATESHAPING	Quantity - 16	~			
	<pre><< First</pre> <pre></pre>	us Next >				

Select Licenses to Revoke

9. Select the licenses to revoke and click **Next**.

The Inventory Data page opens.

	HELP LOGOUT							
	Software License Key Generator 8	& Serial Numb	er Rep	OSITORY			Α	RF
Hello jane	Home Orde	ers	Inve	ntory	G	ienerate Keys		Tools
	SLK LICENSE MOBILITY WIZARD							
	REVOKE SELECTED LICENSES							
	PLEASE FIND THE INVENTORY AND CORRESPO	NDING QUANTITY T	O BE RE	VOKED LISTE	D BELOW.			
	Location: ARRIS TEST 1 Serial Number: DFSN: 103912J11030	21226- DM-640	0					
	HD RATESHAPING has dependent H	ceytype : POW	ER BLC	OCK - SD	RATESHAPING			
	КеуТуре	Qty	Unit Val	Current Val	Resultant feature Val	Sales Order	Line Number	Product Name
	4X ASI MODULE	0 ‡	4	8	8	999999991	23	DM-4A-4
	MPEG-2 AD INSERTION	0 ÷	32	64	64	999999991	17	DM-AI-32
	GigE PORT ACTIVATION	0 ‡	1	2	2	999999991	22	DM-GIGE-PORT1
	HD RATESHAPING	0 ‡	16	16	16	999999991	18	DM-HD-16
	POWER BLOCK - SD RATESHAPING	0 ‡	48	64	64	999999991	19	DM-PB-12
	POWER BLOCK - SD RATESHAPING	0 ‡	16	64	64	999999991	20	DM-PB-4
	PSIP AGGREGATION	0 ‡	1	4	4	999999991	21	DM-AG-PSIP

Inventory Data

- 10. For the licensed **Key Type**, select the quantity of licenses to revoke.
- 11. Click Calculate.

SLK calculates the quantity of licenses to revoke and displays a table with the **Resultant Feature Value**. The **Resultant Feature Value** shows the quantity that will remain on the device.

FEATURES!	HELP LOGOUT						•	
	SOFTWARE LICENSE KEY GENERATOR & S	SERIAL NUMB	er Rei	POSITORY			A	RF
llo jane	Home Orders	s	Inve	entory	e	enerate Keys		Tools
	SLK LICENSE MOBILITY WIZARD							
	REVOKE SELECTED LICENSES							
	PLEASE FIND THE INVENTORY AND CORRESPOND	ING QUANTITY T	O BE RI	EVOKED LIST	ED BELOW.			
	Location: ARRIS TEST 1 Serial Number: DFSN: 103912J1103Q12	226- DM-6400)					
	HD RATESHAPING has dependent ke	ytype : POW	ER BL	OCK - SD	RATESHAPING	e.		
	КеуТуре	Qty		Current Val	Resultant feature Val	Sales Order	Line Number	Product Name
	4X ASI MODULE	2 ‡	4	8	0	999999991	23	DM-4A-4
	MPEG-2 AD INSERTION	2 ‡	32	64	0	999999991	17	DM-AI-32
	GigE PORT ACTIVATION	2 ‡	1	2	0	999999991	22	DM-GIGE-PORT1
	HD RATESHAPING	1 🗘	16	16	0	999999991	18	DM-HD-16
	POWER BLOCK - SD RATESHAPING	1 🗘	48	64	16	999999991	19	DM-PB-12
	POWER BLOCK - SD RATESHAPING	1 🜲	16	64	48	999999991	20	DM-PB-4
	PSIP AGGREGATION	4 🜲	1	4	0	999999991	21	DM-AG-PSIP
	WARNING: ONCE A LICENSE MOBILITY REVOKI	E KEY HAS BEEN	ISSUED,	YOU WILL N	O LONGER HAVE	THE ABILITY TO GEN	ERATE OLDER NON L	CENSE MOBILITY KEY TYPE
	IN SLK.							
	КеуТуре						Resultant	
							feature Val	
	4X ASI MODULE							0
	MPEG-2 AD INSERTION Gige PORT ACTIVATION							0
	HD RATESHAPING						1	1
	POWER BLOCK - SD RATESHAPING							0
	PSIP AGGREGATION							2
	Submit							
	After you install the license/s on the un	it enter the A	cknow	vledaeme	ent code HERE t	o complete the	transaction and	d return the inventor

12. Click Submit.

A confirmation page opens.

13. Click **OK** to submit the request.

After a few moments, a table displays with the revoked license key(s).

	P LOGOUT	SLK							
Soft	ware License	E KEY GENERATOR & S	FRIAL NUMB	ER REP	OSITORY			Δ	RF
jane	Hon	ne Orders	;	Inve	ntory	G	enerate Keys		Tools
SLK	LICENSE MO	BILITY WIZARD							
Rev	oke Selected Lic	CENSES							
		ENTORY AND CORRESPOND	ING QUANTITY T	O BE RE	OKED LISTE	D BELOW.			
	ation: ARRIS	TEST 1 FSN: 103912J1103Q12	26- DM-640	1					
		G has dependent key			OCK - SD	RATESHAPING			
Ke	уТуре		Qty	Unit Val	Current Val	Resultant feature Val	Sales Order	Line Number	Product Name
4X	ASI MODULE		2 ‡	4	8	0	999999991	23	DM-4A-4
MP	EG-2 AD INSE	RTION	2 ‡	32	64	0	999999991	17	DM-AI-32
Giç	E PORT ACTIV	ATION	2 ‡	1	2	0	999999991	22	DM-GIGE-PORTI
HD	RATESHAPING	;	1 🖨	16	16	0	999999991	18	DM-HD-16
PO	WER BLOCK -	SD RATESHAPING	1 🜲	48	64	16	999999991	19	DM-PB-12
		SD RATESHAPING	1 \$	16	64	48	999999991	20	DM-PB-4
	P AGGREGATI		4 ‡	1	4	0	999999991	21	DM-AG-PSIP
IN S		A UCENSE MOBILITY REVOKE	KEY HAS BEEN	ISSUED,	YOU WILL NO	D LONGER HAVE T	HE ABILITY TO GENE	RATE OLDER NON LI	CENSE MOBILITY KEY TYPI
SI	ubmit								
ON	CE ACKNOWLEDG	EVOKE LICENSE KEYS LISTED SEMENT IS GENERATED IN TH DM/SLK/LICENSEREVOKEAC	E GUI, PLEASE E					dgement Code En	TRY HERE:
HTTF									
		TotalQuantity					LicenseKev.		
,	КеуТуре	TotalQuantity	4GYEBWV2F	PSVPQ	RFQZBY.I7		LicenseKey XE30EQA		
	C)				3DKR4WH4GS	XE3OEQA		
HD	C)	4T4EMTECSP	U4ESFL	1351OC3S	3DKR4WH4GS) DJCG5PAQITHI	XE3OEQA 5P2Y		
HD Al-I	M2 C)))	4T4EMTECSP HHXVHU5JC	U4ESFL CALPN	13510C380 1CZWYOE	3DKR4WH4GS) DJCG5PAQITHI 14SSSN4JS7OB6	XE3OEQA 5P2Y SAJXT4I		
HD Al-I SD GIO	M2 C))))	4T4EMTECSF HHXVHU5JC NXDZW2M4	U4ESFL CALPN TEVGTR	13510C3S 1CZWYOE 1YJ6ONW	3DKR4WH4GS) DJCG5PAQITHI	XE3OEQA 5P2Y SAJXT4I SUOU6H3JDI		

After obtaining the revoke license keys, you need to enter them into the DM 6400 GUI to obtain acknowledgement codes.

14. Go to "Managing Acknowledgement Codes" on page 131 to continue.

Managing Acknowledgement Codes

After obtaining the revoke license keys from SLK, you need to copy them, one at a time, into the Accounts tab of the DM 6400 GUI. The system will generate one acknowledgement code for each revoke license key entered in the DM 6400 GUI.

Once an acknowledgement is code is generated in the GUI, you need to copy it, return to SLK, and paste it in the SLK Acknowledgement Code Entry page. You'll need to repeat this procedure for each acknowledgement code that is generated in the DM 6400 GUI.

To manage:

- 1. Log on to the DM 6400 device on which you want to enter the revoke license key.
- 2. In the Element Manager GUI, click **Accounts**.
- 3. Click Enter License.

CherryPicker®	Configuration	Grooming			Analysis	Alarms		Administration	Help 🗸
	Configure	Setup			Stream	List		Aceounts	Customize
	File Editor	View/Edit		Program		Options		Log Out	Exit
			Chern	vPicker	dm00d08804c144 -]			
Admin		The Admin		, (9	vho can do	everything	^
A.T.							A	dd User Edit User	Delete User
Product Licenses							Da	ata Flash Serial # 10391	23110301226
Туре		License Key	Enabl	Used	Expiration Date		Acknowl	edgement Code	
MPEG-2 Ad Insertion		SPU4FHAOUEWRFT	64	0	None			-	
HD Recoding		2FPSVOZN7JBXESTR		0	None				
SD Recoding		JCCALP5H4SOOQQ	64	0	None				
PSIP		2AGG54JDUAJGDM	4	0	None				
GigE Port Activation		M4TEVGTCE5YU7VX	2	0	None				
ASI Output Port Activation	XRRB5RG	C524TQZCOQMG2	8	0	None				
									Enter License
20-Feb-2017	7:00:33 PM UTC	Site 1484843172249	€	U	Jser: Admin	Mode:Normal		CPR: NA	Alarm: On

DM 6400—Accounts

The Enter License window opens.

Enter Lice	nse Key	X
2	License Key OK Cancel	

Enter License Key

- 4. In the Enter License field, paste the revoke license key.
- 5. Click **Apply License**.

An acknowledgement code displays in the Acknowledgement Code column of the Product Licenses table.

CherryPicker®	Configurati	on	Grooming			Analysis		Alarms		Administra	ation	Help 🔻
	Configure	•	Setup			Stream		List		Account	s 🌖	Customize.
	File Edito	г	View/Edit		Program			Options		Log Ou	t)	Exit
				Charr	Dickor	dm00d08804c14						
					yFICKEI	01100000004014-	+ -					
Admin The Admin the user who									no can do	everything		
A T									Ad	dd User Edit	User Del	lete User
Product Licenses									Da	ata Flash Serial #	103912J11	03Q1226
Туре		l	License Key	Enabl	. Used	Expiration Dat	e		Acknowl	ledaement Code		
MPEG-2 Ad Insertion		4T4EMTECS	SPU4FHAOUEWRFT	64	0	None	G	NTMNMVJSMULBJJ3	KAKPWL	VOFJU3WNZEYT	KSZOXHFZC	CMOM
HD Recoding		4GYEBWV2	PRINTER PRINTEPPRINTER PRINTER PRINTER PRINTER PRINTER PRINTEPPRINTER PRINTER PRINTER PRINTER PRINTER PRINTER PRINTER PRINTER PRINTEPPRINT	16	0	None						
SD Recoding		HHXVHU5J	ICCALP5H4SOOQQ	64	0	None						
PSIP		VINVMHA2	AGG54JDUAJGDM	4	0	None						
GigE Port Activation		NXDZW2M	14TEVGTCE5YU7VX	2	0	None						
ASI Output Port Activation	n	XRRB5RGT	C524TQZCOQMG2	8	0	None						
											Enter	License
20-Feb-2017	7:00:33	PM UTC	Site 1484843172249	∿		Jser: Admin		Mode:Normal		CPR: NA	Ala	rm: On

DM 6400—Accounts

6. Copy the acknowledgement code you want to paste in SLK.

Tip: To copy the acknowledgement code, double-click the code and press CTRL+C. Ensure that you do not include blank spaces or extraneous characters.

Note: You can also obtain the acknowledgement code via telnet by using the ConfigDisplay -1 command.

You are now ready to return to SLK and enter the acknowledgement code.

7. Log in to SLK:

https://slk.arris.com

8. Click Inventory > Acknowledgement Code Entry.

The License Revoke Acknowledgement page opens.

NEW FEATURES!	HELP LOGOUT	LK				
:	Software License Key Genera	tor & Serial I	Number Repository		AR	RIS
Hello jane	Home	Orders	Inventory	Generate Keys	Tools	Profile
	LICENSE REVOKE ACKNOWLED Serial Number Serial Number Type Acknowledgment Code Submit	GEMENT Selec	st		•	

License Revoke Acknowledgement

- 9. In the **Serial Number** field, enter the serial number of the DM 6400 for which the acknowledgement code was generated.
- 10. From the Serial Number Type menu, select the DFSN option.
- 11. In the **Acknowledgement Code** field, paste the acknowledgement code obtained from the DM 6400 device.
- 12. Click Submit.

If successful, the message, "License Revoke Acknowledgement and inventory credit successful," displays.

Your revoked license inventory is returned to your SLK inventory pool.

- 13. Repeat steps 3 to 12 for each acknowledgement code provided in the GUI.
- 14. Verify your available license inventory in your license pool.

Go to "Viewing License Pools" on page 39 for information.

After the licenses are returned to the pool, you can select the type and quantity of licenses you need and redeploy them on one or more DM 6400 devices as needed.

Using License Mobility on CAP-1000 Devices

To use license mobility with an SLA on a CAP-1000, the device must be running software version 4.0 or greater. If it is running less than version 4.0, you need to upgrade the unit. Refer to the *CAP-1000 Software Guide* for more information.

This section explains the following procedures:

- Verifying License Availability
- Revoking Licenses
- Managing Acknowledgement Codes

To perform the procedures in this section, you will work with the CAP-1000 Element Manager GUI and the License Mobility Wizard.

Verifying License Availability

To verify:

- 1. Log on to the CAP-1000 device on which you want to revoke licenses.
- 2. Click **Setup > Licenses**.
- 3. In the **Available** column, ensure that the license types you want are available to revoke.

Setup	Triggers	Content Picking	g Alarms	Analysis			
System	Licenses	Permissions	Redundancy	Files	DVB Simulcrypt	Preferences	
roduct Licenses				1			
Туре		Total	Available	Expiration Date	Licens	se Key	Acknowledgement Code
VB ASI Output Port Activatio	n 1		1	None	D5ZH3NWUF4XK4KSWK4JM3	RFTTZCX3ZJ50PGLHWA	
PEG-4/AVC HD Recoding	2		2	None	CXXIH44PL50XHYZ76SVD55	FUNMV63BEBYZ3CJOI	
PEG-2 HD Recoding	96		96	None	QZNPPC6UQWWMPE3W2HOV	VBDANUOEX24BZE63KZYY	
PEG-2 SD Recoding	384		384	None	5NM3POB3SXLDRWR42UC26	BFDY3XMZ4SU7E6YBEI	
PEG-4/AVC Ad Insertion	1		1	None	PWK63UUSLLWR7JUICZAL60	XXE7RV5VKUKUC5M5A	
PEG-2 Ad Insertion	178		178	None	AFPLVAQ3J2YRP5TLVF0FIH	PBAWU5G5BIBIG7ELQ	
herryPicker Redundancy	1		1	None	TLCIEPLPD2HNX6ROAFZORTF	FN2CPPVLX3WOQ5VUA	
d Insertion Protection	1		1	None	GUCLWV5APJV7WSSINISBC0	QTM2P5F6KVHTCNH3A	
BIF Filtering/Merging	384		384	None	FYVLFPFNIFN56SE36BGAT30	VBMEPM7IRIEYBYI	
ISS	1		1	None	IEYEGWGFRSFPA4N2E4ZX3B	4INCOKDSQUCGHNLBY	
AS Switching	1		1	None	AIRP26IQ23H2FHULTLDKRNM	7HXVE4YN7P76G4OQ	
ALM	100		100	None	PIDEC4MXITY7JHDELFIX42YV	UTHQUPMARN7A56Y	

CAP-1000—Licenses

Next, you need to revoke the selected licenses on the device.

4. Go to "Revoking Licenses" on page 125 to continue.


Revoking Licenses

To revoke:

1. Log in to SLK:


https://slk.arris.com

2. From the menu bar, click **Generate Keys > License Mobility**.



SLK Account Home

The License Mobility Wizard opens and the current system location displays in the Locations menu.



Select Location

- 3. If you have more than one location, select **Show More Locations** and choose your location.
- 4. Click Next.

The Select Serial Number page opens.

NEW FEATURES!	HELP LOGOUT	SLK				TM				
	Software License Key Gen	NERATOR & SERIAL NU	IMBER REPOSITORY		AR	RIS				
Hello jane	Home	Orders	Inventory	Generate Keys	Tools	Profile				
	SLK LICENSE MOBILITY WIZ	ZARD								
	SELECT SERIAL NUMBER WHERE N	EW LICENSE WILL BE INSTALI	.ED.							
	Location: ARRIS TEST 2									
	LicenseGuard: 616511200047	7- CAP-1000 🔻								
	lf you do not see your seria 888-944-HELP (4357).	al number listed in the	drop down above, ple	ase contact the ARRIS Technical As	sistance Center at					
	< First < Previous	Next >								

Select Serial Number

5. In the **Select Serial Number** menu, select the serial number of the device on which you want to revoke the license key.

Note: If you do not see your serial number listed in the menu, contact the ARRIS Technical Assistance Center for help. See "Getting Help" on page x for more information.

6. Click Next.

The Select CAP-1000 Software Version Preference page opens.

- 7. Do one of the following:
 - If the software version of your unit is running version 4.0 or above, click **Yes**.
 - If the software version of your unit is running less than version 4.0, click **No**.

IMPORTANT: To use License Mobility, the CAP-1000 device must be running software version 4.0 or greater. If it is running less than version 4.0, you need to upgrade the unit. Refer to the CAP-1000 Software Guide for more information.

NEW FEATURES!	HELP LOGOUT	SLK								
		JLK				TM				
	Software License Key Ge	ENERATOR & SERIAL N	UMBER REPOSITORY		AR	RIS				
Hello jane	Home	Orders	Inventory	Generate Keys	Tools	Profile				
	SLK LICENSE MOBILITY W	IZARD								
	Please select your preference below									
	Is the software version of y	your unit running Versi	ion 4.0 or above?							
	Yes									
	© No									
	« First < Previou	Next >								

Select CAP-1000 Software Version Preference

8. Click Next.

The Select Licenses to Revoke page opens.

NEW FEATURES!	HELP LOGOUT					
		SLK				тм
	Software License Key Geni	erator & Serial Numb	BER REPOSITORY		AR	RIS
Hello jane	Home	Orders	Inventory	Generate Keys	Tools	Profile
	SLK LICENSE MOBILITY WIZ	ARD				
	Select Licenses to Revoke					
	Licenses selected which we transaction.	ere generated as part o	f a bundle will cause o	all licenses in the orginal bu	ndle to be included in this	
	AI-M2-MPEG-2 AD INSE					
	AI-M4-MPEG-4/AVC AD ASI-ASI PORT ACTIVAT		- 256 🔳			
	BISS-BISS ENCRYPTION		ity - 1 📼			
	< First < Previous	Next >				

Select Licenses to Revoke

9. Select the licenses to revoke and click **Next**.

The Inventory Data page opens.

Hello jane	SLK CONSTRUCTION MARE LICENSE KEY GENERATOR & SERIAL NUMBER REPOSITORY Mome Orders Inventory Generate Keys Tools Profile Mome Orders Inventory Generate Keys Tools Profile
Hello jane	K LICENSE MOBILITY WIZARD TOKE SELECTED LICENSES ASE FIND THE INVENTORY AND CORRESPONDING QUANTITY TO BE REVOKED LISTED BELOW. Cardion: ARRIS - Eng Labs fial Number: LicenseGuard: 616021000012- CAP-1000 vyType Qty Unit Current Resultant Sales Order Line Number Product Name
	YOKE SELECTED LICENSES ASE FIND THE INVENTORY AND CORRESPONDING QUANTITY TO BE REVOKED USTED BELOW. Cation: ARRIS - Eng Labs fial Number: LicenseGuard: 616021000012- CAP-1000 YType Qty Unit Current Resultant Sales Order Line Number Product Name
	YOKE SELECTED LICENSES ASE FIND THE INVENTORY AND CORRESPONDING QUANTITY TO BE REVOKED USTED BELOW. Cation: ARRIS - Eng Labs fial Number: LicenseGuard: 616021000012- CAP-1000 YType Qty Unit Current Resultant Sales Order Line Number Product Name
	ASE FIND THE INVENTORY AND CORRESPONDING QUANTITY TO BE REVOKED LISTED BELOW. Cation: ARRIS - Eng Labs fici Number: LicenseGuard: 616021000012- CAP-1000 vyType Qty Unit Current Resultant Sales Order Line Number Product Name
	cation: ARRIS - Eng Labs ial Number: LicenseGuard: 616021000012- CAP-1000 ryType Qty Unit Current Resultant Sales Order Line Number Product Name
	rial Number: LicenseGuard: 616021000012- CAP-1000
	Val Val feature Val
	PEG-4/AVC AD INSERTION 4 1 4 999999991 211.1 CAP1-SLK-AI-MP4
	DINSERTION PROTECTION 1 1 1 999999991 212.1 CAP1-SLK-AIP
	DINSERTION PROTECTION 0 1 1 1 999999991 219.1 CAP1-SLR
	HERRYPICKER REDUNDANCY 0 1 1 1 999999991 219.1 CAP1-SLR
	SS ENCRYPTION/DECRYPTION 0 = 1 1 1 999999991 537.2 CAP1-SLK-BISS

Inventory Data

- 10. For each licensed **Key Type**, select the quantity of licenses to revoke.
- 11. Click Calculate.

SLK calculates the quantity of licenses to revoke and displays a table with the **Resultant Feature Value**. The **Resultant Feature Value** shows the quantity that will remain on the device.

W FEATURES!	HELP LOGOUT SLK							
	SOFTWARE LICENSE KEY GENERATOR	& SERIAL N	JMBER	REPOSITO	DRY			ARF
llo jane	Home Or	ders		Inventory	/	Generate K	eys	Tools
	SLK LICENSE MOBILITY WIZARD							
	REVOKE SELECTED LICENSES							
	PLEASE FIND THE INVENTORY AND CORRESP	ONDING QUANT	ITY TO E	E REVOKED	USTED BELOW.			
	Location: ARRIS - Eng Labs Serial Number: LicenseGuard: 61	5021000012-	CAP-1	.000				
	КеуТуре	Qty		Current Val	Resultant feature Val	Sales Order	Line Number	Product Name
	MPEG-4/AVC AD INSERTION	4 ‡	1	4	0	999999991	211.1	CAP1-SLK-AI-MP4
	AD INSERTION PROTECTION	1 🜲	1	1	0	999999991	212.1	CAP1-SLK-AIP
	AD INSERTION PROTECTION	1 🜲	1	1	0	999999991	219.1	CAP1-SLR
	CHERRYPICKER REDUNDANCY	1 🜲	1	1	0	999999991	219.1	CAP1-SLR
	BISS ENCRYPTION/DECRYPTION	1 🕏	1	1	0	999999991	537.2	CAP1-SLK-BISS
	WARNING: ONCE A LICENSE MOBILITY RET	OKE KEY HAS B	EEN ISSU	JED, YOU WIL	L NO LONGER HA	ve the ability to g	ENERATE OLDER NO	N LICENSE MOBILITY KEY TYPES IN
	< Previous Recalculate							
	КеуТуре						Resultant feature Va	1
	MPEG-4/AVC AD INSERTION							0
	AD INSERTION PROTECTION							0
	CHERRYPICKER REDUNDANCY							2
	BISS ENCRYPTION/DECRYPTION							0
	Submit							
	After you install the license/s on the	unit enter th	e Acki	nowledge	ment code HEF	to complete t	ne transaction o	and return the inventory to
	your pool.			_				

Inventory Data

12. Click Submit.

A confirmation page opens.

13. Click **OK** to submit the request.

After a few moments, a table displays with the revoked license keys.

<page-header> Internet Reference 2. Serial Number Reportion</page-header>	lo jane	Home SLK LICENSE MOBILITY WIZ REVOKE SELECTED LICENSES PLEASE FIND THE INVENTORY AND Location: ARRIS - Eng Labs Serial Number: LicenseGua KeyType MPEG-4/AVC AD INSERTION	Orders ARD CORRESPONDIN rd: 6160210	IG QUANT 1000012-	IIY TO I CAP-1	Inventory 36 REVOKED 1.000	/	Generate Ki	-		_
NUME OUCL OUCL <td< th=""><th></th><th>SLK LICENSE MOBILITY WIZ REVOKE SELECTED LICENSES PLEASE FIND THE INVENTORY AND Location: ARRIS - Eng Labs Serial Number: LicenseGua KeyType MPEG-4/AVC AD INSERTION</th><th>ARD CORRESPONDIN rd: 6160210</th><th>00012-</th><th>TTY TO P</th><th>SE REVOKED</th><th></th><th>Generate Ki</th><th>ays</th><th>Tools Pro</th><th>ofile</th></td<>		SLK LICENSE MOBILITY WIZ REVOKE SELECTED LICENSES PLEASE FIND THE INVENTORY AND Location: ARRIS - Eng Labs Serial Number: LicenseGua KeyType MPEG-4/AVC AD INSERTION	ARD CORRESPONDIN rd: 6160210	00012-	TTY TO P	SE REVOKED		Generate Ki	ays	Tools Pro	ofile
Reverse Success Journal Reverse Success Journal Place Find the Invention and Corresponding Guantity to be revored infer below. Location: ARRIS - Engliable. Berick Journal States and the Number: License@uard:: 51602100012- CAP-1000 MPEG-4/AVCC AD INSERTION Image: The the Number: Product Name AD INSERTION PROTECTION Image: The the the Number: The Number: Product Name AD INSERTION PROTECTION Image: The the the Number: The Number: CAP-1-Six: All-MP4 AD INSERTION PROTECTION Image: The the the Number: CAP-1-Six: All-MP4 AD INSERTION PROTECTION Image: The the the the Number: CAP-1-Six: All-MP4 AD INSERTION PROTECTION Image: The t		REVOKE SELECTED LICENSES PLEASE FIND THE INVENTORY AND Location: ARRIS - Eng Labs Serial Number: LicenseGua KeyType MPEG-4/AVC AD INSERTION	CORRESPONDIN rd: 6160210	00012-	CAP-1	1000	USTED BELOW.				
PLAKE INDE THE VENTION AND CORRESPONDING GUANTITY TO BE REVOKED ISED BLOW. Describer: REVIEW Breiden Vention: Review Review Resultant Review Review		PLEASE FIND THE INVENTORY AND Location: ARRIS - Eng Labs Serial Number: LicenseGua KeyType MPEG-4/AVC AD INSERTION	rd: 6160210	00012-	CAP-1	1000	USTED BELOW.				
Location: KRNS - Englade Breid Number: LicenseeGuard: 61602100012 - CRP-1001 KeyType Oty Unit Current Resultant Sales Order Une Number Product Name MPEG-4/AVC AD INSERTION IIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIII		Location: ARRIS - Eng Labs Serial Number: LicenseGua KeyType MPEG-4/AVC AD INSERTION	rd: 6160210	00012-	CAP-1	1000	USTED BELOW.				
Location: KRIS - Englade Breid Number: LicenseGuard: 61602100012 - CAP-1001 KeyType Offy Unit Current Resultant Sales Order Line Number Product Name MPEG-4/AVC AD INSERTION I 1 0 999999991 211.1 CAP1-SLK-ALMP4 AD INSERTION PROTECTION IIII 1 0 999999991 219.1 CAP1-SLK-ALMP4 AD INSERTION PROTECTION IIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIII		Location: ARRIS - Eng Labs Serial Number: LicenseGua KeyType MPEG-4/AVC AD INSERTION	rd: 6160210	00012-	CAP-1	1000					
Val Val Feature Val MPEG-A/AVC AD INSERTION 4 1 4 0 999999991 211.1 CAP1-SLK-AI-MP4 AD INSERTION PROTECTION 1 1 0 999999991 212.1 CAP1-SLK-AI-P AD INSERTION PROTECTION 1 1 0 999999991 219.1 CAP1-SLR CHERRYPICKER REDUNDANCY 1 1 0 999999991 219.1 CAP1-SLR BISS ENCRYPTION/DECRYPTION 1 1 0 999999991 537.2 CAP1-SLK-BISS WARNING: ONCE A LICENSE MOBILITY REVORE KEY HAS BEEN ISSUED, YOU WILL NO LONGER HAVE THE ABILITY TO GENERATE OLDER NON LICENSE MOBILITY KEY TYPES IN SLK VERVIOUS Recolculate Submit Submit SL Previous Recolculate SLK Acknowledgement Code IN SLK Acknowledgement Code IN SLK Acknowledgement Code Entry HERE HITES:/SLK_ARRS.COM/SLK/LICENSEREVOKEACK.ASEX SL Viecense Key SL MPEG-4 0 BISSENTH745VBP5JNYLSM2 License Key SL MPEG-4 0 BISSENTH745VBP5JNYLSM2 BISSENTH745VBP5JNYLSM2 SL MPEG-4 0 <		MPEG-4/AVC AD INSERTION	Q	≀†γ	Unit						
AD INSERTION PROTECTION I I I 0 999999991 212.1 CAP1-SLK-AIP AD INSERTION PROTECTION I I I 0 999999991 219.1 CAP1-SLR CHERRYPICKER REDUNDANCY I I I 0 999999991 219.1 CAP1-SLR BISS ENCRYPTION/DECRYPTION I I I 0 999999991 537.2 CAP1-SLK-BISS WARNING: ONCE A LICENSE MOBILITY REVOKE KEY HAS BEEN ISSUED, YOU WILL NO LONGER HAVE THE ABILITY TO GENERATE OLDER NON LICENSE MOBILITY KEY TYPES IN SLK. WARNING: ONCE A LICENSE MOBILITY REVOKE KEY HAS BEEN ISSUED, YOU WILL NO LONGER HAVE THE ABILITY TO GENERATE OLDER NON LICENSE MOBILITY KEY TYPES IN SLK. WARNING: ONCE A LICENSE MOBILITY REVOKE KEY HAS BEEN ISSUED, YOU WILL NO LONGER HAVE THE ABILITY TO GENERATE OLDER NON LICENSE MOBILITY KEY TYPES IN SLK. Submit Image: Recalculate Submit Image: Recalculate WARNEL THE REVOKE LICENSE KEYS USTED BELOW IN THE UNIT GUI TO RETRIEVE ACKNOWLEDGEMENT CODE IN SLK ACKNOWLEDGEMENT CODE ENTRY HERE: HITPS://SLK.ARRS.COW/SLK/LICENSEREVOREACK.ASPX With the revoke license Revoke License Revoke Ack.aspx MeeG-4 Mark: River Total Quantity HE GUI, PIEASE ENTER THE ACKNOWLEDGEMENT CODE IN SLK ACKNOWLEDGEMENT CODE ENTRY HERE: HITPS://SLK.ARRS.COW/SLK/LICENSEREVOREACK.Aspx <td></td> <td></td> <td></td> <td></td> <td>Val</td> <td></td> <td></td> <td>Sales Order</td> <td>Line Number</td> <td>Product Name</td> <td></td>					Val			Sales Order	Line Number	Product Name	
AD INSERTION PROTECTION I I I 0 999999991 219.1 CAP1-SLR CHERRYPICKER REDUNDANCY I I I 0 999999991 219.1 CAP1-SLR BISS ENCRYPTION/DECRYPTION I I I 0 999999991 537.2 CAP1-SLR WARNING: ONCE A LICENSE MOBILITY REVOKE KEY HAS BEEN ISSUED, YOU WILL NO LONGER HAVE THE ABILITY TO GENERATE OLDER NON LICENSE MOBILITY KEY TYPES IN SUB Recolculate Submit Plesvious Recolculate Submit NESS/SUK/LICENSEREVOKEACK.ASPX Intrs://SIK.ARRS.COM/SIK/LICENSEREVOKEACK.ASPX NEWFEG-4 O AIP D BXHVW RDIKTHECCKIO QMAUV.IG2ODSF222BBHDL7QI BISS O BZSFH745VBP5J.INVISM22 AIP D BZSFH745VBP5J.INVISM22		AD INSERTION PROTECTION		4 ‡	1	4	0	999999991	211.1	CAP1-SLK-AI-MP4	
CHERRYPICKER REDUNDANCY 1 1 0 999999991 219.1 CAP1-SLR BISS ENCRYPTION/DECRYPTION 1 1 0 999999991 537.2 CAP1-SLR-BISS WARNING: ONCE A LICENSE MOBILITY REVOKE KEY HAS BEEN ISSUED, YOU WILL NO LONGER HAVE THE ABILITY TO GENERATE OLDER NON LICENSE MOBILITY KEY TYPES IN SLK. Previous Recolculate Submit Please INSTALL THE REVOKE LICENSE KEYS LISTED BELOW IN THE UNIT GUI TO RETREVE ACKNOWLEDGEMENT CODE. Once Acknowledgement Scherate on the Gui, PLASE ENTER THE ACKNOWLEDGEMENT CODE IN SLK ACKNOWLEDGEMENT CODE ENTRY HERE: HTTPS://SLK.ARRS.COM/SLK/LICENSEREVOKEACK.ASPX				1 🗘	1	1	0	999999991	212.1	CAP1-SLK-AIP	
BISS ENCRYPTION/DECRYPTION 1 1 0 99999991 537.2 CAP1-SLK-BISS WARNING: ONCE A LICENSE MOBILITY REVOKE KEY HAS BEEN ISSUED, YOU WILL NO LONGER HAVE THE ABILITY TO GENERATE OLDER NON LICENSE MOBILITY KEY TYPES IN SLK. Previous Recolculate Submit PLEASE INSTALL THE REVOKE LICENSE KEYS LISED BELOW IN THE UNIT GUI TO RETRIEVE ACKNOWLEDGEMENT CODE. Once Acknowledgement is Generated in the Gui, PLEASE ENTER THE ACKNOWLEDGEMENT CODE IN SLK ACKNOWLEDGEMENT CODE ENTRY HERE: HTTPS://SLK.ARRIS.COM/SLK/LICENSEREVOKEACK.ASPX		AD INSERTION PROTECTION		1 ‡	1	1	0	999999991	219.1	CAP1-SLR	
WARNING: ONCE A LICENSE MOBILITY REVOKE KEY HAS BEEN ISSUED, YOU WILL NO LONGER HAVE THE ABILITY TO GENERATE OLDER NON LICENSE MOBILITY KEY TYPES IN SLK. Previous Recolculate Submit		CHERRYPICKER REDUNDANC	Y	1 🜲	1	1	0	999999991	219.1	CAP1-SLR	
SLK. < Previous		BISS ENCRYPTION/DECRYPTIC	N	1 🗘	1	1	0	999999991	537.2	CAP1-SLK-BISS	
MPEG-4 0 KL7VTNI6FAISQ2IBXSHIBZSFTH745VBP5JNYLSM2 AIP 0 BXHWRDIKTTHECGKIOQMAUVJGZQD5F2ZBBHDL7QI BISS 0 BZSFTH745VBP5JNYLSM2EX6KLYMUSZNUMEDX7PQ		SLK.	e SE KEYS USTED B NERATED IN THE	BELOW IN	THE UN	t gui to ret	RIEVE ACKNOWLEI	DGEMENT CODE.			
AIP 0 BXHWRDIKTHECGKIOQMAUVJGZQD5F228BHDL7QI BISS 0 BZSFTH745VBP5JNYLSM2EX6KLYMU5ZNUMEDX7PQ	Γ	KeyType Tota	Quantity					LicenseKe	èy		1
BISS 0 BZSFTH745VBP5JNYLSM2EX6KLYMU5ZNUMEDX7PQ				-							
		UPK U		X5JH	WI/TRB	JKII6ZX2O	INKL/VINI6FAIS	3∕5irx2Hi			
After you install the license/s on the unit enter the Acknowledgement code HERE to complete the transaction and return the inventory to		Atter you install the license/ your pool.	s on the Unit	enter fr	IE ACK	nowiedge	ement codê HE	RE 10 COMPLETE 1	ne iransactión c	and reiom the inventory to	

After obtaining the revoke license keys, you need to enter them into the CAP-1000 GUI to obtain acknowledgement codes.

14. Go to "Managing Acknowledgement Codes" on page 131 to continue.

Managing Acknowledgement Codes

After obtaining the revoke license keys from SLK, you need to copy them, one at a time, on the Licenses tab of the CAP-1000 GUI. The system will generate one acknowledgement code for each revoke license key entered in the CAP-1000 GUI.

Once an acknowledgement is code is generated in the GUI, you need to copy it, return to SLK, and paste it in the SLK Acknowledgement Code Entry page. You'll need to repeat this procedure for each acknowledgement code that is generated in the CAP-1000 GUI.

To manage:

- 1. Log on to the CAP-1000 device on which you want to enter the revoke license key.
- 2. In the Element Manager GUI, click **Setup > Licenses**.
- 3. In the Enter a New License Key field, enter the revoke license key.

CherryPicker [®] Eleme	nt Manager						Groups Logs Help About Logo
Setup Tr	iggers	Content Picking	g Alarms	Analysis			
System Li	censes	Permissions	Redundancy	/ Files	DVB Simulcrypt	Preferences	
Product Licenses							
Туре		Total	Available	Expiration Date	Licens	e Key	Acknowledgement Code
VB ASI Output Port Activation	1		1	None	D5ZH3NWUF4XK4KSWK4JM3	RFTTZCX3ZJ50PGLHWA	
IPEG-4/AVC HD Recoding	2		2	None	CXXIH44PL50XHYZ76SVD55F	FUNMV63BEBYZ3CJOI	
IPEG-2 HD Recoding	96		96	None	QZNPPC6UQWWMPE3W2HOW	BDANUOEX24BZE63KZYY	
IPEG-2 SD Recoding	384		384	None	5NM3POB3SXLDRWR42UC268	BFDY3XMZ4SU7E6YBEI	
IPEG-4/AVC Ad Insertion	1		1	None	PWK63UUSLLWR7JUICZAL60	XXE7RV5VKUKUC5M5A	
IPEG-2 Ad Insertion	178		178	None	AFPLVAQ3J2YRP5TLVF0FIHF	PBAWU5G5BIBIG7ELQ	
CherryPicker Redundancy	1		1	None	TLCIEPLPD2HNX6ROAFZORTF	N2CPPVLX3W0Q5VUA	
Ad Insertion Protection	1		1	None	GUCLWV5APJV7WSSINISBC0	QTM2P5F6KVHTCNH3A	
BIF Filtering/Merging	384		384	None	FYVLFPFNIFN56SE36BGAT317	VBMEPM7IRIEYBYI	
IISS	1		1	None	EYEGWGFRSFPA4N2E4ZX3B	4INCOKDSQUCGHNLBY	
AS Switching	1		1	None	AIRP26IQ23H2FHULTLDKRNM	7HXVE4YN7P76G4OQ	
ALM	100		100	None	PIDEC4MXITY7JHDELFIX42YV	UTHQUPMARN7A56Y	
Active License Guard Serial N	lumber: 616	511200047	Enter a new licens	se key:			Apply License

CAP-1000—Licenses

4. Click Apply License.

An acknowledgement code displays in the Acknowledgement Code column of the License table.

Setup	Triggers	Content Picking	Alarms	Analysis			
System	Licenses	Permissions	Redundancy	Files	DVB Simulcrypt	Preferences	
roduct Licenses							
Туре		Total	Available	Expiration Date	License	e Key	Acknowledgement Code
VB ASI Output Port Activation	1		1	None	TU4BWFMOEADOOK4XJWRG	CPUOXBMWKVMYL240ESY	MQQQBQOSTGOY373AFTWM4TKBKAHTCTATQUODL
PEG-4/AVC HD Recoding	2		2	None	ZSI30EWJVJ46PQQ6FQXSLW	ANRJVF2B6DYSKY2JQ	52RJ2ZV5ZEJPFDDPDWDMA6FST2WMFAGBQJLSEEI
PEG-2 HD Recoding	96		96	None	E4Y6WE6A4T34W5QNMQO67	7PQ6SQJ7FRE3UBX4EI	
PEG-2 SD Recoding	384		384	None	OTTRI2N5VJNJABAFMT7BJVK	IXM7HAZ5M6LCGDQY	
IPEG-4/AVC Ad Insertion	1		1	None	6IUU4WMIBAWMK04KJ54LYEI	EBBMGQY677WXLKA6I	
IPEG-2 Ad Insertion	178		178	None	HB3TJPDBY2R2PHMGNQ5MY0	DG5JH2FFNDE3XHUCWI	
herryPicker Redundancy	1		1	None	5S7C536FFAXJWSL6BLEWXD	UX2ISWPF32CNVWIQ	
d Insertion Protection	1		1	None	OHOIDWTX6HTZ2NNG4L46E5H	KNSOJYXIGOBLNDAUI	
BIF Filtering/Merging	384		384	None	XUG5GDHFI03EQHLKX76KHX	PXKZKBLZBKHBS3CSI	
ISS	1		1	None	U33QL6LJ7XSIUKPS4TCIQWVI	BIBYFB4KSJMC6YSY	
AS Switching	1		1	None	NW4CKYPK242VJNDNA2VOV	KIIB5I6XQOSOJ3BFOA	
ALM	100		100	None	RVFNAZ7T6TAUW2THLTIMX2	TNDYS5RHCVIVPJSDA	

CAP-1000—Licences

5. Copy the acknowledgement code you want to paste in SLK.

Tip: To copy the acknowledgement code, double-click the code and press CTRL+C. Ensure that you do not include blank spaces or extraneous characters.

Note: You can also obtain an acknowledgement code via telnet by using the ConfigDisplay -1 command.

You are now ready to return to SLK and enter the acknowledgement code.

6. Log in to SLK:

https://slk.arris.com

7. Click Inventory > Acknowledgement Code Entry.

The License Revoke Acknowledgement page opens.

NEW FEATURES!	HELP LO	OGOUT	SLK				
	Software L	ICENSE KEY GEN	ierator & Serial	Number Repository		AR	RIS
Hello jane		Home	Orders	Inventory	Generate Keys	Tools	Profile
	Serial Nur Serial Nur	mber Type edgment Cod	Sele	ct		v	

License Revoke Acknowledgement

- 8. In the **Serial Number** field, enter the serial number of the CAP-1000 requiring the revoke license key.
- 9. From the Serial Number Type menu, select the License Guard option.
- 10. In the **Acknowledgement Code** field, paste the acknowledgement code obtained from the CAP-1000.
- 11. Click Submit.

If successful, the message, "License Revoke Acknowledgement and inventory credit successful," displays.

Your revoked license inventory is returned to your SLK inventory pool.

- 12. Repeat steps 3 to 11 for each acknowledgement code provided in the GUI.
- 13. Verify your available license inventory in your license pool.

Go to "Viewing License Pools" on page 39 for information.

After the licenses are returned to the pool, you can select the type and quantity of licenses you need and redeploy them on one or more CAP-1000 devices as needed.

Chapter 8 Transferring Inventory

In This Chapter

- Overview
- Transferring Serial Numbers
- Transferring Software Licenses

Overview

This chapter explains how to transfer inventory in SLK from one pool to another. This includes both licensed hardware and unconsumed licensed inventory. To generate licenses, both the purchased license and serial number must be in the same site. Use the procedures in this chapter to transfer licenses and serial numbers to the same site, if needed.

Transferring Serial Numbers

To transfer:

1. Log in to SLK:

https://slk.arris.com

2. From the menu bar, click **Inventory > License Key Sets**.

The License Hardware Serial Number page opens.

		SLK				ARR	тм
1	SOFTWARE LICEN	se Key Generator & Seriai	L NUMBER REPO	DSITORY		AKK	
Hello jane	Home	Orders		Inventory (Generate Keys	Tools	Profil
Refresh List	ARRIST	EST ARRIS TEST 1					
ARRIS TEST						COMPARE	
ARRIS TEST 1	Selec	License Key Inventory I	End User	Serial Number	Platform	Transfer	
ARRIS TEST 2		159961	ARRIS TEST 1	103912J1103Q1226	DM	TRANSFER	
		171781	ARRIS TEST 1	437CTR75sk702sc0030	02 DM	TRANSFER	
		173408	ARRIS TEST 1	B8363195VJ310F179X0	DM DM	TRANSFER	
		183168	ARRIS TEST 1	3308680287037571	SE-4000	TRANSFER	
		198607	ARRIS TEST 1	3412754209000157021	11 NE-2500	TRANSFER	
		205967	ARRIS TEST 1	6543876578902764	SE-6000	TRANSFER	
	1					Page 1 of 1	(6 items)

License Hardware Serial Number

3. Under **Select**, select the check box associated with the device you want.

4. Click **Transfer**.

The Serial Number & License Key Transfer page opens.

SERIAL NUMBER & LIC	LICENSE KEY TRANSFER	×
License Key ID:	159961	
Serial Number:	103912J1103Q1226	
Serial Number Typ	rpe: 404	
Current Site:	ARRIS TEST 1	
New Site:	ARRIS TEST 2	
	Show More Locations	
	If you do not see the location you are looking for, please contact Technical Support to r	equest access to the location.
🔲 🕶 Warning: th	this Serial Number is associated with other hardware. Check this if you wish to move associate	ed hardware with it.
	Submit	

Serial Number & License Key Transfer

5. Review the warning:

** Warning: This Serial Number is associated with other hardware. Check this if you wish to move associated hardware with it.

- 6. To proceed with the transfer, select the **Warning** check box.
- 7. Select Show More Locations.
- 8. Select the site you want.
- 9. Enter the quantity you want.
- 10. Click Submit.

If successful, the message, "Transfer Successful" displays.

SERIAL NUMBER & LI	JCENSE KEY TRANSFER	×
License Key ID:	173408	
Serial Number:	B8363195VJ310F179X00	
Serial Number Typ	pe: 404	
Current Site:	ARRIS TEST 1	
New Site:	ARRIS TEST 2 💌	
	Show More Locations	
	If you do not see the location you are looking for, please contact Technical Support to req	uest access to the location.
Varnina: th	his Serial Number is associated with other hardware. Check this if you wish to move associated	hardware with it.
Transfer Success		
	Submit	

Transfer Successful

Transferring Software Licenses

To transfer:

1. Log in to SLK:

https://slk.arris.com

2. From the menu bar, click **Inventory > License Pool**.

The License Pool Inventory page opens.

New Features! HELP LOGOUT SLK Software License Key Generator & Serial Number Repository					ARR			
Hello jane	Home Ord	ers	Inventory	/ Generate K	eys	То	ols	Profile
REFRESH LIST	ARRIS TEST		1					
 ARRIS TEST 1 ARRIS TEST 2 	End User	Sales Order	Кеу Туре	Description	A∨ailable Unit Qty	Platform		
	Key Type: 1080P							
	ARRIS (INFOSYS) - BANGALORE IN	90485014 Transfered Inventory Line 6	1080P	6XXX-SLK-1080P,6XXX SERIES ENCODER 1080P 50/60 OPTIONAL FEATURE LICENSE FINISHED GOOD	3	SE-NE-SLK	GENERATE KEY	TRANSFER
	ARRIS (Motorola) - BASINGSTOKE GB U	61013370 SO Line (4 1.1	1080P	6XXX-SLK-1080P,6XXX SERIES ENCODER 1080P 50/60 OPTIONAL FEATURE LICENSE FINISHED GOOD	5	SE-NE-SLK	GENERATE KEY	TRANSFER
	ARRIS (Motorola) - SAN DIEGO CA US 1	90482858 Transfered Inventory Line 14	1080P	6XXX-SLK-1080P,6XXX SERIES ENCODER 1080P 50/60 OPTIONAL FEATURE LICENSE FINISHED GOOD	1	SE-NE-SLK	GENERATE KEY	TRANSFER
	ARRIS (Motorola) - SAN DIEGO CA US 1	90485014 Transfered Inventory Line 1	1080P	6XXX-SLK-1080P,6XXX SERIES ENCODER 1080P 50/60 OPTIONAL FEATURE LICENSE FINISHED GOOD	22	SE-NE-SLK	GENERATE KEY	TRANSFER

License Pool

- 3. If you have more than one site, click the **Expand** button in the left panel.
- 4. Select the site you want.

Orders for the site display in tabular format.

- 5. To view the table, do the following:
 - To expand the entire table, click **Refresh List** in the left panel (if available).
 - To expand a column, select and drag it to the width you want.
 - To sort a column in alphanumeric order, click the column title.
- 6. Under the **Description** column, locate the license you want.
- 7. Click **Transfer**.

SULK Software License Key Generator & Serial Number Repository						ARR			
Hello jane	Home	Orders	;	Inventory	Generate Ko	eys	T	ools	Pro
REFRESH LIST	ARRIS TEST								
ARRIS TEST 1	End Use	r	Sales Order	Кеу Туре	Description	Available	Platform		
ARRIS TEST 2						Unit Qty			
	Кеу Тур	e: 1080P							
	ARRIS (IN BANGAL		90485014 Transfered Inventory Line 6	1080P	6XXX-SLK-1080P,6XXX SERIES ENCODER 1080P 50/60 OPTIONAL FEATURE LICENSE FINISHED GOOD	3	SE-NE-SLK	GENERATE KEY	TRANSFE
		otorola) - IOKE GB UK 4	61013370 SO Line 1.1	1080P	6XXX-SLK-1080P,6XXX SERIES ENCODER 1080P 50/60 OPTIONAL FEATURE LICENSE FINISHED GOOD	5	SE-NE-SLK	GENERATE KEY	TRANSFER
		otorola) - 30 CA US 1	90482858 Transfered Inventory Line 14	1080P	6XXX-SLK-1080P,6XXX SERIES ENCODER 1080P 50/60 OPTIONAL FEATURE LICENSE FINISHED GOOD	1	SE-NE-SLK	GENERATE KEY	TRANSFER
		otorola) - 30 CA US 1	90485014 Transfered Inventory Line 1	1080P	6XXX-SLK-1080P,6XXX SERIES ENCODER 1080P 50/60 OPTIONAL FEATURE LICENSE FINISHED GOOD	22	SE-NE-SLK	GENERATE KEY	TRANSFER

Transfer

The License Pool Inventory Transfer page opens.

LICENSE POOL INVENTORY T	RANSFER	×
Software Inventory ID	: 110747	
Product:	556944-024-00	
Current Site:	ARRIS TEST 1	
Available Qty:	4	
New Site:	ARRIS TEST 2 💌	
	Show More Locations	
	If you do not see the location you are looking for, please contact Technical Support to request access to the location	
Quantity to Transfer:	1	
	Submit	

License Pool Inventory Transfer

- 8. In the **New Site** menu, select the site you want.
- 9. Click Submit.

If successful, the message, "Transfer Successful" displays.

LICENSE POOL INVENTORY TO	tansfer	×
Software Inventory ID	: 110747	
Product:	556944-024-00	
Current Site:	ARRIS TEST 1	
Available Qty:	4	
New Site:	ARRIS TEST 2 💌	
	Show More Locations	
	If you do not see the location you are looking for, please contact Technical Support to request access to the location.	
Quantity to Transfer:	1	
Transfer Successful	Submit	

Transfer Successful

Chapter 9 Decoding Licenses and Acknowledgement Codes

In This Chapter

- Overview
- Decoding License Keys
- Decoding Acknowledgement Codes

Overview

SLK provides a function that enables you to decode license keys. License keys are associated with licensed key type on a device. You might need to decode a license key in the following circumstances:

- Verify if the license key number you have written down or cut/pasted as a reference is associated with a particular device
- Verify if a license key is valid
- Troubleshoot invalid key errors

SLK also lets you decode acknowledgement codes. These are codes provided to you during the License Mobility revoke process You might need to decode an acknowledgement code in the following circumstances:

- Verify if an acknowledgement code is valid
- Troubleshoot invalid acknowledgement code errors

Decoding License Keys

To decode:

1. Log in to SLK:

https://slk.arris.com

2. From the menu bar, click **Tools > Decode License**.

The Decode License page opens.

NEW FEATURES!	HELP LOGOUT	SLK			TM
	Software License Key Ge	NERATOR & SERIAL N	UMBER REPOSITORY		ARRIS
Hello jane	Home DECODE LICENSE Serial Number Serial Number Type Model	Orders Select BW-3200	Inventory	Generate Keys	Tools Profile Search Decode License Decode Ack Code Reports
	License Key License Mobility Decode		,		

Decode License

- 3. In the **Serial Number** field, enter the serial number of the device requiring the decode license.
- 4. From the Serial Number Type menu, select the type you want.
- 5. From the **Model** menu, select the device model.
- 6. In the **License Key** field, paste the license key of the device.
- 7. If the license key is in License Mobility software format, select the check box.
- 8. Click **Decode**.

The decoded license key information displays.

NEW FEATURES!	HELP LOGOUT					
		SLK				тм
	Software License Key Geni	AR	RIS			
Hello jane	Home	Orders	Inventory	Generate Keys	Tools	Profile
	DECODE LICENSE					
	Serial Number	103912J1103Q1	226			
	Serial Number Type	DFSN - DM proc	ducts, CAP products		•	
	Model	DM-6400	•			
	License Key	NXDZW2M4TEVGT	CE5YU7VXT54MWSLFJL			
	License Mobility					
	Decode					
	LICENSE KEY DETAILS					
	Serial Number :		103912J1103Q1226			
	License Key :		NXDZW2M4TEVGTCE5YU7VXT	54MWSLFJLN54IT07Y		
	Quantity :		2			
	License Type :		Perpetual			
	License Key Type :		GIGE			
	Product :		GigE PORT ACTIVATION			
	Feature :		Port			
	Expiration Date :		No-expiration-date			
	Sequence Number :		10			

Decoded License Details

Decoding Acknowledgement Codes

To decode:

1. Log in to SLK:

https://slk.arris.com

2. From the menu bar, click **Tools > Decode Ack Code**.

The Decode Acknowledgement Code page opens.

Orders	Inventory	Generate Keys		RR	
MENT CODE					
Select			•		
BW-3200	•				
	Select	Select	Select	Select	Select

Decode Acknowledgement Code

- 3. In the Serial Number field, enter the serial number of the device requiring the decode license.
- 4. From the Serial Number Type menu, select the type you want.
- 5. From the **Model** menu, select the device model.
- 6. In the **Acknowledgement Code** field, enter the acknowledgement code.

On the DM 6400, you can obtain this code in the Accounts tab of the GUI. On a CAP-1000, you can obtain the code in the Setup > Licenses tab of the GUI.

7. Click **Decode**.

The decoded acknowledgement code information displays.

NEW FEATURES!	HELP LOGOUT				
		SLK			тм
	Software License Key Gei	NERATOR & SERIAL N	umber Repository		ARRIS
Hello jane123	Home	Orders	Inventory	Generate Keys	Tools Profile
	DECODE ACKNOWLEDGEN	NENT CODE			
	Serial Number	616511200047			
	Serial Number Type	LicenseGuard a	and corresponding External	DFSN - CAP products	•
	Model	CAP-1000	▼		
	Acknowledge Code	G7QLMCD4LZEHH	2HAJOLXXZSZCCFKASJ:		
	Decode				
	LICENSE KEY DETAILS				
	Serial Number :	616511200047			
	Acknowledgement Code :	G7QLMCD4LZEHH2H	AJOLXXZSZCCFKASJSB3DPUY(CAPAUYKBVRQC537IWZXK63KAYXM	6SMAGNK6LFDHB6ABXN6FSV7UA
	Quantity :	48			
	Processed Date :	12/7/2016			
	Sequence Number :	2			
	License Key Type :	AI-M2			
	Product :	MPEG-2 AD INSER	TION		
	Feature :	Channel			

Decoded Acknowledgement Code Details



ARRIS Enterprises, LLC. 3871 Lakefield Drive, Suwanee, GA 30024 www.arris.com

ARRIS and the ARRIS logo are all registered trademarks of ARRIS Enterprises, LLC. Other trademarks and trade names may be used in this document to refer to either the entities claiming the marks and the names of their products. ARRIS disclaims proprietary interest in the marks and names of others.

©ARRIS Enterprises LLC, 2017. All rights reserved.

365-095-31649 x.1 5/2017

